

PHILIPS

Open-ear wireless
sports headphones

Open-ear fit

Clear call quality

TAT3708BK



Free your ears. Hear it all.

These open-ear wireless headphones let you hear everything that's going on around you-and your music too.

Hear differently

- Sound without earphones. Open-ear design
- Balanced sound wherever you are

Active all day

- IPX4 splash and sweat resistant

Powerful playlists. Clear calls

- AI mic for clear call quality

Specifications

Sound

Frequency range: 20 - 20,000 Hz
Speaker diameter: 13 mm
Impedance: 20 Ohm
Maximum power input: 5 mW
Sensitivity: 92 dB (1K Hz)
Driver type: Dynamic

Connectivity

Bluetooth version: 5.4
Wireless
Bluetooth profiles: A2DP, HFP, AVRCP
Supported codec: SBC
Type of wireless transmission: Bluetooth

Outer Carton

Length: 42.8 cm
Number of consumer packagings: 60
Width: 41.3 cm
Gross weight: 11.9 kg
Height: 29.00 cm
GTIN: 14895229149554

Convenience

Volume control
Water resistance: IPX4
Type of controls: Touch

Power

Number of batteries: 3 pcs
Music play time: 6 + 16 hour(s)
Charging time: 2 hour(s)
Battery type(Charging case): Lithium Polymer (Built-in)
Battery type(Earbud): Lithium Polymer (Built-in)
Battery capacity(Case): 300 mAh
Battery capacity(Earbud): 45 mAh

Packaging dimensions

Height: 13.4 cm
Packaging type: Box
Type of shelf placement: Hanging
Width: 13.4 cm
Depth: 4.1 cm
Number of products included: 1
EAN: 4895229149557
Gross weight: 0.14 kg
Nett weight: 0.075 kg
Tare weight: 0.065 kg

Accessories

Quick Start Guide
Charging case
Charging cable: USB-C cable

Design

Color: Black
Wearing style: Ear-hook
In-ear fitting type: Open fit

Telecommunication

Microphone for call: 1 AI mic

Dimensions

Charging case dimension(WxDxH):
9.35*5.0*2.91 cm
Earbud dimension(WxDxH): 5.0*2.05*3.55 cm
Total weight: 0.05 kg

Voice assistant

Voice assistant support

Highlights

Balanced sound everywhere

These headphones feature an Adaptive Equal Loudness Compensation (AELC) algorithm. This adjusts the treble and bass so that whether you're outside with the volume up or inside with the volume down, you'll always hear clear, balanced sound.

Clear call quality

Don't let sounds from the world interrupt your listening. These headphones feature an AI microphone that uses an advanced AI algorithm to filter out the noise you don't want to hear and ensure clear call quality. Hear each other clearly every time.

IPX4 splash/sweat resistant

An IPX4 rating and powerful 13 mm drivers let you enjoy great sound in any weather. The headphones are splash resistant and won't mind a little rain or sweat so you don't need to worry about getting caught in a shower.

Directional Acoustic design

With specialized chamber and algorithm, Directional Acoustic technology beams music into your ear canal, minimizing leakage and vibration and retaining detail and bass. All the benefits of an open-ear design with improved sound quality and comfort.

