

# PHILIPS



D-Line Display

Signage Solutions

32"

Powered by Android

400 cd/m<sup>2</sup>



32BDL4650D

## Smart and modular for an even longer lifetime powered by Android

The Philips D-Line is designed to engage your audience and delight customers. Powered by Android 11 for easy software integrations, this versatile display is suitable for impact in any setting.

### Expand your viewing experience

- ADS wide-view panel display

### Innovative solutions for any signage application

- Save and play content with internal memory
- Android SoC processor. Native and web apps

### Care about you, your business and your audience

- 4G/LTE optional module for reliable connection
- Modularity – longer product lifetime
- FailOver. Ensure your display never goes blank

### Maximising the impact of your message

- Catch the Wave for revolutionary results
- Connect and control your content via the cloud

# Highlights

## Internal Memory



Save and play content with internal memory. Upload your media into the display and playback content immediately. Working in conjunction with the internal browser, it also serves as a memory cache when streaming online content. If the network ever fails, the internal memory keeps content running by playing a cached version of the content, ensuring that your media stays up even if the network goes down.

## ADS wide-view panel display

Be seen from any angle with ADS wide-view technology. Advanced Super Dimension Switch delivers faster on-display picture processing for smoother content transitions, remarkable image accuracy and superior colour reproduction with 180 degree viewing.

## FailOver

Critical for demanding commercial applications, FailOver is a revolutionary technology that automatically plays back-up content on screen in the unlikely event of a media player failure. Simply select a primary input connection and a FailOver connection, and you're ready for instant content protection.

## Modularity

Extend your display into the future with our modular approach. Bringing opportunities for longer product lifetime with easily detached and replaced components, plus a firm focus on sustainability, with reduced WEEE disposal.

## Powered by Android 11

Powered by Android 11, your Philips D-Line delivers the ultimate, most secure and connected display experience. Optimised for native Android

apps, it enables you to install web apps and software directly onto the display, eliminating the need for an external media player.

## SmartBrowser

Connect and control your content via the cloud with our integrated HTML5, Chromium-based browser. Design your content online and connect a single display, or your entire network, either landscape or portrait. Simply connect to the Internet via an RJ45 cable.

## PPDS Wave

Unlock the power, versatility and intelligence inside your Philips D-Line displays remotely with Wave. This evolutionary cloud platform puts you fully in control, with simplified installation and setup, monitoring and controlling displays, upgrading firmware, managing playlists and setting power schedules. Saves you time, energy and environmental impact.

# Specifications

## Picture/Display

**Diagonal screen size (metric):** 81.28 cm  
**Diagonal screen size (inch):** 32 inch  
**Aspect ratio:** 16:9  
**Panel resolution:** 1920 x 1080p  
**Pixel pitch:** 0.36375 (H) x 0.36375 (V) mm  
**Optimum resolution:** 1920 x 1080 @ 60 Hz  
**Brightness:** 400 cd/m<sup>2</sup>  
**Display colours:** 16.7 Million  
**Contrast ratio (typical):** 1200:1  
**Dynamic contrast ratio:** 500,000:1  
**Response time (typical):** 8 ms  
**Viewing angle (horizontal):** 178 degree  
**Viewing angle (vertical):** 178 degree  
**Picture enhancement:** 3/2 - 2/2 motion pull down, Motion compens. deinterlacing, Dynamic contrast enhancement, Progressive scan  
**Panel technology:** ADS  
**Operating system:** Android 11  
**Haze:** 25%

## Connectivity

**Audio output:** 3.5 mm jack  
**Video input:** DVI-I (x 1), DisplayPort 1.4 (x 1), HDMI 2.0 (x 2), USB 3.0 (x 2), VGA (via DVI)  
**Audio input:** 3.5 mm jack  
**Other connections:** 4G/LTE antenna connectors, Micro USB (x 1) (OTG), USB 2.0 (x 1)  
**Video output:** DisplayPort 1.4 (x 1)  
**External control:** RJ45, RS232C (in/out) 2.5 mm jack, IR (in/out) 3.5 mm jack

## Convenience

**Placement:** Landscape (24/7), Portrait (24/7)  
**Tiled Matrix:** Up to 10 x 15  
**Screen-saving functions:** Pixel Shift  
**Keyboard control:** Hidden, Lockable  
**Signal loop through:** RS232, IR Loop through, DisplayPort  
**Energy-saving functions:** Smart Power  
**Network controllable:** RS232, External 4G mPCIe slot, RJ45

## Sound

**Built-in speakers:** 2 x 10 W RMS

## Power

**Mains power:** 100 ~ 240 VAC, 50 ~ 60 Hz  
**Consumption (Typical):** TBD W  
**Consumption (Max):** TBD  
**Standby power consumption:** <0.5 W  
**Energy Label Class:** G

## Supported Display Resolution

**Computer formats:** 1920 x 1080, 60 Hz, 1024 x 768, 60 Hz, 1280 x 1024, 60 Hz, 1280 x 720, 60 Hz, 1440 x 900, 60 Hz, 1600 x 900, 60 Hz, 1680 x 1050, 60 Hz, 640 x 480, 60 Hz, 800 x 600, 60 Hz  
**Video formats:** 1080i, 50, 60 Hz, 576i, 50 Hz, 576p, 50 Hz, 480p, 60 Hz, 480i, 60 Hz, 1080p, 50, 60 Hz, 720p, 50, 60 Hz

## Dimensions

**Set Width:** 726.5 mm  
**Product weight:** 5.7 kg  
**Set Height:** 425.4 mm  
**Set Depth:** 65.1 (@Wall mount)/ 69.1 (@AC) mm  
**Set Width (inch):** 28.60 inch  
**Set Height (inch):** 16.75 inch  
**Wall Mount:** 100 (H) x 100 (V) mm / 200 (H) x 200 (V) mm, M4  
**Set Depth (inch):** 2.56(@Wall mount)/2.72(@AC) inch  
**Bezel width:** 11.9 mm (T/L/R), 17.2 mm (B)  
**Product weight (lb):** 12.57 lb

## Operating conditions

**Altitude:** 0 ~ 3000 m  
**Temperature range (operation):** 0 ~ 40 °C  
**MTBF:** 50,000 hour(s)  
**Temperature range (storage):** -20 ~ 60 °C  
**Humidity range (operation)[RH]:** 20–80% RH (No condensation)  
**Humidity range (storage) [RH]:** 5–95% RH (No condensation)

## Multimedia Applications

**USB Playback Video:** MPEG, H.263, H.264, H.265, AVI, MP4, MPEG4, VP8, VP9, WEBM  
**USB Playback Picture:** BMP, JPEG, PNG  
**USB Playback Audio:** AAC, HEAAC, MPEG

## Internal Player

**CPU:** 2 x A72 + 4 x A53  
**GPU:** ARM Mali-T860 MP4  
**Memory:** 4 GB RAM  
**Storage:** 32 GB eMMC

## Accessories

**Included Accessories:** RS232 daisy-chain cable, Philips logo (x 1), USB Cover (x 1), Screws, AC Power Cord, AC Switch Cover, IR sensor cable (1.8 m) (x 1), Quick start guide, Remote control and AAA batteries, RS232 cable, Wire Clamper (x 3)

## Miscellaneous

**On-Screen Display Languages:** English, French, German, Spanish, Polish, Turkish, Russian, Italian, Simplified Chinese, Traditional Chinese, Arabic, Japanese, Danish, Dutch, Finnish, Norwegian, Portuguese, Swedish  
**Warranty:** 3 year warranty  
**Regulatory approvals:** CE, CCC, RoHS, CB, EMF, FCC, Class A, Energy Star 8.0, UL

