

# PHILIPS

Open-ear true  
wireless earbuds

2000 series

True wireless open earbuds

Ear-cuff style

Up to 28 hours of play time

Bluetooth multipoint

TAQ2000WT



## Ear-cuff style. Open-ear fit.

Enjoy clear audio and all-day comfort with the true wireless open earbuds that you wear like an ear cuff. Each bud clips on lightly but securely, while the open-ear design lets you hear the world as well as what you're listening to.

### **True wireless open earbuds. Ear-cuff style.**

- Ear-cuff style open earbuds. Comfy all day
- Up to 28 hours of play time. Slimline charging case
- Stable Bluetooth multipoint connectivity

### **Responsible design**

- Responsible design and packaging
- Plastic-free packaging and soy-based ink
- IPX4 splash and sweat resistant

### **Your stylish everyday companion**

- Clear calls. They'll hear what you're saying
- Customisable on-ear controls
- Philips Headphones app. Personalise your earbuds

## 2000 series

Open-ear true wireless earbuds

TAQ2000WT/00

# Specifications

### Sound

Frequency range: 20–20,000 Hz  
Speaker diameter: 12 mm  
Impedance: 16 Ohm  
Maximum power input: 10 mW  
Sensitivity: 104 dB (1K Hz)  
Driver type: Dynamic

### Connectivity

Bluetooth version: 5.4  
Bluetooth profiles: HFP, A2DP, AVRCP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC

### Outer Carton

Length: 23.90 cm  
Number of consumer packages: 24  
Width: 22.80 cm  
Gross weight: 2.640 kg  
Height: 20.00 cm  
GTIN: 1 48 95229 15917 1  
Net weight: 1.61 kg  
Tare weight: 1.03 kg

### Convenience

Water resistance: IPX4  
Philips Headphones app support  
Mono mode for TWS  
Firmware updates possible  
Type of controls: Button

### Inner Carton

Length: 11.10 cm  
Number of consumer packages: 3  
Width: 10.40 cm  
Height: 8.50 cm  
Net weight: 0.20 kg  
Gross weight: 0.290 kg  
Tare weight: 0.09 kg  
GTIN: 2 48 95229 15917 8

### Power

Number of batteries: 3  
Music play time: 7 + 21 hour(s)  
Charging time: 2 hour(s)  
Fast charging time: 15 mins for 1 hour

Battery type (Charging case): Lithium Polymer (built-in)  
Battery type (Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 11.2 g  
Battery capacity (Case): 450 mAh  
Battery capacity (Earbud): 51 mAh

### Packaging dimensions

Height: 9.80 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 9.65 cm  
Depth: 3.40 cm  
Number of products included: 1  
EAN: 48 95229 15917 4  
Gross weight: 0.091 kg  
Net weight: 0.067 kg  
Tare weight: 0.024 kg

### Accessories

Quick Start Guide  
Charging case  
Charging cable: USB-C cable, 200 mm

### Design

Colour: White  
Ear fitting: Open-ear

### Telecommunication

Microphone for call: 1 mic

### Dimensions

Charging case dimension (W x D x H): 6.55 x 2.77 x 3.92 cm  
Earbud dimension (W x D x H): 2.60 x 2.70 x 1.95 cm  
Total weight: 0.048 kg

### UPC

UPC: 8 40063 20600 7

### Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Manual  
Voice assistant support

# Highlights

### Ear-cuff style open earbuds

These open earbuds clip on lightly but securely to your outer ear, and a flexible joint lets you adjust the grip for maximum comfort. Precision air-conduction drivers direct sound into your ear canal without sealing it, so you'll hear what's going on in your immediate surroundings too.

### 28 hrs of play time (7 + 21)

You get 7 hours of play time from a full charge, and an extra 21 hours from the case. If you need a quick boost, pop the earbuds back in the case for 15 minutes to get an extra hour. It takes 2 hours to recharge the earbuds fully, and mono mode lets you use one earbud at a time while the other one charges.

### Bluetooth 5.4 multipoint

Advanced Bluetooth connectivity gives you a more stable connection for seamless streaming, and you can connect to two Bluetooth devices at the same time. Enjoy that playlist or listen uninterrupted to your favourite podcast without annoying dips in the sound.

### Responsible design

We're continually working to make our supply chain more sustainable and transparent. Our plastic-free packaging uses FSC-certified recycled cardboard and soy-based ink.

### IPX4 splash/sweat resistant

With their featherlight design, comfortable fit and an IPX4 rating, these true wireless open earbuds are ready for everyday use. Fully splash resistant, they won't mind a little sweat and you don't need to worry about getting caught in the rain.

### Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm quietens some of the background noise from the world around you.

### On-ear controls

There are handy button controls on the earbuds for playback, volume and calls. Prefer to use the left or right earbud? You can customise how these controls are set up via the Philips Headphones companion app.

### Philips Headphones app

As well as customising the on-ear controls, you can use our Headphones app to get the latest firmware updates, manage connected devices or find a missing earbud. There's an in-app equaliser too.

