



Videowall

Signage Solutions

55"

Direct LED Backlights

Full HD

500cd/m²



55BDL3305X

Captivate and connect

Remarkable retail experiences around the clock

The Philips Videowall 3000 is designed for 24/7 operation and engages customers with its dynamic, immersive content. The CMND platform simplifies the management of content, while FailOver ensures enhanced reliability and peace of mind.

Cost-effective system solution

• FailOver ensures content is always playing

Effortless setup. Total control.

- Operate, monitor and maintain with CMND & Control
- Add Android processing power with an optional CRD50 module

Powerful system solution

- Energy-saving automatic backlight control
- OPS slot allows for PC embedding without cabling
- Tiling mode. Create tiled 4K videowalls of any size

Brilliant images. Endless possibilities.

- Full HD monitors. Brilliant images. Clear contrast
- IPS panel: rich color consistency from every angle
- Ultra-narrow bezels. For distraction-free images

Videowall

55BDL3305X/00

Specifications

Picture/Display

Diagonal screen size: 54.5 inch / 138.7 cm

Aspect ratio: 16:9

Panel resolution: 1920x1080p Pixel pitch: 0.63 x 0.63 mm

Optimum resolution: 1920 x 1080 @ 60 Hz

Brightness: 500 cd/m² Display colors: 16.7 M Contrast ratio (typical): 1200:1 Dynamic contrast ratio: 500,000:1 Response time (typical): 8 ms Viewing angle (horizontal): 178 degree

Viewing angle (vertical): 178 degree

Haze: 25%

Connectivity

Audio output: 3.5 mm Mini Jack (x1)

Video input: Display Port1.2 (x1), DVI-D (x1), HDMI

2.0 (x2), VGA (Analog D-Sub) (x1) Audio input: 3.5 mm mini jack (x1)

Other connections: OPS, USB 2.0 (x1), Thermal

sensor

Video output: DisplayPort 1.2 (x1)

External control: IR (in) 3.5 mm jack, LAN RJ45 (x2)

Convenience

Placement: Landscape (24/7), Portrait (24/7)

Tiled Matrix: Up to 15 x 15

Screen saving functions: Pixel Shift, Low Bright Signal loop through: DisplayPort, RJ45 Ease of installation: Carrying Handles, Smart

Energy saving functions: Smart Power Network controllable: LAN (RJ45)

Built-in speakers: 2 x 10W (RMS)

Power

Consumption (On mode): 140 W Consumption (Typical): 180 W Consumption (Max): 340 W Standby power consumption: 0.5W

Energy Label Class: G

Supported Display Resolution

Computer formats: 720 x 400, 70Hz, 800 x 600, 60, 75Hz, 1024 x 768, 60, 75Hz, 1280 x 768, 60Hz, 1280 x 800, 60Hz, 1280 x 960, 60Hz, 1280 x 1024, 60Hz, 1360 x 768, 60Hz, 1366 x 768, 60Hz, 1600 x 1200, 60Hz, 1920 x 1080, 60Hz, 640 x 480, 60, 72, 75Hz

Video formats: 1080p, 50, 60Hz, 720p, 50, 60Hz, 1080i, 25, 30Hz, 2160P 50, 60Hz ((HDMI/OPS/DP)

Dimensions

Set dimensions (W x H x D): 1211.3 x 682.1 x 97.8 mm (D@WallMount) / 97.8 mm (D@Handle) mm Smart Insert mount: 100mm x 100mm, 6xM4xL6 Product weight: 28.8 kg Wall Mount: 400 x 400 mm, M6

Set dimensions in inch (W x H x D): 47.69 x 26.85 x 3.85 (D@WallMount) / 3.85 (D@Handle) inch Bezel width (combined): <3 mm

Operating conditions

Altitude: 0 ~ 3000 m

Temperature range (operation): 0 ~ 40 °C

MTBF: 50,000 hour(s)

Temperature range (storage): -20 ~ 60 °C Humidity range (operation)[RH]: 20 ~ 80%

(without condensation)

Humidity range (storage) [RH]: 5 ~ 95% (without condensation)

Accessories

Included Accessories: Gap pad x3, IR sensor cable (1.8 m) (x1), Quick start guide (x1), Remote control & AAA batteries, RJ45 / RS232 converter, Wire Clamper (x3), Power cord, DP cable (x1), RJ45 cable (x1), Edge alignment pin (x2), Kit-1 (x1), Kit-2

Miscellaneous

On-Screen Display Languages: Arabic, English, French, German, Italian, Japanese, Polish, Russian, Spanish, Simplified Chinese, Turkish, **Traditional Chinese** Warranty: 3 year warranty

Regulatory approvals: CE, FCC, Class A, RoHS, CB, ETL, BSMI

Highlights

CMND & Control

Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

Optional CRD50 module

Embed an Android System-on-Chip (SoC) in your Philips Professional Display. The optional CRD50 module is an OPS device that enables Android processing power without the need for cables. Simply slide into the OPS slot, which contains all the connections needed to run the module (including power supply).

FailOver

From waiting room to meeting room, never show a blank screen. FailOver lets your Philips Professional Display switch automatically between primary and secondary inputs ensuring content keeps playing even if the primary source goes down. Simply set a list of alternate inputs to be sure your business is always on.

Pure Colour Pro

Boost image quality with Pure Colour Pro. Delivering higher luminance through custom colour temperature settings and advanced gamma calibration, content looks crisper and more radiant for stunning realism with a visual pop.

OPS slot

Integrate a full-power PC or Android-powered CRD50 module directly into your Philips Professional Display. The OPS slot contains all the connections you need to run your slot-in solution, including a power supply.

Tiling mode

Connect two or more Philips professional displays to create a tiled videowall-without the need for external devices. A single player takes care of content, whether you have four screens or 40. 4K content is fully supported, and if you're showing that content on four screens you get the best possible dot-by-dot resolution.

© 2025 Koninkliike Philips N.V. All Rights reserved.

Issue date 2025-04-22 Version: 5.5.1

EAN: 87 21038 10147 8

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

