

# PHILIPS



Facial recognition  
smart door lock

7000 series

3D face unlock

Radar motion detection

4-inch LCD display



DDL720CCCKW

## Your face, your key

Unlock, touch-free

Experience the ease of face recognition unlocking with the Philips DDL720-FVP-7HWS. Dual cameras simulate human eye imaging to capture and recognize 3D facial features, unlocking your door touch-free—your face is the key.

### Smart life "locked" with excellence

- With touch-free convenience
- Stay informed about your doorstep while away
- Monitor your home online 24/7
- Smart lighting for clearer sight, even at night
- Data encrypted for added security

### Secure protection, smart embedded

- Your instant home guarding assistant
- Elevate your privacy and security
- Automatically locks with every close
- Say goodbye to the security concern

### Easy life goes beyond this

- Know what's outside at a glance
- Ideal for the whole family
- One turn, instant unlock

## 7000 series

Facial recognition smart door lock

DDL720CCCKW/00

# Highlights

### 3D face unlock

When you approach the Philips smart lock DDL720-FVP-7HWS within 1 meter\*, the radar sensor activates, triggering the facial recognition module. The dual-front cameras capture your unique facial features in 3D, effectively identifying photos, videos, makeup, and more—making face unlocking seamless and manual door opening a thing of the past.

### Work with Home Access App\*

The DDL720-FVP-7HWS works with the Home Access App. Once connected to the network, you can access lock operation records, doorbell notifications, and unlocking history anytime, anywhere. Instant pop-up alerts for any unusual activity keep you informed and secure at your doorstep.

### Video door viewer

When visitors ring the doorbell, you'll receive an instant notification on the Home Access App. Tap the message to start a two-way audio conversation and remotely view your doorstep. Plus, the video door viewer automatically captures photos or videos with each ring. If you can't respond right away, you can easily check visitor details in the logs.

### Wide-angle night vision camera

The DDL720-FVP-7HWS features a wide-angle camera and four low-power infrared lights, offering both daytime and night vision modes. As the light dims, the infrared lights

automatically activate, switching seamlessly to night vision. It can clearly recognize facial features from up to 2 meters away.

### Cloud storage\*

Once the cloud storage service is activated, the DDL720-FVP-7HWS securely uploads encrypted snapshots and recordings to the cloud. Even if the lock is tampered with or damaged, your data remains safe and accessible at any time through the Home Access App.

### Smart motion tracking

The DDL720-FVP-7HWS features a radar sensor that triggers the video door viewer when it detects unusual activity within 1 meter\* of your door. It instantly sends the alert to the Home Access App, allowing you to easily monitor your doorstep and boost your home security.

### One-tap voice change

The DDL720-FVP-7HWS offers real-time voice changing, letting you choose from 'Original Voice', 'Deep Voice', or 'Funny Voice' during remote video communication. Easily disguise your true voice when interacting with strangers, enhancing your privacy and security.

### Mechanical electronic mortise\*

The DDL720-FVP-7HWS features a mechanical electronic mortise that offers superior security and convenience compared to common mechanical locks. When the sensor latch is triggered, the system automatically checks the

lock status. If the door is closed, an external motor engages within 10 seconds\* to secure the lock, ensuring your home safety.

### Real-time push alerts

Home security, fully protected. The DDL720-FVP-7HWS offers multiple safety alerts, including latch anomalies, armed mode\*, tamper alerts, system lockout, and loitering detection. Any unusual activity is instantly sent to the app, ensuring your home remains secure at all times.

### 4-inch LCD display

The indoor assembly features a 4-inch LCD display, allowing you to check visitors and your doorstep without opening the door. Just tap the screen for quick access—no more traditional peepholes—making it ideal for seniors and kids. Customize brightness and screen timeout through the Home Access App for a personalized experience.

### 5 unlocking methods

The DDL720-FVP-7HWS supports five unlocking methods: facial recognition, fingerprint, PIN code, key tag, and mechanical key. With versatile options, it effortlessly adapts to various situations, making it especially convenient for seniors and children.

### Indoor quick-open handle

The indoor assembly features a quick-open handle. In emergencies, if the smart lock's electronic functions fail, a simple turn of the handle is all it takes to unlock the door, ensuring your safety and peace of mind.

## 7000 series

Facial recognition smart door lock

DDL720CCCKW/00

# Specifications

### Design & Appearance

**Color:** Sky grey  
**Handle:** Push-pull handle  
**Main Material:** Aluminium alloy  
**Surface Processing:** Baking varnish  
**Facial Recognition:** Supported  
**Fingerprint Sensor:** Semiconductor  
**Display:** 4-inch LCD display  
**Palm vein recognition:** Not supported

### Access Solution

Fingerprint  
Password/PIN Code  
Temporary PIN code  
Card/Key Tag  
Mechanical Key  
Face Unlock

### Lock Capacity

**Fingerprint:** Up to 100(Master fingerprint incl.)  
**Card/Key Tag:** Up to 100  
**Master PIN Code:** 1  
**User PIN Code:** Up to 20(One-time codes incl.)  
**Face ID:** Up to 50

### Power Specification

**Battery Type:** Li-polymer Battery  
**Time of Use:** 3 months\*  
**Emergency Power Supply:** 5V power bank

### Easy Operation

**Voice Guide:** Real voice navigation

### Smart Lock Functions

**Mortise:** C grade lock cylinder  
**Locking Function:** Indoor lock-out, System locking  
**Safety Function:** Hidden PIN code, Dual verification, Armed mode, Indoor quick-open

handle

**Alarm Function:** Tamper alert, Armed mode alert, Latch abnormality alert, System locking alert, Low battery alert

### Mode

**Operation Mode:** Manual mode, Auto mode  
**System Setup Mode:** General mode, Dual verification mode

### Installation

**Door Thickness:** 38-120 mm, Other range\*  
**Door Opening Direction:** Right inward opening, Left outward opening, Right outward opening, Left inward opening  
**Door Type:** Wooden door, Copper door, Security door  
**Door backset:** 70mm

© 2025 Koninklijke Philips N.V.  
All Rights reserved.

Issue date 2025-09-29  
Version: 2.2.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 69 71318 50558 4

[www.philips.com](http://www.philips.com)



\* Home Access App: the DDL720-FVP-7HWS works with Home Access App.

\* Cloud storage: only subscribers to the cloud storage service can access historical recorded videos; non-subscribers can view only high-definition snapshots.

\* 1 meter: the radar sensor detects activity up to 1 meter. Loitering alerts are turned off by default but can be activated in the Home Access App. You can adjust loitering sensitivity in the App: high sensitivity at 1 meter and low sensitivity at 0.5 meters. Set loitering duration to 10, 20, 30, or 60 seconds.

\* Mechanical electronic mortise: refers to mortises that feature an external motor and electronic detection. When the sensor latch is triggered and the door lock is closed, the external motor engages the deadbolt to complete the locking.

\* 10 seconds: data sources from internal testing data.

\* Armed mode: only available when using a mortise with a detection switch. If a mortise without a detection switch is used, the armed mode function will be unavailable.

\* Special Features: The armed mode requires the standard 311 mortise with a built-in detection module to activate arming and latch anomaly alerts. These functions are unavailable if a mechanical mortise without a detection switch is used.

\* 3 months: this is internal test data; actual battery life may vary with usage frequency.

\* Other range: the included installation kit is suitable for doors with the mentioned thickness. For doors outside this range, please contact authorized Philips smart lock consumer care centers or designated offline dealers.