

# PHILIPS

USB power bank

27,000 mAh

3 USB charging ports

QC 3.0 and PD 3.0

PPS

DLP1965CB



## Powerful power bank with 65W output

### Dual output with PD3.0

Massive 27,000 mAh capacity with safe Li-polymer battery. PD 65 W output to charge your laptop, mobile phone and more. Supports fast charge protocols QC 3.0, PD 3.0 with PPS. With multiple national safety certifications and protection systems

#### Superior Charging Design

- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously
- USB-A with QC fast charging

#### Confirm operation at a glance

- LCD display for power indication

#### Portable power

- Works anywhere - great when you're not near a power source

# Highlights

## Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

## LCD display for power status

LCD display for power indication



## USB-A with QC fast charging

Quick Charge (QC) fast-charging technology delivers faster charging by increasing voltage and current. It uses the Quick Charge protocol to optimise charging speeds for compatible devices, reducing charge times.

## 3 USB charging ports

3 USB ports to charge three devices simultaneously

## Outer Carton

GTIN: 14895229159478

## Inner Carton

GTIN: 24895229159475

## Compatibility

Works with the following: USB-charged devices

## Power

**Battery Capacity:** 9000 mAh@11.1 V (99.9 Wh, cell qty: 9000 mAh\*3, 27,000 mAh in total)

**Battery type:** Li-Polymer

**Power input:** USB-C1 input: 5 V/3 A, 9 V/3 A, 12 V/3 A, 15 V/3 A, 20 V/3 A (60 W max.) Micro USB input: 5 V/2 A, 9 V/2 A

**Output:** USB-C1 output: 5 V/3 A, 9 V/3 A, 12 V/3 A, 15 V/3 A, 20 V/3.25 A (65 W max.) USB-C2 output: 5 V/3 A, 9V/2A (18 W max.) USB-A output: 5 V/3 A, 9 V/2 A (18 W max.) Max power: PD65W

## Packaging dimensions

**Type of shelf placement:** Both

**Number of products included:** 1

**EAN:** 4895229159471

**Gross weight:** g kg

## Product dimensions

**Height:** 14.8 cm

**Width:** 6.45 cm

**Depth:** 3.95 cm

**Weight:** 0.54 kg

