

PHILIPS

True wireless
headphones

2000 series

Small buds. Great value

Natural sound. Dynamic bass

Pocket-sized charging case

4 mic technology



TAT2000PK

The essential everyday buds

Upgrade your everyday essentials with these small, true wireless earbuds that fit like a dream and sound great too. You get up to 32 hours of play time with the pocket-sized charging case, and your calls will be clearer than ever.

Packed with essential features

- Stable Bluetooth multipoint connection and easy pairing
- Google Fast Pair and Microsoft Swift Pair compatible
- Quick charge for 10 minutes and get an extra hour
- IPX4 splash and sweat resistant

True wireless earbuds. Great value, great sound.

- Great sound even at low volume with Dynamic Bass
- 6 mm driver and dynamic bass-boost function
- Up to 32 hours of play time. Pocket-sized charging case
- 4 mic technology. Clearer calls, even in crowded places

Ready for you

- Comfy fit and customisable on-ear touch controls
- Philips Headphones app. Personalise your earbuds
- Warm, natural sound. Philips sound signature
- Responsible design and packaging

Highlights

Great sound. Dynamic Bass

These true wireless earbuds might be small, but you won't need to turn up the volume to get the best sound out of their 6 mm drivers. Activate Dynamic Bass via the earbud controls or the Philips Headphones app, and you can enjoy the full power of your favourite basslines even if you're listening quietly.

32 hrs of play time (7 + 25)

You get 7 hours of play time from a full charge, and an extra 25 hours from the case. Pop the earbuds back in the charging case and they'll recharge fully in 2 hours. If you need a quick boost, just 10 minutes gives you an extra hour, and Mono mode lets you use either earbud while the other one charges. The case can be charged via USB-C.

4 mic technology

If you're on a call, our 4 mic set up and a noise-reduction algorithm will combine to pick up the sound of your voice and quieten background noise. Even if you're in a busy café, your voice will

come through clearly and the person you're speaking to won't need to listen to all the other conversations going on around you as well!

Bluetooth 5.4 multipoint

Bluetooth 5.4 brings you a steadier connection for seamless streaming without annoying dips in the sound. You can connect to two Bluetooth devices at the same time and manage connected devices via the Philips Headphones app. Android users can also use Google Fast Pair and Windows users can use Microsoft Swift Pair.

IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

Comfy fit and touch controls

The ear tips rest gently but securely in your ear canal, and interchangeable silicone ear-tip covers let you find your perfect fit. Touch controls on the earbuds keep things simple, and you can customise how these controls are set up via the Philips Headphones companion app.

Philips Headphones app

As well as customising the earbud touch controls, our companion app lets you activate Dynamic Bass or fine-tune your sound with the in-app equaliser. Plus, you can use the app to manage connected devices, keep your earbud's firmware up to date — and more.

Philips sound signature

From music to podcasts, you'll love what you hear! These true wireless earbuds feature large drivers tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.

Responsible design

We're continually working to make our supply chain more sustainable and transparent. These earbuds are made with RCS-certified, post-consumer recycled plastics and our plastic-free packaging uses FSC-certified recycled cardboard and soy-based ink.

2000 series

True wireless headphones

TAT2000PK/00

Specifications

Sound

Frequency range: 20–20,000 Hz
Speaker diameter: 6 mm
Impedance: 16 Ohm
Maximum power input: 5 mW
Sensitivity: 104 dB (1k Hz)
Driver type: Dynamic

Connectivity

Bluetooth version: 5.4
Bluetooth profiles: A2DP, AVRCP, HFP
Maximum range: Up to 10 m
Multipoint connection
Supported codec: SBC

Outer Carton

Length: 24.80 cm
Number of consumer packages: 24
Width: 22.30 cm
Gross weight: 2.817 kg
Height: 21.20 cm
GTIN: 1 48 95229 16029 0
Net weight: 1.51 kg
Tare weight: 1.307 kg

Convenience

Water resistance: IPX4
Philips Headphones app support
Mono mode for TWS
Firmware updates possible
Type of controls: Touch
Google Fast Pair
Microsoft Swift Pair

Inner Carton

Length: 11.50 cm
Number of consumer packages: 3
Width: 10.20 cm
Height: 9.00 cm
Net weight: 0.19 kg
Gross weight: 0.313 kg
Tare weight: 0.123 kg
GTIN: 2 48 95229 16029 7

Power

Number of batteries: 3 pcs
Music play time: 7 + 25 hour(s)
Charging time: 2 hour(s)
Fast charging time: 10 mins for 1 hr
Battery type (Charging case): Lithium Polymer (Built-in)
Battery type (Earbud): Lithium Polymer (Built-in)
Battery weight (Total): 12.1 g
Battery capacity (Case): 520 mAh
Battery capacity (Earbud): 45 mAh

Packaging dimensions

Height: 9.5 cm
Packaging type: Carton
Type of shelf placement: 1
Width: 9 cm
Depth: 3.3 cm
Number of products included: Hanging
EAN: 48 95229 16029 3
Gross weight: 0.089 kg
Net weight: 0.063 kg
Tare weight: 0.026 kg

Accessories

Quick Start Guide
Eartips: 3 sizes (S/M/L)
Charging case
Charging cable: USB-C cable, 200 mm

Design

Colour: Pink
Ear coupling material: Silicone
Ear fitting: In-ear
In-ear fitting type: Silicone ear-tip

Telecommunication

Microphone for call: 4 mics

Dimensions

Charging case dimension (W x D x H): 5.70 x 2.60 x 4.40 cm
Earbud dimension (W x D x H): 2.50 x 1.90 x 3.00 cm
Total weight: 0.041 kg

UPC

UPC: 8 40063 20632 8

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant
Voice assistant activation: Multi-Function touch
Voice assistant support

