

PHILIPS

Travel Charger and
Power Bank

10,000 mAh

Black

DLP5712CB



Versatile travel-mate Power Bank

Maximum 22.5 W output

10,000 mAh capacity Power Bank. No more hassle when charging your mobile devices. Supports fast charging with 20 W PD. With integrated Lightning and USB-C cable. Power status LED display

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- 50% charge in 30 minutes
- USB-A with QC fast charging
- USB-C PD 20 W charging port

Portable power

- Works anywhere - great when you're not near a power source

Highlights

USB-C PD 20 W charging port.

Equipped with USB-C (Power Delivery) PD 20 W fast charging port.

USB-A with QC fast charging

Quick Charge (QC) fast-charging technology delivers faster charging by increasing voltage and current. It uses the Quick Charge protocol to optimise charging speeds for compatible devices, reducing charge times.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Specifications

Outer Carton

GTIN: 14895229156514

Inner Carton

Number of consumer packages: 1

GTIN: 24895229156511

Compatibility

Works with the following: USB-charged devices

Power

Battery Capacity: 10,000 mAh

Battery type: Lithium-ion

Power input: USB-C input: 5 V/3 A, 9 V/2 A, 12 V/1.5 A

Output: USB-A output: 5 V/3 A, USB-C output: 5 V/3 A, 9 V/2.22 A, 12 V/1.5 A (20 W max), USB-C Cable output: 5 V/3 A, 5 V/4.5 A, 9 V/2 A, 12 V/1.5 A (22.5 W max), Lightning Cable output: 5 V/2 A, 9 V/2.22 A (20 W max)

Packaging dimensions

Number of products included: 1

EAN: 4895229156517

Product dimensions

Height: 8.09 cm

Width: 8.79 cm

Depth: 2.47 cm

Accessories

Cables: Integrated USB-C and Lightning Cable

User Manual: Included

Charging and Control

Charging indicators: LED

Charging

Wireless power output: 15 W

