

# PHILIPS

Indoor over-ear  
headphones

9000 series

Retro design, sparkling sound

Wired open-back headphones

Angled 50 mm drivers

Comfy for long listening

SHP9500CY



## The Freddie

Ooh, they're your best friend! Give the music you love the sound it deserves with these classic-looking, open-back wired headphones. Built for home listening, they boast audiophile-grade tuning, groovy retro style, and modern comfort.

### **Century Series. Wired open-back headphones.**

- Looks from back then, sound from now
- Open-back, over-ear headphones. Get closer to your music
- Crafted for at-home listening

### **The Freddie celebrates 100 years of Philips sound**

- Angled 50 mm neodymium drivers. Authentic hi-fi sound
- Controlled bass. Sparkling highs. Natural midrange
- Audiophile-grade connections and long 3 m cable

### **Retro looks. Modern comfort and performance.**

- Double-layered headband and breathable ear-cup cushions
- Durable steel outer headband
- Warm, detailed, natural. Philips sound signature
- Responsible design and packaging

## 9000 series

Indoor over-ear headphones

SHP9500CY/00

# Highlights

### Retro design, superb sound

Leather trousers, your best shirt, and the retro 70s look of these over-ear headphones! Whether you're rocking out to vinyl from back in the day or streaming the latest single drop, it's time to kick back and get into the warm, authentic sound.

### Open-back headphones

The open-back design lets you feel the soul of your music. With no enclosure trapping the sound, you'll be treated to an immersive, spacious performance that separates voices and instruments so you can enjoy the full impact of every note. It's like being in the studio with your favorite band.

### 50 mm neodymium drivers

The neodymium drivers are engineered to tilt at 15 degrees, fitting the natural geometry of your ear so you hear every frequency with optimal accuracy. You get sparkling highs, controlled lows, and a midrange that's lush and natural. Perfect for any music you care to throw at them.

### Supreme comfort

The chocolate-brown inner headband is supremely soft, and the breathable ear-cup cushions keep your ears cool during long

listening sessions. The durable steel outer headband promises years of use and provides just the right amount of clamp to keep these headphones comfortably in place.

### Wired hi-fi headphones

From your stereo to your favorite armchair, the included 3 m cable gives you plenty of reach. The gold-plated connector and 6.3 mm jack adapter make sure you get the best connection when listening on audiophile-grade equipment.

### Philips sound signature

Music to podcasts, these headphones make the most of the sounds you love! You'll enjoy warm, detailed sound with rich bass from the large drivers, which are tuned to the Philips sound signature.

### Responsible design

We're continually working to make our supply chain more sustainable and transparent. Our packaging uses FSC-certified recycled cardboard and soy-based ink.

# Specifications

### Sound

**Acoustic system:** Open  
**Frequency range:** 12 - 35,000 Hz  
**Speaker diameter:** 50 mm  
**Impedance:** 32 Ohm  
**Sensitivity:** 101 dB (1K Hz, 1mV)  
**Speaker diameter:** 50 mm  
**Maximum power input:** 20 mW  
**Driver type:** Dynamic

### Connectivity

**Cable Connection:** single-sided cable  
**Finishing of connector:** gold-plated  
**Cable length:** 3 m  
**Connector:** 3.5 mm  
**Headphone socket:** 3.5 mm

### Outer Carton

**Length:** 37.20 cm  
**Number of consumer packagings:** 3  
**Width:** 20.30 cm  
**Gross weight:** 1.96 kg  
**Height:** 24.20 cm  
**GTIN:** 1 48 95229 16007 8  
**Nett weight:** 0.97 kg  
**Tare weight:** 0.99 kg

### Packaging dimensions

**Height:** 24.3 cm  
**Packaging type:** Carton  
**Type of shelf placement:** Hanging  
**Width:** 19.1 cm  
**Depth:** 11.8 cm  
**Number of products included:** 1  
**EAN:** 48 95229 16007 1  
**Gross weight:** 0.542 kg  
**Nett weight:** 0.324 kg  
**Tare weight:** 0.218 kg

### Product dimensions

**Height:** 21.00 cm  
**Width:** 19.00 cm  
**Depth:** 10.30 cm  
**Weight:** 0.296 kg

### Accessories

**Included adapters:** 3.5-6.3 mm adapter plug

### Design

**Color:** Century brown  
**Wearing style:** Headband  
**Ear coupling material:** Fabric  
**Ear fitting:** Over-ear  
**Earcup type:** Open-back

### UPC

**UPC:** 8 40063 20606 9

