

PHILIPS

Indoor over-ear
headphones

9000 series

Retro design, sparkling sound

Wired open-back headphones

Angled 50 mm drivers

Comfy for long listening

SHP9500CY



The Freddie

Ooh, they're your best friend! Give the music you love the sound it deserves with these classic-looking, open-back wired headphones. Built for home listening, they boast audiophile-grade tuning, groovy retro style and modern comfort.

Century Series. Wired open-back headphones.

- Looks from back then, sound from now
- Open-back, over-ear headphones. Get closer to your music
- Crafted for at-home listening

The Freddie celebrates 100 years of Philips sound

- Angled 50 mm neodymium drivers. Authentic hi-fi sound
- Controlled bass. Sparkling highs. Natural midrange
- Audiophile-grade connections and long 3 m cable

Retro looks. Modern comfort and performance.

- Double-layered headband and breathable ear-cup cushions
- Durable steel outer headband
- Warm, detailed, natural. Philips sound signature
- Responsible design and packaging

9000 series

Indoor over-ear headphones

SHP9500CY/00

Highlights

Retro design, superb sound

Leather trousers, your best shirt and the retro 70s look of these over-ear headphones! Whether you're rocking out to vinyl from back in the day or streaming the latest single drop, it's time to kick back and get into the warm, authentic sound.

Open-back headphones

The open-back design lets you feel the soul of your music. With no enclosure trapping the sound, you'll be treated to an immersive, spacious performance that separates voices and instruments so you can enjoy the full impact of every note. It's like being in the studio with your favourite band.

50 mm neodymium drivers

The neodymium drivers are engineered to tilt at 15 degrees, fitting the natural geometry of your ear so you hear every frequency with optimal accuracy. You get sparkling highs, controlled lows and a midrange that's lush and natural. Perfect for any music you care to throw at them.

Supreme comfort

The chocolate-brown inner headband is supremely soft and the breathable ear-cup cushions keep your ears cool during long

listening sessions. The durable steel outer headband promises years of use and provides just the right amount of clamp to keep these headphones comfortably in place.

Wired hi-fi headphones

From your stereo to your favourite armchair, the included 3 m cable gives you plenty of reach. The gold-plated connector and 6.3 mm jack adapter make sure that you get the best connection when listening on audiophile-grade equipment.

Philips sound signature

Music to podcasts, these headphones make the most of the sounds you love! You'll enjoy warm, detailed sound with rich bass from the large drivers, which are tuned to the Philips sound signature.

Responsible design

We're continually working to make our supply chain more sustainable and transparent. Our packaging uses FSC-certified recycled cardboard and soy-based ink.

Specifications

Sound

Acoustic system: Open
Frequency range: 12 - 35,000 Hz
Speaker diameter: 50 mm
Impedance: 32 Ohm
Sensitivity: 101 dB (1K Hz, 1 mV)
Speaker diameter: 50 mm
Maximum power input: 20 mW
Driver type: Dynamic

Connectivity

Cable Connection: single-sided cable
Finishing of connector: Gold-plated
Cable length: 3 m
Connector: 3.5 mm
Headphone socket: 3.5 mm

Outer Carton

Length: 37.20 cm
Number of consumer packages: 3
Width: 20.30 cm
Gross weight: 1.96 kg
Height: 24.20 cm
GTIN: 1 48 95229 16007 8
Net weight: 0.97 kg
Tare weight: 0.99 kg

Packaging dimensions

Height: 24.3 cm
Packaging type: Carton
Type of shelf placement: Hanging
Width: 19.1 cm
Depth: 11.8 cm
Number of products included: 1
EAN: 48 95229 16007 1
Gross weight: 0.542 kg
Net weight: 0.324 kg
Tare weight: 0.218 kg

Product dimensions

Height: 21.00 cm
Width: 19.00 cm
Depth: 10.30 cm
Weight: 0.296 kg

Accessories

Included adapters: 3.5-6.3 mm adapter plug

Design

Colour: Century brown
Wearing style: Headband
Ear coupling material: Fabric
Ear fitting: Over-ear
Earcup type: Open-back

UPC

UPC: 8 40063 20606 9

