

PHILIPS

Smart lever door lock

6000 series

Intuitive fingerprint unlock

Mute by "0" button

Safehandle function

With 60mm door backset

DDL603LKABW



Unlock new joy in life

Wi-Fi connection, smart life under control

Wi-Fi-enabled DDL603E-5HWS supports you to distribute one-time PIN code and check the access records remotely, etc. With the fingerprint sensor integrated into the handle, unlocking is conveniently in one grip, adding more fun to your life.

Smart life locked with excellence

- Allow one grip to unlock

Caring designs comes with high quality of life

- Voice prompt makes operation easier
- Leave a quiet place for the family
- Ensure home secure and eliminate risk while away

Highlights

Intuitive fingerprint



Adopted the integrated handle design with an FPC semiconductor fingerprint, the fingerprint recognition speed of Philips DDL603E-5HWS is less than 0.5 s. Pressing down the handle allows one grip to unlock and brings you a fast and intuitive opening experience.

Mute by "0" button



The "0" button is used both as a digit button and a mute button. Long press the "0" button for 2 seconds to enable the mute mode no matter you are in or out. Without disturbing your family at night, the thoughtful design allows you to get back home in a quiet manner, which leaves a quiet place for the family.

Safehandle function



You can enable the safehandle feature before leaving home. After the door is locked, the indoor handle will be frozen so that nobody could open the door by pressing down the inside handle. This feature can prevent children and pets from accidentally opening the door, thus eliminating security risks.

Low battery level alert



When the door lock's battery level is less than 20%, it will trigger an alert. The Philips DDL603E-5HWS has an emergency power supply Micro-USB interface, which allows charging by the output voltage of 5V power bank. The operation is simple, and the working state of the smart lock is fully assured, allowing you to use it with peace of mind every day.

Specifications

Design & Appearance

Color: Obsidian black

Handle: Lever handle

Fingerprint Sensor: Semiconductor

Access Solution

Fingerprint

Password/PIN Code

Card/Key Tag

Mechanical Key

Lock Capacity

Card/Key Tag: Up to 100

Master PIN Code: 1

User PIN Code: Up to 20

One-time PIN Code: 1

Power Specification

Power Supply: 4 AA batteries

Time of Use: 10 months*

Maximum Batteries Capacity: 8 batteries

Emergency Power Supply: 5V power bank

Easy Operation

Indicator: Door locks status prompt, Low battery prompt, Mute status prompt, System locking prompt

Voice Guide: Human voice guide

Smart Lock Functions

Mortise: C grade lock cylinder

Locking Function: Indoor deadlock

Safety Function: Dual verification, Hidden PIN code

Installation

Door Thickness: 38-60 mm, 60-90 mm, 90-120 mm, Other range*

Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward opening

Door Type: Antitheft door, Copper door, Wooden door

