

PHILIPS

Smart video door
lock

3000 series

Remote unlocking

3.5-inch IPS screen

Temporary PIN code unlock

With 60mm door backset

DDL303BFACW



Remote unlocking

Easy life is under control

Philips DDL303-VP-5HWS integrates door viewer, doorbell, and door lock features. Stay connected via Wi-Fi and use Smart Life App for remote unlocking and lock records. Embrace a smart, convenient life without limitations!

Secure protection, smart embedded

- One-step mechanical rotation for unlocking
- Protect real password from being peeping
- Instantly protect home security at all times

Easy life goes beyond this

- Fit for multiple mechanical mortises
- One-key quick locking
- Say goodbye to the key-only era
- Leave a quiet place for the family

Smart life "locked" with excellence

- Allow easy life in one step
- Clear viewing at the doorway

Highlights

One-click remote unlock



The "#" key is used both as a doorbell button and a "#" key. When the door lock is in sleep mode and pressing the "#" key can activate the doorbell, and the camera will immediately capture the photo and uploads it to the Smart Life App. After viewing the logs and confirming the visitor's information, you can unlock the door remotely through the App with a singel tap, allowing the visitors to enter the door easily.

3.5-inch IPS screen



The inside assembly is equipped with a 3.5-inch IPS display screen, allowing you to instantly view the situation outside the door without opening the door. This feature is especially beneficial for families with elderly individuals or young children, as there is no need to log into the Smart Life App. It ensures a more user-friendly and hassle-free experience for everyone.

Indoor quick opening



The inside assembly of the door lock equips with a quick-open handle and a rotary knob. If an emergency leads to the malfunction of the smart door lock, it does not affect the opening of the

door lock. Rotating the handle or the rotary knob allows emergency egress, which could ensure the users' safety.

20-digit hidden PIN code



With the 20-digit hidden PIN code technology, Philips DDL303-VP-5HWS lets you enter any random number combination of up to 20 digits, including the valid PIN code, to verify and unlock the door. This feature ensures security, prevents peeping, and safeguards your real PIN code.

Multiple alerting



Our DDL303-VP-5HWS smart lock comes with multiple alerts including anti-disassembly, system lock-out, low battery alert etc. It not only provides constant protection for your home, but also keeps you updated on the condition of the door lock in real time for your convenience.

Universal structure design



The DDL303-VP-5HWS has a universal interchangeable design, compatible with various standard mechanical mortises*. Enjoy a smart lifestyle without the need to replace the mortise. It can be installed on wooden doors, security doors, and various door types, including doors

equipped with concealed lock rods, offering high adaptability and an easy installation experience for your convenience.

"Lock" key settings



The "*" key is used both as a "lock" button and an "*" key. Upon normal use, the dead bolt will pop out and lock automatically upon door closing. If you want to achieve instant door locking upon closing, you can wake up the keypad and long press the "*" key for 2 seconds to make the dead bolt pop out immediately, realizing one-key quick locking.

Various ways of unlocking



Fingerprints, PIN codes, Smart Life App, key tags, and mechanical keys are available unlocking methods, which can meet the need of different users, and are applicable for the whole family.

Mute by "0" key



The "0" key is used both as a digit button and a mute button. Press and hold the "0" key for 2 seconds to enable the mute mode. Without disturbing your family at night, the thoughtful design allows you to get back home in a quiet manner.

3000 series

Smart video door lock

DDL303BFACW/00

Specifications

Design & Appearance

Color: Red copper

Handle: Push-pull handle

Main Material: Aluminium alloy

Fingerprint Sensor: Semiconductor

Access Solution

Fingerprint

Password/PIN Code

Temporary PIN code

Card/Key Tag

Mechanical Key

Mobile APP

Power Specification

Battery Type: Li-polymer Battery

Time of Use: 3 months*

Emergency Power Supply: 5V power bank

Easy Operation

Voice Guide: Human voice guide

Smart Lock Functions

Mortise: C grade lock cylinder

Installation

Door Thickness: 38-60 mm, 60-90 mm, 90-120 mm, Other range*

Door Opening Direction: Left inward opening, Left outward opening, Right inward opening, Right outward opening

Door Type: Antitheft door, Copper door, Wooden door

