

# PHILIPS

Wifi Smart Deadbolt

4000series

Built-in Wi-Fi

Fingerprint access

ANSI/BHMA Grade 3

Physical keypad

DDL242XI5KNW



## Essential Smart Security

### 4 ways to unlock

Classic design meets cutting-edge technology—the physical keypad panel offers easy use, while built-in Wi-Fi provides full smart functionality, including remote control, real-time notifications, and multiple unlock methods.

#### Seamless ease of use

- 4 ways to unlock your door with ease
- Fingerprint access for all your instant moments
- Auto-lock your door with peace of mind

#### Technical solutions

- Remote control your lock through app on your smartphone
- Works with voice assistants for easy smart home integration

#### Enhanced security and safety

- Let you stay informed in all critical situations

# Highlights

## Remote control through app

With the Philips Home Access app, you can lock and unlock your door remotely, share PIN codes, monitor real-time notifications, and check your lock's activity history—all from your smartphone, ensuring complete control over your home's security no matter where you are.

## 4 ways to unlock

Choose the unlock method that fits your lifestyle the moment you arrive home. You can choose from unlocking with your fingerprint, PIN codes, keys, or just unlock the door with a gentle touch of the Philips Home Access app on your smartphone.

## All-in-one security alerts

The lock provides all-in-one security alerts, including Away mode alarm when you leave home, Jam alarm for latch blockage, Low battery alert for timely maintenance, and Wrong-entry limited Alarm triggered when multiple incorrect attempts are made within a short period. These alerts keep you informed and enhance home security.

## Fingerprint access

With 0.3s recognition speed, a 99% recognition rate, and the ability to store up to 20 fingerprints, you can enjoy quick and secure access. Just a simple touch for fast, reliable entry every time.

## Works with voice assistants

Seamlessly integrate the lock into your smart home system with Amazon Alexa or Google Assistant. Use voice commands to lock, unlock the door, and check door status, offering convenient hands-free control.

## Auto-lock

The Auto-lock feature automatically locks your door after a set time (between 10-180 seconds). Whether you're in a rush or simply forget, this feature ensures your door is securely locked, offering convenience and enhancing your home's security.

# Specifications

## Access solution

Password

## Design

Material: Aluminum alloy

Color: Satin nickel

## Installation

Bolt type: Dead bolt

Keyway: SC1

Door thickness: 1-3/8 to 2 inch (35-50mm)

Opening direction: Right inside / Right outside, Left inside / Left outside

Cross bore hole: 1-1/2 or 2-1/8 inch (38/54mm)

Backset: 2-3/8 or 2-3/4 inch (60mm/70mm)

## Connectivity

Bluetooth

Wi-Fi

Z-Wave: No

## Access solutions

Unlocking from outside: Fingerprint, PIN code, Mechanical key, Home Access app

Unlocking from inside: Thumb turn, Home Access app, Voice assistant

## Max Credentials Capacity

Fingerprint: 20

Master PIN code: 1

User PIN code: 100

One-time PIN code: Unlimited

## Modes

Operation mode: Manual mode, Auto mode

Security mode: Away mode

## Power

Power supply: 8 AA batteries

Emergency powering: Not supported

## Operating Environment

Temperature: From -35°C to 66°C

Humidity: 0-95%

## Key Features

Safety: Local storage, AES128, ANSI/BHMA Grade 3

Alarm: Low battery alarm, Wrong entry limit alarm, Jam alarm

Remote control: App unlock, Generate temporary PIN codes, Simple sharing, Manage user account

## Voice guide

Language: English / French / Spanish

## Accessory

Wi-Fi bridge: Not included

