

# PHILIPS

USB power bank

20,000 mAh

3 USB charging ports

QC 3.0 and PD 3.0

PPS

DLP7721C



## Powerful power bank

with a portable back-up power pack

Big 20,000mAh capacity with safe Li-polymer battery. No more hassle when your cellphone is out of battery. Fast charge your device with USB-C PD 3.0 Max 20W or USB-A port with QC 3.0 Max 18W output.

### Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously
- USB-A with QC fast charging
- USB-C PD 20W charging port

### Confirm operation at a glance

- LED power-indicator light

### Portable power

- Works anywhere - great when you're not near a power source

# Highlights

## USB-C PD 20W charging port.\

Equipped with USB-C (Power Delivery) PD 20W fast charging port.

## USB-A with QC fast charging

Quick Charge (QC) fast charging technology delivers faster charging by increasing voltage and current. It uses Quick Charge protocol to optimize charging speeds for compatible devices, reducing charge times

## 50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.



## Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

## Smart Protection

Smart protection against overheating, overvoltage and overcurrent

## LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is powered.

## Design and finishing

**Materials:** PC + ABS

## Outer Carton

**Length:** 34 cm

**Number of consumer packagings:** 18

**Length:** 13.4 inch

**Width:** 24 cm

**Height:** 22.5 cm

**GTIN:** 1 48 95229 13553 3

**Width:** 9.4 inch

**Height:** 8.9 inch

## Inner Carton

**Length:** 22 cm

**Number of consumer packagings:** 6

**Length:** 8.7 inch

**Width:** 10.7 cm

**Height:** 20.5 cm

**Width:** 4.2 inch

**Height:** 8.1 inch

**GTIN:** 2 48 95229 13553 0

## Compatibility

**Works with the following:** USB charged devices

## Power

**Battery Capacity:** 20,000mAh 74Wh

**Power input:** Type-C 5V/3A, MicroUSB 5V/2A

**Output:** USB-C Max 20W USB-A Max 18w

## Packaging dimensions

**Height:** 17 cm

**Type of shelf placement:** Both

**Width:** 9.5 cm

**Depth:** 3.5 cm

**Height:** 6.7 inch

**Number of products included:** 1

**EAN:** 48 95229 13553 6

**Width:** 3.7 inch

**Depth:** 1.4 inch

## Product dimensions

**Height:** 13.6 cm

**Width:** 6.8 cm

**Depth:** 2.75 cm

**Width:** 2.7 inch

**Height:** 5.4 inch

**Depth:** 1.1 inch

**Weight:** 0.355 kg

**Weight:** 0.783 lb

## Accessories

**Cables:** USB-C charging cable

**User Manual:** User Manual

