

# PHILIPS

Home Projector

NeoPix 150

180 degrees rotative stand

Full HD 1080p resolution

Up to 80" screen size

Silent fan

NPX150



## Compact, versatile and immersive

Experience entertainment like never before with the NeoPix 150. Compact and built to transform any space into your personal theater. Its innovative 180-degree rotating stand allows for effortless projection on virtually any flat surface.

### **Wireless and sound**

- Wireless screen mirroring
- Stereo speakers

### **Image and technology**

- LED light source
- Full HD 1080p

### **Unlimited screening options**

- up to 80" screen size
- 180 degrees rotative stand

# Highlights

## LED light source

The high-quality LED light system delivers rich, vivid colours that last up to 30,000 hours. With an average use of 4 hours per day, this projector will last for up to 20 years.

## Wireless screen mirroring

Connect your mobile devices such as tablets, smartphones or even computers wirelessly to mirror and share your contents. With the Dual band (2.4 and 5GHz), your connection will get even more stable and faster for smoother playback.

## up to 80" screen size

Enjoy your favorite movies, shows, and more on a stunning projection of up to 80 inches — delivering crisp visuals and rich detail for a truly immersive viewing experience.

## Stereo speakers

Immerse yourself in outstanding sound quality with the audio system, featuring two speakers for a truly exceptional audio experience. Need a bigger sound? The 3.5 mm jack output is there to connect your earphones or external speakers.

## 180 degrees rotative stand

Break free from traditional viewing with its innovative 180 degree rotating stand. This feature invites you to redefine the boundaries of your entertainment.

## Full HD 1080p

Bring your entertainment to life with True Full HD 1080p — enjoy razor-sharp images, deep contrast and crystal-clear text for an unforgettable viewing experience.

# Specifications

## Technology

**Display technology:** LCD

**Light source:** LED

**Brightness:** up to 250 lumens\*

**Contrast ratio:** 1000:1

**Resolution:** 1920 x 1080 pixel

**Throw ratio:** 1,2:1

**Aspect ratio:** 16:9

**Focus adjustment:** Manual

**Keystone correction:** Auto

**LED lifetime:** Up to 30.000h

**Projection image size:** up to 80" (200cm)

**Recommended usage:** 80" in dark room

## Connection

**Wi-Fi:** Dualband 2.4GHz and 5GHz

**WLAN IEEE 802.11 b/g/n:** screen mirroring function

**HDMI:** x1

**USB:** x1

**Audio out:** 3.5 mm jack

**DC-IN**

## Sound

**Stereo Speaker:** 2x3W

## Dimensions

**Weight:** 0.85 kg

**unpacked (WxDxH):** 126x208x144mm

## Power source

**Power consumption:** Standby less than 0.5 W

**DC-in:** 100-240V AC 50/60Hz 1 A



\* Colour brightness (colour light output) and white brightness (white light output) will vary depending on projector settings. Colour light output measured in accordance with IDMS 15.4; white light output measured in accordance with ISO 21118.

\* The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.