

PHILIPS

Wall charger

Power Delivery

3 USB charging ports

GaN 100W

White

DLP6332CW



Wall charger with 2 USB-C and USB port

100W output with GaN technology

Maximum 100W output wall charger with 2 USB-C and 1 USB-A port. Able to charge your laptop and 2 other devices simultaneously. UK socket.

Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent
- 50% charge in 30 minutes
- Wall charger with GaN technology

Top Performance

- USB-C port with Power Delivery support

Highlights

USB-C port with PD

USB-C is the latest charging connector standard, which is now adopted by mobile devices such as cell phones, cameras and tablets. PD (Power delivery) is the USB standard for power delivery for more power and fast charging.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. The compact chargers can provide more power with faster charging times. The increased power are capable to power deliver to modern laptops with USB-C connection.

50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.

Specifications

Design and finishing

Color(s): White

Materials: PC

Outer Carton

GTIN: 14895229165103

Inner Carton

Number of consumer packagings: 1

GTIN: 24895229165100

Power

Adaptor type: UK type

Power input: 100-240V~ 50/60Hz, 2A max

Output: USB C1/C2 : 5V/3A,

9V/3A,12V/3A,15V/3A, 20V/5A 100W Max, USB

A: 5V/3A, 9V/3A,10V/2,5 A, 12V/2.25A 27W

Max. USB C1+ USB C2 or USB C1+ USB A:

65W+27W Max. USB C2+ USB A: 5V/4.8A, 24W

Max.

Packaging dimensions

Packaging type: Box

Number of products included: 1

EAN: 4895229165106

Product dimensions

Height: 6.8 cm

Width: 3.2 cm

Depth: 6.15 cm

