

PHILIPS

Portable Radio

CENTURY

Classic design, modern sound

FM/DAB+ digital tuning

Bluetooth® 5.4

User-replaceable battery

TAV2000DB



The Janet

Poetry for the eyes and ears! This portable home radio is designed to delight with its bold looks and rich, warm sound. Enjoy clear FM and DAB+ radio and easily stream playlists: there's a headphone jack for private listening too.

CENTURY range. FM/DAB+ portable home radio.

- Looks from back then, sound from now
- 2.5" full-range driver. 5 W of rich, warm sound
- FM/DAB+ digital tuner with 20 FM and 20 DAB+ presets
- Two presets can be allocated to quick-access buttons
- Bluetooth® 5.4 for a stable, longer-range connection

The Janet celebrates 100 years of Philips sound

- Classic 1950s rounded form factor
- Modern colourful display with adjustable brightness
- Telescopic aerial for clear reception
- 3.5 mm audio-out for wired headphones

Classic looks. Modern features and performance

- Easily replaceable built-in rechargeable battery
- Dual alarms and Sleep Timer
- Responsible design and packaging

Highlights

Classic design, modern sound

Come for the classic design, stay for the warm sound. This portable radio brings back the rounded design and tactile volume knob of 1950s radios, and adds a dash of warm, surprisingly powerful sound from its 2.5" full-range driver. It's the perfect blend of legacy and innovation.

FM/DAB+ with up to 40 presets

This DAB+/FM radio gives you the widest selection of stations, and its telescopic aerial ensures crystal-clear reception. Digital tuning makes stations easy to find, and you can store 20 FM presets and 20 DAB+ presets. Your two favourite stations can be allocated to the quick-access buttons marked "1" and "2" on the front of the radio.

Bluetooth® 5.4

This classic-looking radio does more than just radio. Bluetooth® 5.4 connectivity lets you stream podcasts, playlists and more from your smart

device to the radio. You'll enjoy a stable connection with high-quality sound, even if your playlist is streaming from the phone you left in another room.

Replaceable built-in battery

With a built-in rechargeable lithium-ion battery that's easily replaceable when it reaches the end of its life, you can depend on The Janet radio for years to come! You get approx. 15 hours of play time from a full charge, and it takes around 3.5 hours via USB-C to fully recharge the battery.

Colourful TFT display

The clear TFT display gives you station icons in full colour, plus artist and song information from the DAB+ station you're listening to. A digital clock shows the time, and you can adjust the brightness to suit your room or dim the display at night.

Dual alarms and Sleep Timer

If you like falling asleep to the sound of the radio, you can use the Sleep Timer to control how long the radio plays for—and set two alarms to ensure that you wake up. Alarms can use an alarm tone or the radio, and the volume starts low before gradually increasing.

Audio out

Want to enjoy your favourite radio show while your partner watches TV? A 3.5 mm audio-out jack means you can plug your wired headphones into the radio and keep your sounds to yourself.

Responsible design

We're continually working to make our supply chain more sustainable and transparent. This clock radio is made with post-consumer recycled plastics, and our packaging uses FSC-certified recycled cardboard and soy-based ink.

Specifications

Sound

Output power (RMS): 5 W
Sound System: Mono
Volume control: rotary (digital)
Output power (MAX): 10 W
Total harmonic distortion: <10%

Loudspeakers

Full-range driver diameter: 2.5"
Number of full-range drivers: 1

Connectivity

Bluetooth: Yes, support SBC and AAC streaming
Bluetooth version: 5.4
Bluetooth profiles: A2DP, AVRCP
Bluetooth range: 25 m (free space)
3.5 mm headphone jack
Audio in: No

Tuner/Reception/Transmission

Antenna: Telescopic
Auto digital tuning
Tuner bands: FM, DAB/DAB+
Station presets: 20 FM, 20 DAB+
DAB: info display, menu, smart scan
RDS: Yes.

Convenience

Backlight colour: black
Display type: TFT display

Power

Battery Capacity: 3.65 V, 2600 mAh
Battery type: Li-ion polymer (replaceable)
Input: 5 V, 2 A
Standby power consumption: 0.8 W
Operating time on battery: 15 hour(s)
Power type: DC in (via USB-C)
Charging time: 3.5 hour(s)

Packaging dimensions

Height: 12.5 cm
Packaging type: Box
Type of shelf placement: Standing
Width: 21.5 cm
Depth: 11.5 cm
Number of products included: 1
Gross weight: 0.761 kg
Net weight: 0.618 kg
Tare weight: 0.143 kg

Product dimensions

Height: 11.16 cm
Width: 19 cm
Depth: 9.15 cm
Weight: 0.55 kg

Accessories

Included accessories: USB cable, Quick start guide, Warranty certificate

Alarm

Alarm source: DAB radio, FM radio, Buzzer
No. of alarms: 2
Sleep timer: 15/ 30/ 60/ 90/ 120 mins
Snooze (repeat alarm): 10/20/30/40/50/60 mins
Gentle Wake
Kitchen timer
Alarm frequency:
Once/Daily/Weekday/Weekend

Clock

Display: TFT
Type: Digital
Time format: 12 H, 24 H
Brightness control (Dim): High/Medium/Low

