

PHILIPS

Bluetooth party speaker

200 W max (100 W RMS), Bass+

Full-speaker lightshow

Bluetooth® Auracast™ and TWS

AC or battery power

TAX5000



Big sound. Epic bass.

Bring on the bass beats! This party speaker plays loud with a whole lot of feeling. Our Bass+ tech delivers deep, distortion-free bass at any volume. Full-speaker party lights, dual mic and guitar inputs, and echo effects bring the fun.

Portable party speaker. Deep, controlled bass.

- Big sound for epic parties. 100 W RMS and Bass+
- 2x 8" woofers, 2x 2" tweeters
- Cue the tunes! Bluetooth®, aux-in, and USB playback
- TWS and Auracast™ for multi-speaker setups

Full-speaker lightshow, AC or battery power

- Mic and guitar inputs, plus echo effects
- Full-speaker lightshow. Club vibes from top to bottom
- 13 different lighting modes let you set the perfect vibe
- Built-in battery for up to 14 hours playback, and AC input

Rock up ready to party

- Built-in carry handle and wheels. IPX4 splash proof
- Easy control via speaker panel or our companion app
- Dimensions/weight: 73.3x32x32.3 cm, 11.4 kg

Highlights

200 W max (100 W RMS), Bass+

Love a good bassline? With two 8" woofers and our exclusive Bass+ technology, the bass on this party speaker will sound deep, rich, and full—even if you're listening at lower volumes while chilling out at the end of the night. You get 200 W max (100 W RMS) of earth-shaking sound, and two 2" tweeters mean vocals don't just sing, they soar.

Bluetooth® 5.4

Stream your playlists, plug in a USB drive, or go ahead and hook up your DJ decks or CD player via audio-in. If you're streaming tunes, Bluetooth® 5.4 brings you a faster, steadier connection for better sound quality that won't dip. It also gives you a wider range so you can control those playlists from practically anywhere in the party.

TWS and Auracast™ compatible

Want more? For a wider soundstage, you can pair with another TAX5000 speaker via True Wireless Stereo (TWS). For bigger events or the

ultimate house party, you can broadcast the tunes to as many Auracast™ compatible speakers as you could ever need! Send the beats around the house or create a wall of sound in one room.

Mic and guitar inputs

There's nothing like a karaoke session or impromptu live performance for bringing everyone together. This party speaker comes equipped with two mic inputs and a 6.3 mm guitar input: you can control mic and guitar volume, and add echo effects, using physical controls on the speaker panel or use our companion app.

Full-speaker lightshow

When the tunes are pumping, a rainbow of colorful RGB LED lights shimmer and pulse on the surface of the twin woofers as well as along the sides and the bottom of the speaker. There are 13 light-effect modes to choose from: simply press the light button on the speaker or use our companion app to get the lightshow started.

Built-in battery and AC input

Dance until the morning comes. The built-in battery gives you up to 14 hours of play time on a single charge, and you can always plug this party speaker into the AC power outlet to keep the tunes coming while it recharges. A full recharge takes approximately 4 hours.

Splash proof and easy to move

Roll up to a friend's house. Set up on a patio. The carry handle and wheels make it easy to move this party speaker and it's splash proof too. A little rain won't stop the tunes—and if you drop the bassline and hands go up with drinks still in them, just wipe off any spills and party on.

Easy control

You can take control of the volume, lights, and karaoke effects via the speaker panel—or use the Philips Entertainment app, which also lets you fine-tune bass and treble frequencies. Want to keep the neighbors happy? You can turn Bass+ off and scale back the bass via our app or the Bass+ button on the speaker.

Specifications

Sound

Output power (RMS): 100W (Based on IEC 60268 standard. This rating was not tested under the FTC standard.)

Sound enhancement: Bass+, Karaoke

Frequency response: 20Hz - 20kHz, ±3dB

Output power (MAX): 200W (Based on IEC 60268 standard. This rating was not tested under the FTC standard.)

Total harmonic distortion: 10%

Speaker impedance: 4 ohm

Loudspeakers

Driver configuration: 2-way

Number of sound channels: 2

Number of tweeters: 2

Number of woofers: 2

Tweeter diameter: 2"

Woofer diameter: 8"

Connectivity

Bluetooth version: 5.4

Bluetooth profiles: A2DP, AVRCP, Streaming

Format: SBC

Bluetooth range: 10M (free space)

USB: Type-A (playback)

Audio in: 1x 3.5mm Line in

USB charging: 5V, 1A

Mic in: 2 x (6.3mm w/ vol control)

Guitar input: 1 x (6.3mm w/ vol control)

DLNA Standard: No

Multiple speaker connection

Multiple speaker scenario: Stereo, Broadcasting, Receiving

Multiple speaker technology: TWS, Auracast

Smart Home: None

Supported Audio Formats

Bluetooth: SBC

USB: MP3

Convenience

Karaoke: echo control, MIC volume

Buttons and controls: Mic volume and echo, Guitar volume, Lighting switch, Bass+, Auracast, Play/Pause, Bluetooth, Power on/off, Main unit volume, Treble and Bass control

Volume control: Rotary

Water resistance: IPX4

Light Effect: Yes, 13 light effects

Guitar control

Compatibility

Smartphone/tablet APP control

Power

Battery Capacity: 5200 mAh, 7.3 V

Power supply: 100-240VAC, 50/60Hz

Standby power consumption: <0.5W

Battery Type: Lithium-ion

Operating time on battery: 14 hour(s)

Charging time: 4 hour(s)

Packaging dimensions

Height: 84 cm

Packaging type: Box

Type of shelf placement: Standing

Width: 41 cm

Depth: 41 cm

Number of products included: 1

Gross weight: 14.6 kg

Nett weight: 12 kg

Tare weight: 2.6 kg

Product dimensions

Height: 73 cm

Width: 32 cm

Depth: 32 cm

Weight: 11.9 kg

Accessories

Included accessories: USB cable, Quick start guide, Warranty certificate, Safety warranty sheet

