

# PHILIPS

Wet & Dry Electric  
Shaver

Shaver 1000 Series

PowerCut Blades

3D Floating heads

Anti-corrosion European steel

Wet & Dry shave

S1882/00



## Fast shave

Philips Shaver 1000 Series gives you a fast, clean shave at an accessible price. The 27 self-sharpening PowerCut Blades, wet & dry use and full washability make the shaver easy to use and provide excellent value.

### Fast and clean shave

- PowerCut Blades for a consistent, clean shave
- 3D Floating Heads for a comfortable shave
- Anti-Corrosion European blades

### Easy to use

- Wet and dry shaving at the sink or in the shower
- Waterproof for easy cleaning or shower use
- 35 minutes of cordless shaving from a 1-hour charge
- Sleek lines and youth aesthetic
- One-touch open for easy cleaning
- Battery status at a glance
- Protective cap keeps the shaving head clean
- USB-A for convenient charging

## Shaver 1000 Series

Wet & Dry Electric Shaver

S1882/00

# Highlights

### PowerCut Blades



27 self-sharpening blades with 3.5 million cutting motions/minute consistently cut each hair up to 0.046 mm for a smooth, even finish every time.

### 3D Floating Heads



Floating heads move freely in three directions to keep contact with the curves of your face, ensuring a comfortable shaving experience.

### Anti-Corrosion European steel

The self-sharpening blades are made from surgical-grade steel to resist corrosion and they stay like new for 2 years.

### Wet and dry shaving

Choose a convenient dry shave, or pair with your favorite foam or gel for a refreshing wet shave, even in the shower.

### Iconic design

With its sleek lines and a youthful aesthetic, the design of the shaver seamlessly blends into any contemporary lifestyle.

### One-touch open

The shaver head flips open at the touch of a button to rinse it under running water.

### 35 minutes of cordless shaving

A durable NiMH battery provides 35 minutes of shaving power on a 1h charge. In a hurry? A 5-minute quick charge gives you enough power for one shave.

### Waterproof (IPX7)

Rinse under running water or shave in the shower. The IPX7 waterproofness rating means it can be submerged in one meter of water for up to 30 minutes.

### Protective cap

Keep the shaving head clean and safe between shaves or when traveling.

### Battery indicator

Don't get caught with an empty battery. The battery indicator lets you know if the battery is low or charging.

### USB-A Charging

At Philips, we drive sustainability in all aspects of product creation. Our ambition is to reduce waste and minimize the number of USB adaptors we put in the market. Should you need an adapter, a suitable supply unit is available via: [www.philips.com/support](http://www.philips.com/support)

# Specifications

### Accessories

**Maintenance:** Protective cap, SH30, Charging cable

### Power

**Charging time:** 1 hour full charge

**Run time:** 35 minutes

**Battery type:** NiMH

**Quick charge:** Yes, 5 minutes

### Design

**Color:** Dark Forest

**Handle:** Self-standing shaver

### Service

**Replacement head:** Replace every 24 months with SH30

**2-year warranty**

### Shaving Performance

**Shaving system:** PowerCut blade system, 27 self-sharpening blades, 3.500.000 cutting movement/min

**Contour following:** 3D Floating Heads

### Ease of use

**Display:** Alive indicator

**Cleaning:** One-touch open, Fully washable

**Wet & Dry:** Shave wet or dry

**Operation:** Cordless use only

**Waterproof:** Waterproof IPX7, Showerproof

### Skin Protect technology

**Skin Protection:** Anti-corrosion Shaving System

