

PHILIPS

Wall charger

USB-A and USB-C port

45 W Output

incl USB-C to C cable

Black

DLP5321NB



Wall charger with USB-A and C port

Maximum 45 W output

Charge your latest devices from this USB-A and USB-C port to optimise the charging power and minimise the charging time. Maximum 45 W output. Include USB-C to C braided 1 metre charging cable.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- 50% charge in 30 minutes
- Wall charger with GaN technology
- USB-A with QC fast charging

Top Performance

- USB-C port with Power Delivery support

Highlights

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

USB-C port with PD

USB-C is the latest charging connector standard, which is now adopted by mobile devices such as mobile phones, cameras and tablets. PD (Power delivery) is the USB standard for power delivery for more power and fast charging.

50% charge in 30 min

Fast charging - charge your mobile phone from 0 to 50% in 30 minutes time.

Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. These compact chargers can provide more power with faster charging times, so they are capable of delivering power to modern laptops with USB-C connection.

USB-A with QC fast charging

Quick Charge (QC) fast-charging technology delivers faster charging by increasing voltage and current. It uses the Quick Charge protocol to optimise charging speeds for compatible devices, reducing charge times.

Specifications

Design and finishing

Colour(s): Black

Materials: PC 94V0 Fireproof

Outer Carton

GTIN: 14895229162904

Inner Carton

GTIN: 24895229162901

Power

Adapter type: EU

Power input: 100-240 V~ 2.1 A 50-60 Hz;

Output: USB C Output: PD 45 W Max USB A Output: QC 18 W Max USB C + USB-A: 35 W + 10 W Max

Packaging dimensions

Number of products included: 1

EAN: 4895229162907

Product dimensions

Height: 3.25 cm

Width: 4.2 cm

Depth: 4.9 cm

