

PHILIPS

Bluetooth party speaker

80 W max (40 W RMS), Bass+

Mic and guitar inputs

Beat-synced party lights

Bluetooth® Auracast™ and TWS

TAX4000



Tight bass. Powerful sound.

Get the party started right with the portable party speaker that knows how to drop a great bassline! Bass+ tech brings you deep distortion-free bass at any volume. Beat-synced lights, mic and guitar inputs and echo effects bring the fun.

Portable party speaker. Deep, controlled bass.

- Feel that bass with 40 W RMS of powerful sound and Bass+
- 2 x 8" woofers, 2 x 2" tweeters
- Cue the tunes! Bluetooth®, AUX-in and USB playback
- TWS and Auracast™ for multi-speaker setups

LED lightshow and karaoke effects

- Mic and guitar inputs, plus echo effects
- Beat-synced lightshow. Rainbow LEDs pulse to the music
- 13 different lighting modes let you set the perfect vibe

Rock up ready to party

- Easy control via speaker panel or our companion app
- Built-in carry handle, AC powered
- Dimensions/weight: (H x W x D) 73.18 x 32 x 32 cm, 8.5 kg

Highlights

80 W max (40 W RMS), Bass+

Love a good bassline? With two 8" woofers and our exclusive Bass+ technology, the bass on this party speaker will sound deep, rich and precise—even if you're listening at lower volumes while chilling out at the end of the night. You get 80 W max (40 W RMS) of powerful sound, and two 2" tweeters mean vocals don't just sing, they soar.

Bluetooth® 5.4

Stream your playlists, plug in a USB drive or go ahead and hook up your DJ decks or CD player via audio-in. If you're streaming tunes, Bluetooth® 5.4 brings you a faster, steadier connection for better sound quality that won't dip. It also gives you a wider range so you can control those playlists from practically anywhere in the party.

TWS and Auracast™ compatible

Want more? For a wider soundstage, you can pair it with another TAX4000 speaker via True Wireless Stereo (TWS). For bigger events or the

ultimate house party, you can broadcast the tunes to as many Auracast™-compatible speakers as you could ever need! Send the beats around the house or create a wall of sound in one room.

Mic and guitar inputs

There's nothing like a karaoke session or impromptu live performance for bringing everyone together. This party speaker comes equipped with a mic input and a 6.3 mm guitar input: you can control the mic and guitar volume and add echo effects using physical controls on the speaker panel or our companion app.

Beat-synced party lights

When the tunes are pumping, a rainbow of colourful RGB LED lights shimmer and pulse on the surface of the speaker's twin woofers. With 13 light modes to choose from, you get to set the perfect vibe: simply press the light button on the speaker panel or use our companion app to get the lightshow started.

Easy control

Philips Entertainment



You can take control of the volume, lights and karaoke effects via the speaker panel—or use the Philips Entertainment app, which also lets you fine-tune bass and treble frequencies. Want to keep the neighbours happy? You can turn Bass+ off and scale back the bass via our app or the Bass+ button on the speaker.

Portable and AC powered

Rock up ready to party! The built-in carry handle offers a comfortable grip, making it easy to carry this party speaker, and it plugs straight into an AC socket for endless power—and dancing.

Specifications

Sound

Output power (RMS): 40 W
Sound enhancement: Bass+, Karaoke
Frequency response: 20 Hz - 20 kHz, ±3 dB
Output power (MAX): 80 W
Total harmonic distortion: 10%

Loudspeakers

Driver configuration: 2-way
Number of sound channels: 1
Number of tweeters: 2
Number of woofers: 2
Tweeter diameter: 2"
Woofer diameter: 8"

Connectivity

Bluetooth version: 5.4
Bluetooth profiles: A2DP, AVRCP, Streaming
Format: SBC
Bluetooth range: 10 M (free space)
USB: Type-A (playback)
Audio in: 1 x 3.5 mm
Mic in: 1 x (6.3 mm w/ vol control)

Guitar input: 1 x (6.3 mm w/ vol control)
Multiple speaker connection
Multiple speaker scenario: Stereo, Broadcasting
Multiple speaker technology: TWS, Auracast
Smart Home: None

Supported Audio Formats

Bluetooth: SBC
USB: MP3

Convenience

Karaoke: MIC volume, echo control
Volume control: Rotary
Light Effect: Yes, 13 light effects
Guitar control

Compatibility

Smartphone/tablet APP control

Power

Power supply: 100-240 VAC, 50/60 Hz

Packaging dimensions

Height: 82.8 cm
Packaging type: Box
Type of shelf placement: Standing
Width: 38.2 cm
Depth: 38.2 cm
Number of products included: 1
Gross weight: 10.6 kg
Net weight: 8.605 kg
Tare weight: 1.995 kg

Product dimensions

Height: 73.18 cm
Width: 32 cm
Depth: 32 cm
Weight: 8.5 kg

Accessories

Included accessories: AC Power Cord, Quick start guide, Warranty certificate, Safety warranty sheet



* The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The Auracast™ word mark and logos are trademarks owned by Bluetooth SIG, Inc.
* AC plug and quantity varies by region.
* Music play time depends on the volume level and audio content.