

PHILIPS

Penlight

Xperion 3000

100 lm main beam

50 lm Spotlight

Battery life: 4 h (Spot: 6 h)

LUMX30PENX1



Quality light to get the job done

Portable LED inspection tool

Compact and ergonomic, our Philips Xperion 3000 Penlight is an everyday companion, ideal for quick inspection jobs. Featuring a natural white light, it illuminates what's in front of you and fits easily into narrow spaces.

Dual-mode, natural white LED light

- Bright, eye-friendly light suitable for daily use
- Long running time in different light modes

Handy and easy to operate

- Battery-status indicator

Versatile for hands-free use

- Smart rotatable clip, strong magnets and ergonomic body

Highlights

Bright, comfortable work light

Whether you're in your garage, completing some DIY or trying to fix an appliance, it's always handy to have a small lamp tucked into your pocket. With its dual light modes, the Philips Xperion 3000 Penlight lights up what you're working on, so you can see the details you need to get the job done quickly.

Light modes for multiple needs

The Philips Xperion 3000 Penlight is designed to be ready for action. A single charge provides enough energy for all the daily inspection tasks: up to 4 hours in Eco mode, 2 hours in Boost mode and 3.5 hours with the torch beam. Powered by a powerful Li-ion battery, the Philips Xperion 3000 Penlight can be fully charged within 2 hours via USB-C, ensuring maximum usage of its bright LED light.

Battery-status indicator

See when the battery needs charging. The Philips Xperion 3000 Penlight features a battery-status indicator showing how long the work lamp can function before the battery runs down entirely. Never run out of power again in the middle of a job.

Enables hands-free working

The ergonomically shaped body of the Philips Xperion 3000 Penlight allows you to hold this work light securely. If you need both hands free for work, position the light using its two strong magnets, one on the rotatable clip and the other on the bottom of the lamp. The power button is located on the back to ensure that the light does not shine directly into your eyes when you turn it on.

Specifications

Marketing specifications

Expected benefits: Portable LED inspection tool

Product description

Hook: Standard clip

Impact protection rating (IK): IK06

Ingress protection rating (IP): IP20

Magnet: 1 magnet

Materials and finishing: Robust ABS

Operating temperature: 0°C to 40°C

Pointing light

Range: Xperion 3000

Resistant to: grease, oil, workshop solvents

Technology: LED

UV leak detector: No

Light characteristics

Colour temperature: 6000 K

LED lifetime: 10,000 hour(s)

Light output (pointer): 50 lumens

Beam angle: 80°

Light output: 100 lumens

Electrical characteristics

Wattage: 1.4 W

Voltage: 3.7 V

Battery capacity: 800 mAh

Battery run time (boost): Up to 4 hours

Battery run time (eco): Up to 6 hours (Spot Light)

Battery type: Li-ion battery

Plug type: Plug not included

Charging cable type: USB-C cable

Battery charging time: Up to 2.2 hours

Power Source: Li-ion battery

Ordering information

Order entry: X30PENX1

Ordering code: 02488631

Packaging Data

EAN1: 8719018024886

EAN3: 8719018024893

Packed product information

Length: 18 cm

Width: 5,4 cm

Height: 4 cm

Pack Quantity / MOQ: 6

Weight with batteries: 55 g

Cable length: 100 cm USB-C cable

Outer pack information

Length: 19,5 cm

Width: 14 cm

Height: 13 cm

Gross weight per piece: 0,847 g

