

PHILIPS

Flood

Xperion 3000

1000 lm Boost/500 lm Eco

300 lm Spotlight

Battery life: 3 h (Eco: 6 h)

180° pivoting handle

LUMX30FLX1



Quality light to get the job done

Portable LED projector light

Small but powerful, versatile yet robust, the Philips Xperion 3000 Flood LED projector light provides the bright white light you need to illuminate large dark areas. Enjoy up to six hours of continuous use before charging the battery.

Bright, comfortable work light

- Light up your whole work area

Sturdy lamp for daily use

- Shock resistance proven in drop tests
- Water resistant against splashes

Versatile for hands-free use

- Rotating handle for hands-free use
- Magnetic mounting accessory for hands-free lighting

Handy and easy to operate

- Recharge other devices with the useful USB port
- Rechargeable battery lasts up to 6 hours
- Indicator shows how long the battery will last

Highlights

Bright, comfortable work light

Whether you need to light up a work site, temporarily replace a wall lamp or illuminate outdoor activities, the Philips Xperion 3000 Flood is perfect for lighting up large dark areas. Delivering 1000 lumens (10 W), its homogeneous bright light produces an extra-wide beam. If you need less light and more battery life, you can switch to the 500 lumen (5 W) Eco mode.

Shock resistant

We've made our Philips Xperion 3000 Flood tough enough for use both indoors and outside. Built to last, this lamp has been subjected to 1.5 metre drop tests and can easily survive occasional drops during use.

Water resistant

Whether you use our Philips Xperion 3000 Flood indoors or outdoors, the lamp is designed to survive in tough conditions. Resistant to water, it will continue to work when splashed, such as during light rain.

Versatile rotating handle

Sometimes you need hands-free lighting so you can focus on your task. The 180° rotating handle on the back of our Philips Xperion 3000 Flood allows you to position the projector as needed. You can also use the handle as a hook to hang

the lamp or as a support to stand it up. This versatility enables you to direct the light just where you need it.

Useful USB charging port

The Philips Xperion 3000 Flood can also be used as a power bank to charge other devices, such as your smartphone. Plug your device into the USB port on the back of the lamp, and it will begin charging.

Magnetic mounting accessory

The Philips Xperion 3000 Flood also comes with a magnetic mounting accessory. Attach it to the handle to mount your projector onto any metal surface. Perfect for use in a garage or other work environments.

Up to 6 hours of battery life

Once fully charged, your Philips Xperion 3000 Flood delivers bright white light (1000 lumens/10 W) for up to three hours in Boost mode. If you need longer battery life, switch to Eco mode (500 lumens) and enjoy up to six hours of continuous light.

Battery-life indicator

No more worries about your light dying just when you need it most. On the back of the Philips Xperion 3000 Flood is a battery-life indicator which tells you exactly how long you've got before needing to recharge the battery.

Specifications

Marketing specifications

Product highlight: Dual lights: flood + spotlight

Expected benefits: Portable LED projector light

Product description

Impact protection rating (IK): IK08

Ingress protection rating (IP): IP65

Magnet: Magnetic handle

Materials and finishing: Nylon+ rubber

Operating temperature: 0°C to 40°C

Orientable light: 180° pivoting handle

Pointing light

Range: Xperion 3000

Resistant to: grease, oil, workshop solvents

Technology: LED

UV leak detector: No

Hook: 180° rotatable

Light characteristics

Colour temperature: 6000 K

LED lifetime: 30000 hour(s)

Light output (pointer): 300 lumens

Beam angle: 110°

Light output: 1000 lumens

Light output (eco): 500 lumens

Beam angle (pointer): 30°

Electrical characteristics

Wattage: 10 W + 3 W Spot W

Voltage: 3.7 V

Battery capacity: 4400 mAh

Battery run time (boost): Up to 3 hours

Battery run time (eco): Up to 6 hours

Battery type: Li-ion battery

Plug type: Plug not included

Charging cable type: USB-C cable

Battery charging time: Up to 5.5 hours

Power Source: Li-ion battery

Ordering information

Order entry: X30FLX1

Ordering code: 02504331

Packaging Data

EAN1: 8719018025043

EAN3: 8719018025050

Packed product information

Length: 10,8 cm

Width: 4,5 cm

Height: 13 cm

Pack Quantity / MOQ: 1

Weight with batteries: 235 g

Cable length: 100 cm USB-C cable

Outer pack information

Length: 28 cm

Width: 12,8 cm

Height: 17,6 cm

Gross weight per piece: 1,81 g

