

PHILIPS

Wall charger

USB-A and USB-C port

45 W Output

Black

DLP4345CB



Wall charger with USB-A and C port

Maximum 45 W output

Charge your latest devices from this USB-A and USB-C port to optimise the charging power and minimise the charging time. Maximum 45 W output.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- 50% charge in 30 minutes
- Wall charger with GaN technology

Top Performance

- USB-C port with Power Delivery support

Highlights

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

USB-C port with PD

USB-C is the latest charging connector standard, which is now adopted by mobile devices such as mobile phones, cameras and tablets. PD (Power delivery) is the USB standard for power delivery for more power and fast charging.

50% charge in 30 min

Fast charging - charge your mobile phone from 0 to 50% in 30 minutes time.

Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. These compact chargers can provide more power with faster charging times, so they are capable of delivering power to modern laptops with USB-C connection.

Specifications

Design and finishing

Colour(s): Black

Materials: PC, ABS

Outer Carton

GTIN: 14895229162911

Inner Carton

GTIN: 24895229162918

Compatibility

Compatible with: most devices with a USB cable

Power

Adapter type: EU

Power input: 100-240 V 50/60 Hz 1.5 A

Output: 45 W Max USB-C output: DC 5 V/3 A, 9 V/3 A 12 V/3 A, 15 V/3 A, 20 V/2.25 A USB-A output: DC 5 V/3 A, 9V/2 A, 12 V/1.5 A USB-C+ USB-A output: 30 W+12 W max

Packaging dimensions

Number of products included: 1

EAN: 4895229162914

Product dimensions

Height: 7.36 cm

Width: 4.1 cm

Depth: 3.1 cm

