

PHILIPS

Surge protector

6 outlets

5 USB charging ports

900J

30 W GaN

SPN7063WA



Protect and Charge your electronics

USB charging and surge protection.

Featuring 6 grounded French sockets. Integrated 5 USB 30 W GaN charging for mobile devices. Designed to protect your equipment from electrical surges. Automatically shuts down power to your system to protect against subsequent surges.

Safety protection

- Double pole switch

Built-in convenience

- 6 outlets
- 2 m power cord
- 4 x Type A ports, Max 20 W output

USB Charging Power

- Wall charger with GaN technology
- USB-C PD 30 W charging port.

Pure Protection

- Power Blocker
- 900 joules of surge protection
- €100.000 connected equipment limited warranty.

Highlights

6 outlets

Converts one outlet into six outlets, allowing you to plug in multiple devices from one single AC outlet.

4 x Type A ports

4 x Type A ports, Max 20 W output

900 joules of surge protect

Protect your valuable electronic equipment from random voltage spikes that might be caused by lightning, motors or power generators etc.

Double pole switch

Switches both the live and neutral to ensure safe isolation of the load circuit.

2 m power cord

Provides power to the unit, which can be 2 m from the AC outlet.

€100.000 Limited warranty

To protect your connected equipment within the product warranty period. Limited warranty amounts to €100.000.

Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. These compact chargers can provide more power with faster charging times, so they are capable of delivering power to modern laptops with USB-C connection.

USB-C PD 30 W charging port.

Equipped with USB-C (Power Delivery) PD 30 W fast charging port.

Specifications

Outer Carton

GTIN: 14895229151755

Inner Carton

GTIN: 24895229151752

Packaging dimensions

Number of products included: 1

EAN: 4895229151758

Product dimensions

Cable length: 200 cm

