

# PHILIPS

Smart lever door lock

6000 series

Intuitive fingerprinting

Mute by "0" key

Low battery alarm

With door backset 60 mm

DDL609LKLBO



## A new trip to smart life

One touch to unlock swiftly

DDL609-5HS realizes an easy one-touch door-opening experience by integrating a semiconductor fingerprint sensor and the lever into one. Besides, dual verification, hidden PIN code, multiple alerts, etc. bring you a safe and easy new life.

### Easy life doesn't stop there

- Say goodbye to the key-only era
- Unlock swiftly with one grip

### Upgraded smart chip enhances home security

- Protect home security at all time
- Leave a quiet place for the family

# Highlights

## Various ways of unlocking

Fingerprints, PIN codes, key tags, and mechanical keys are available unlocking methods, which can meet the need of different users, and are applied for the whole family.

## Intuitive fingerprinting

Adopted a semiconductor fingerprint sensor, the recognition speed is less than or equal to 0.5 s\*. When holding the handle, the finger can naturally fall on the fingerprint reader, and the door can be opened with one grip, giving you a convenient and fast door-opening experience.

## Multiple alerts

DDL609-5HS is equipped with the low battery alert, trial-and-error alert, system locking alert and other features to enhance the home security and instantly safeguard you and your family.

## Mute by "0" key

The "0" key is used both as a digit button and a mute button, press and hold the "0" key for 3 seconds can enable the mute mode. Without disturbing your family at night, the thoughtful design allows you to get back home quietly. After enabling the mute mode, press the "0" key again for 3 seconds to resume the voice mode, which is simple to operate.

# Specifications

## Design & Appearance

**Color:** Obsidian black

**Handle:** Lever handle

**Main Material:** Aluminium alloy

**Surface Processing:** Baked paint finish

## Access Solution

**Fingerprint**

**Password/PIN Code**

**Card/Key Tag**

**Mechanical Key**

## Lock Capacity

**Fingerprint:** Up to 20

**Card/Key Tag:** Up to 100

**Master PIN Code:** 1

**User PIN Code:** Up to 20

## Power Specification

**Power Supply:** 4 AA batteries

**Battery Type:** Alkaline Batteries

**Time of Use:** 10 months\*

**Maximum Batteries Capacity:** 8 batteries

**Emergency Power Supply:** 5V power bank

## Easy Operation

**Voice Guide:** Real voice navigation

## Mode

**System Setup Mode:** Dual verification mode, General mode

## Installation

**Door Thickness:** 30-60 mm, 60-90 mm, Other range\*

**Door Opening Direction:** Right inward opening, Right outward opening, Left inward opening, Left outward opening

**Door Type:** Wooden door, Security door

**Mortise backset:** 60mm



\* 0.5 s: data source from internal test report.

\* 30-90 mm: this product applied to door thickness of 30-90 mm (without considering the influence of off-center structure), the attached installation kit is used for door thickness of 30-60 mm, other accessories can be matched according to the door thickness, please consult the official store dealers.

\* 10 months: this is internal test data; actual battery life may vary with usage frequency.

\* Other range: the included installation kit is suitable for doors with the mentioned thickness. For doors outside this range, please contact authorized consumer care centers or designated offline dealers.