

PHILIPS

Home Projector

NeoPix 444

Up to 100" screen size

LED

500 ANSI lumens

360° rotating stand

NPX444



A stylish projector adapted to you

Experience powerful visuals in a compact and silent design with the NeoPix 444 projector. Delivering True Full HD 1080p resolution and 500 ANSI Lumens, this compact projector ensures bright, vibrant images in any room.

Resolution and technology

- Full HD 1080p
- LED light source

Unlimited screening options

- 360 degree rotative stand
- Up to 100" screen size

Adjustment and sound

- Auto image adjustment
- Stereo speakers

Highlights

Auto image adjustment

Auto Keystone and Auto Focus ensure optimal image alignment and clarity, delivering an enhanced viewing experience.

Stereo speakers

Immerse yourself in outstanding sound quality with the audio system, featuring two speakers for a truly exceptional audio experience. Need a bigger sound? The 3.5 mm jack output is there to connect your earphones or external speakers.

Full HD 1080p

Bring your entertainment to life with True Full HD 1080p — enjoy razor-sharp images, deep contrast and crystal-clear text for an unforgettable viewing experience.

360 degree rotative stand

Break free from traditional viewing with its innovative 360 degree rotating stand. This feature invites you to redefine the boundaries of your entertainment.

Up to 100" screen size

Enjoy your favourite films, series and more on a stunning projection of up to 100 inches — delivering crisp visuals and rich detail for a truly immersive viewing experience.

LED light source

The high-quality LED light system delivers rich, vivid colours that last up to 30,000 hours. With an average use of 4 hours per day, this projector will last for up to 20 years.

Specifications

Technology

Display technology: LCD

Light source: LED

Brightness: up to 500 lumens*

Contrast ratio: 1000:1

Resolution: 1920 x 1080 pixels

Throw ratio: 1.25:1

Focus adjustment: Auto

Integrated media player

Keystone correction: Auto

LED lifetime: Up to 30,000 h

Projection image size: up to 255 cm (100")

Recommended usage: 100" max in dark room

Connection

HDMI: x 1

USB: x 1

Audio out: 3.5 mm jack

DC-IN

Sound

Stereo Speaker: 2 x 5 W

Dimensions

Weight: 2.48 kg

unpacked (W x D x H): 195 x 219 x 194 mm



* Colour brightness (colour light output) and white brightness (white light output) will vary depending on projector settings. Colour light output measured in accordance with IDMS 15.4; white light output measured in accordance with ISO 21118.

* The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.