

PHILIPS

Home Projector

NeoPix 250 Smart

True Full HD 1080p

180 degree rotative stand

Wireless screen mirroring

Smart with Apps

NPX250



Big-Screen Brilliance, Anywhere You Go!

The Philips NeoPix 250 Smart is designed to redefine entertainment, featuring a 180 degree rotating stand that lets you project on any flat surface effortlessly.

Functions and content

- Google TV streaming device included
- Advanced Picture Correction

A wireless environment

- Wi-Fi screen mirroring
- Wireless Sound

Brilliant Image

- True Full HD 1080p
- Advanced LED Light Source

Highlights

Wi-Fi screen mirroring

Connect your mobile devices wirelessly to mirror and share your local content on tablets, smartphones or even computers. Videos on your phone? No worries just send it through Wi-Fi! (IOS, Android, Mac and PC).

Google TV streaming device included

Google TV brings together all your favourite streaming apps and personalised recommendations in one intuitive platform. With a user-friendly interface, Google TV curates shows, movies and videos based on your viewing habits, suggesting options from services like Netflix, Hulu, Disney+ and more, so you can discover new favourites without endless scrolling.

Wireless Sound

Do you have a wireless speaker, mouse, keyboard or other remote controls? Not to worry, thanks to its Bluetooth functionality, you can easily connect to any of these accessories.

True Full HD 1080p

Watch films and more in Native Full HD 1080p high-definition sharpness, full of the fine details that can be lost at lower resolutions. The picture remains lifelike and text is crystal-clear when displayed on a wall, ceiling... and more!

Advanced Picture Correction

Auto vertical keystones and 4 corner correction automatically help eliminate crooked, distorted images for a perfectly proportioned picture, even if the device is not straight in front of the wall. The auto-focus technology and digital zoom allow you to fine-tune pictures to your needs and place your projector at any distance.

Advanced LED Light Source

The high-quality LED light system delivers rich, vivid colours and lasts up to 30,000 hours. With an average use of 4 hours per day, it will last for 20 years! Energy consumption is also much lower than a regular lamp projector, meaning that you get a bigger screen and a fully immersive cinema experience, all from an eco-friendly device!

Specifications

Technology

Display technology: LCD

Light source: LED

Brightness: up to 250 lumens*

Contrast ratio: 3000:1

Resolution: 1920 x 1080 pixels

Throw ratio: 1.31:1

Aspect ratio: 16:9

Focus adjustment: Auto

Keystone correction: horizontal and vertical

LED lifetime: Up to 30,000 h

Projection image size: up to 200 cm (80")

Resolution supported: 4K

Recommended usage: 80" in dark room

Connection

Wi-Fi: Dualband 2.4 GHz and 5 GHz

Bluetooth: Bluetooth 5.0

HDMI: x 1

USB: x 1

Audio out: 3.5 mm jack

DC-IN

Sound

Stereo Speaker: 2 x 3 W

Bluetooth speaker connection

Dimensions

Weight: 2.5 kg

unpacked (W x D x H): 239 x 140.7 x 187.9 mm

