

Philips Unite LED 6000 All In One



Unite LED 6000
Series All In One

LED Solutions

135"



135HDL6015IA

Philips Unite LED 6015 All in One

Enhanced mobility, safety, and energy efficiency

Maximise ROI with this ultimately flexible dvLED display. Mechanised to raise and lower, as well as folding to fit through doorways, this All In One display can be moved to suit, with the option for a flight case for easy movement, too.

Smart foldable display construction

- Designed for easier transportation and space saving storage
- Smooth, safe height adjustment. Built-in cabling and audio

Emergency stop function

- Immediate stop capability for motorised height adjustments
- Prevents injuries during lifting or lowering operations

Crystal-clear COB LED with nano coating

- 1.5mm pixel pitch for ultra-sharp visuals

Unique low power standby mode

- Using less than 0.5W in standby mode for best energy savings

Integrated Android SoC – Philips Wave ready

- Control with remote or via remote device management

Highlights

Crystal clear visuals with COB LED technology

Experience superior picture quality with COB LED and a fine 1.5mm pixel pitch. Vibrant colours, deep blacks, and uniform brightness create an immersive visual experience, ideal for professional meeting rooms, auditoriums, and corporate settings.

Ultra-efficient standby mode

Maximise energy savings without compromising on quality or reliability. The Philips Unite LED 6015 All In One includes our ultra-low standby mode. Consuming less than 0.5 Watts, this unique feature helps to lower operational costs and support sustainability goals. Instant power-up via remote control ensures minimal downtime when you are ready to present.

Foldable design for easy handling

Designed with a smart, foldable structure, setup, transportation, and storage are more convenient than ever. Seamless when set up, the screen folds

neatly for compact transportation, protecting the display during moves and allowing easier access through standard doors and in elevators.

Motorised height adjustment

Designed for professional flexibility and enhanced mobility, the Philips Unite LED 6015 All In One includes a motorised trolley enabling smooth and safe electric lifting. Adjust the display height easily with just the push of a button, ensuring perfect viewing in any setting. Ideal for dynamic spaces, this height adjusting feature also allows for simple transportation through doors between rooms, and in elevators between floors.

Philips Wave ready

Philips Wave – the evolutionary remote device management platform – puts you fully in control. Simplified installation and setup, monitoring and

control, firmware upgrades, managing playlists, and setting power schedules. Saving time, energy, and environmental impact.

Emergency stop and anti-pinch

Safety comes first and with the motorised height adjustment on the Philips Unite LED 6015 All In One with special features including an emergency stop button and anti-pinch protection are integrated as standard. The emergency stop ensures quick response during lifting, while the anti-pinch function detects obstructions and halts movement to prevent injury or equipment damage.

Integrated Android SoC

Incorporating the world-renowned reliability of Android 11. Optimised for native Android apps, the integrated System on Chip (SoC) enables you to install web apps and software directly onto the display, eliminating the need for an external media player.

Specifications

Picture/Display

Aspect ratio: 16:9
Brightness uniformity: $\geq 95\%$
Color temperature adjust range: 6500 ± 500 K
Contrast ratio (typical): 5000:1
Viewing angle (horizontal): 160° degree
Viewing angle (vertical): 160° degree
Frame frequency (Hz): 50/60
Refresh rate(Hz): 3840
Brightness Max: 500 cd/m²
Electric Lifting
Screen Folding
Anti-Pinch
Emergency stop
Resolution: 1920 x 1080

Connectivity

Video input: DVI-I (x 1), DisplayPort 1.4 (x1),
HDMI 2.0 (x2), USB 3.0 (x2)
Audio input: 3.5 mm mini jack (x1)
Audio out: 3.5mm headphone/line-out jack
Video output: DisplayPort 1.4 (x1)
External control: RS232C (in/out) 2.5 mm jack,
RJ45, IR (in/out) 3.5 mm jack

Power

Mains power: AC 100~240
Max Power consumption (W): 1.650 W
Typical power cons. (W): 600

Operating conditions

Temperature range (operation): -20~45 °C
Temperature range (storage): -20~50 °C
Humidity range (operation)[RH]: 10~80%
Humidity range (storage) [RH]: 10~85%

Module

LED type: COB
Pixel constitution: 1R1G1B_Flip Chip
LED lifetime(Hrs): 100.000
Module resolution (WxH pixels): 96x108
Pixel pitch (mm): 1.5625
Module size (WxH in mm): 150 x 168.75

Accessories

Included accessories: Remote Control & AAA
Batteries, Quick start guide, Speaker set
Wifi module: CRD22 Wifi & Bluetooth USB
module, incl 2 antennas

Miscellaneous

Warranty: 3 Years
Regulatory approvals: CE, FCC SDOC, Part 15,
Class A, CB 62368, RoHS

Packaging Data

Packing Options: Wooden crate
Product Dimension: 3000x1687.5 mm
Dimension of packaging: 2250W x 1100D x
2100H mm
Dimension when fully extended: H2475.5 x
W3010 x D850 mm
Dimension when folded: H1875.5 x W1820 x
D850 mm
Gross weight: 555 kg
Net weight: 278 kg

Feature

Included Features: File management, Chromium,
Browser, Media Player, Settings, Teamviewer, PDF
Player, Interact

