



LED Display

Signage Solutions

31"

Direct View LED



31BDL7524L

Unleash your imagination even more

LED Display for every form and shape

No limits. No boundaries. Philips L-Line 7000 series is an LED signage solution for endless possibilities in shape and size. Seamless linking and multiple size options enable truly unique displays of any dimension for perfect results.

Next level performance

- Dynamic Panel Connect
- Factory calibrated
- Philips Active Health Monitoring
- High brightness LED panel

Endless possibilities

- Available in 3 dimensions
- Dynamic Power Saving
- Optional bevelled corners allow curved displays
- Seamless linking for perfect imagery

Ready for impact

- Conformal coating and ingress protection
- Forms any shape, L-shape corner, or curvature
- Fire retardant design

Highlights

Optional easy mount brackets

Patented easy-mount brackets make installation even faster. These optional items are available for flat LED mounting, convex curved (177.5/175/172.5 degree), and L-shape 90 degree corners.

Ingress protection

Dust, dirt, fungus and moisture resistant conformal coating protects this product and enables easier maintenance. IP30 rated and certified against ingress for reduced chance of short circuit from dust and corrosion.

Dynamic Panel Connect

Mix and match each of the Philips L-Line 7000 LED panel sizes to form a single display of any shape and dimension. Dynamic flexible alignment pins ensure a perfect fit in any circumstance - resulting in a smooth, seamless display surface. For added convenience and efficiency, each LED panel features openings on each side to allow for versatile wired connection between the LED panels and any external input connection. Openings on the top and bottom of the LED panel can be popped out in case access is only available from the top or bottom of the panel.

Dynamic Power Saving

Philips Professional LED Displays use high-performance LEDs, which are tested thoroughly, energy efficient and cost effective. Furthermore, enhanced technology allows the display to dynamically save on power consumption.

Factory calibrated

Every Philips L-Line LED panel is calibrated in our factory under perfect circumstances. That means there's no need for further calibration on location, resulting in quicker installations. Calibration and configuration files are available to ensure fast maintenance.

Fire retardant design

Fire retardant design slows down the spread of flames in the event of fire, and help protect the structural integrity of the LED panel in case of fire. Tested and certified with Fire Safety Certifications.

L-shape corner, or curvature

The Philips L-Line 7000 series LED panels come with a height of 25 cm and are available in 50 cm, 75 cm and 100 cm widths. These displays are ready to be installed in any landscape format with no limitations to size. Also available with bevelled corners to form curved designs in both convex and concave formats.

High brightness LED panel

Visualize all kinds of content in any setting. Make a big impact with crisp and clear messaging in bright locations, such as storefront windows or

places subject to direct sunlight. This high bright LED panel is perfect for attracting attention in large, busy areas that are subject to high ambient light.

Optional bevelled corners

Create bezel-free displays of any shape, size or resolution. The modular design of Philips Professional LED panels means you can adapt to any space. Build vast, immersive installations or assemble intriguing patterns. Easily create displays that flow seamlessly around doorways and other openings. Even corners and curved displays become easy to create with the new Philips 7000 series.

Active Health Monitoring

Achieve perfection through precision. Active Health Monitoring makes maintenance fast, simple, and predictable by displaying the exact item of failure and location. Utilising this software that works in real-time both online and offline, replacing the relevant part becomes an efficient process, and a must for display owners with many geographical locations.

Perfect imagery

Your Philips Professional LED Display features built-in cable wiring to keep power and data cables tidy. Display panels are daisy-chained for both power and data, allowing you to minimise clutter and speed up installation.

Specifications

Picture/Display

Aspect ratio: 3:1
 Brightness uniformity: >=97%
 Brightness after calibration: 2750 nits
 Brightness before calibration: 3500 nits
 Calibration(brightness/color): Supported
 Color temperature adjust range: 4000~9500 K (by software)
 Color temperature default: 6500±500 K
 Contrast ratio (typical): 11000:1
 Viewing angle (horizontal): 160 degree degree
 Viewing angle (vertical): 155 degree degree
 Picture enhancement: Wide color gamut display
 Placement: Landscape
 Frame frequency (Hz): 50 & 60
 Refresh rate(Hz): 2100~3900 (14 bits: 3900Hz)
 Usage: Indoor

Convenience

Ease of installation: Guide pins, Light weight
 Power loop through: For 230V environments: 12 cabinets or less, for 110V environments: 6 cabinets or less, 10A max
 Signal control loop through: RJ45

Power

Input voltage: AC100~240V (50 & 60Hz)
 Black screen power cons. (W): <10
 Max. power cons. AC (W): <118.4
 Max. power cons. BC (W): <153.6
 Typical power cons. (W): <39.5

Operating conditions

Temperature range (operation): -20~45 °C
 Temperature range (storage): -20~50 °C
 Humidity range (operation)[RH]: 10~80%
 Humidity range (storage) [RH]: 10~85%

Cabinet

Cabinet area (m2): 0.1875
 Cabinet pixels (Dot): 32.448
 Cabinet resolution (W x H): 312x104
 Cabinet size (mm): 750x250x40
 Data connector: RJ45
 Power connector: 3 core socket (C14 in, C13 out)
 Receiving card quantity: 1 pcs
 Receiving card spec.: A5S plus
 Receiving card brand: NovaStar
 Weight (KG): 4.57
 Cabinet diagonal (inch): 31.1"
 Cabinet construction: Die-Casting Aluminum
 Side angle (degree): 45

Module

LED type: SMD 1515 Gold wire
 Pixel constitution: 1R1G1B
 LED lifetime(Hrs): 100,000 at half brightness
 Module resolution (WxH pixels): 104x104
 Pixel pitch (mm): 2.4
 Module size (WxH in mm): 249.9*249.9

Accessories

LAN cable (RJ45, CAT-5): 1 pcs
 Power cable: 2 pcs
 QSG: 1 pcs

Miscellaneous

Warranty: 2 years
 Regulatory approvals: EN55032, EN55035, EN61000-3-2, EN61000-3-3, IEC/UL60950, IEC/UL62368, IEC62471, RoHS, FCC SDOC, Part 15, Class A, EAC
 Fire retardancy certification: BS 476 Part7:1997, UL94
 Conformal coating: hub board, backside LED module

Packaging Data

Dimension of packaging (mm): 950x421x224
 Gross weight (KG): 9.36

