

# PHILIPS

## True wireless headphones

Small buds. Great value

Natural sound. Dynamic Bass

Pocket-sized charging case

Up to 24 hours of play time

TAT1500BG



## Get your music on

The best things in life are simple. Grab your headphones, take your tunes and head out! With great sound, dynamic bass and a pocket-sized charging case, these super-small and comfy true wireless earbuds are ready for your day—and night.

### **Great sound and clear call**

- Always hear your music. Noise Cancelling
- Great sound even at low volume with Dynamic Bass
- Clear calls. They'll hear what you're saying

### **Comfortable and convenient**

- Secure, comfortable in-ear fit
- IPX4 splash and sweat resistant
- Multipoint connection and touch controls

### **Ready for you**

- Always ready. Pocket-sized charging case and mono mode
- No worries. Up to 24 hours of play time with the case
- Quick charge for 15 minutes and get an extra hour
- Philips Headphones app personalises your audio experience

# Highlights

## Noise Cancelling

Noise cancelling quiets external noise, including wind, so you can focus on your tunes or calls. Want to hear more of what's going on around you? Tap an earbud to activate Awareness Mode.

## Great sound. Dynamic Bass

These true wireless earbuds sound great, and you won't need to turn up the volume to get the best out of their 8 mm drivers. Activate Dynamic Bass via the left earbud and you can enjoy the full power of your favourite basslines even if listening quietly.

## Clear calls

Your voice will come through clearly when you're on a call. One AI mic picks up the sound of your voice while a noise-reduction algorithm quiets some of the background noise from the world around you.

## Secure, comfortable in-ear fit

You get real comfort thanks to soft, interchangeable silicone ear-tip covers. The ear tips insert securely into your ear canal, creating a perfect seal that helps diminish external noise. Plus, the stalks make these earbuds easy to insert and remove.

## IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means that these earbuds are splash resistant so they don't mind a little rain! Wearing them during a quick workout or on a particularly hot day? They won't mind a little sweat either.

## Multipoint and touch controls

Touch controls on the earbud stalks keep things simple, and multipoint lets you connect to two Bluetooth devices (iOS or Android) at the same time.

## Pocket-sized charging case

Head out with the small charging case in your pocket and your earbuds will always be ready for you. They'll stay protected and keep charging when you're not using them, and mono mode means that you can use either earbud while the other one charges.

## 24 hours of play time with case

You get 6 hours of play time from a full charge and an extra 18 hours from the case with noise cancelling off. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

## Philips Headphones app

Download the free Philips Headphones app to fine-tune your sound profile. Choose from preset EQ modes or customise the EQ curve to match your favourite content, listening style and personal preferences.

# Specifications

## Sound

Acoustic system: Closed  
Frequency range: 20–20,000 Hz  
Impedance: 16 Ohm  
Maximum power input: 7 mW  
Sensitivity: 104 dB (1k Hz)  
Speaker diameter: 8 mm  
Driver type: Dynamic

## Connectivity

Bluetooth version: 6.0  
Bluetooth profiles: AVRCP, A2DP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC

## Outer Carton

Length: 22.60 cm  
Number of consumer packages: 6  
Width: 16.70 cm  
Height: 19.60 cm  
GTIN: 1 48 95229 17303 0

## Convenience

Water resistance: IPX4  
Mono mode for TWS  
Type of controls: Touch

## Power

Number of batteries: 3 pcs  
Music play time: 6 + 18 hour(s)  
Charging time: 2 hour(s)  
Fast charging time: 15 mins for an hour  
Battery type (Charging case): Lithium Polymer (built-in)  
Battery type (Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 9.1 g

## Packaging dimensions

Height: 21.2 cm  
Packaging type: Blister  
Type of shelf placement: Hanging  
Width: 18.2 cm  
Depth: 3.8 cm  
Number of products included: 1  
EAN: 48 95229 17303 3

## Accessories

Quick Start Guide  
Eartips: 3 pairs (S/M/L)  
Charging case  
Charging cable: USB-C cable, 200 mm

## Design

Colour: Beige  
Ear coupling material: Silicone  
Ear fitting: In-ear  
In-ear fitting type: Silicone ear-tip

## Telecommunication

Microphone for call: 1 mic

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Multi-Function touch  
Voice assistant support

## Dimensions

Earbud dimension (W x D x H):  
2.10 x 2.09 x 2.69 cm  
Charging case dimension (W x D x H):  
6.20 x 2.58 x 3.93 cm  
Total weight: 0.031 kg

