

PHILIPS

Smart video door
lock

1000 series

Remote video intercom

4-inch IPS display

Real-time Wi-Fi connection

Automatic locking

DDL111BEGBW



Wonderful life starts from a

With remote video intercom

Philips Alpha-VP-5HWS-H smart lock integrates door viewer, doorbell, and lock. Wi-Fi connectivity and a 2MP wide-angle camera let you see your doorstep anytime via app. Smart security, always visible.

Smart life "locked" with excellence

- Always know what's happening outside
- Make real-time communication everywhere
- See doorway activity clearly
- Clearer images even at night
- Instant pushed alert upon abnormal situation

Upgraded smart chip enhances home security

- Emergency unlocking made easy
- Prevent disclosure of the actual PIN code
- Instantly protect home security at all times

Easy life doesn't stop here

- Eliminate the hassle of manually locking
- The door opens when a hand is detected
- Say goodbye to the key-only era
- Leave a quiet place for the family

Highlights

Real-time Wi-Fi connection

The Philips Alpha-VP-5HWS-H stays online in real time via Wi-Fi. Once paired with the app*, you can view access history, send temporary PIN codes remotely, and watch live video at your door with a single tap.

Remote video intercom

When a visitor presses the doorbell, a notification is sent to your app instantly. Tap the notification to start two-way audio and connect with them. The video lock automatically records video whenever the doorbell rings, so you won't miss any visitor information—even when you're away.

4-inch IPS display

The indoor assembly features a 4-inch IPS display. Tap the display button to view visitors and the doorway; tap again to turn off the screen—making it convenient for children and the elderly. You can also adjust the screen brightness and sleep timeout via the app.

Wide-angle night vision

The Philips Alpha-VP-5HWS-H is equipped with a 144° wide-angle camera and two low-power infrared fill lights. It supports both daytime and night vision modes. In low-light conditions, the infrared lights automatically turn on, switching to night vision and recognizing facial features up to 1 meter from the lock.

PIR motion detection

Equipped with a PIR sensor, the Alpha-VP-5HWS-H uses an AI humanoid detection algorithm to identify unusual activity within 3 meters* of the front door. It instantly captures a photo or records a video, then pushes a notification to the app via an encrypted cloud server, allowing you to monitor all doorway activity and prevent security risks.

Quick-access thumbturn

The inside assembly features a thumbturn, allowing you to unlock the door with a simple twist—even during power outages or electronic malfunctions. Reliable safety when it matters most.

20-digit hidden PIN code

Alpha-VP-5HWS-H features 20-digit hidden PIN code technology. To prevent peeping, you can enter random digits before or after your actual PIN—up to a total of 20 digits—ensuring your access code stays secure.

Multiple alerting

Equipped with multiple alerts, such as anti-dismantling, system locking, low battery level, and abnormal bolt, the Philips Alpha-VP-5HWS-H ensures instant protection for your family and provides real-time reminders of the lock status, offering a sense of assurance and security.

Fully automatic mortise

The Philips Alpha-VP-5HWS-H features a fully automatic mortise, allowing you to push the door to unlock without any extra steps. The bolts automatically retract after successful verification via fingerprint or PIN code. If the door is left ajar, the system sends an alert to notify you of the lock status.

Indoor infrared sensor unlock

With both a touch sensor and an infrared sensor on the handle, the door unlocks effortlessly when the hand touches the sensor and the infrared sensor detects it.

Various ways of unlocking

Fingerprints, PIN codes, key tags, and mechanical keys are available unlocking methods, which can meet the need of different users, and are applicable for the whole family.

Mute by "0" key

The "0" key serves as both a digit and a mute button. Press and hold it for 2 seconds to activate mute mode. This thoughtful design lets you enter your home quietly at night without disturbing your family.

Specifications

Design & Appearance

Color: Obsidian black

Handle: Push-pull handle

Access Solution

Fingerprint

Password/PIN Code

Card/Key Tag

Mechanical Key

Power Specification

Battery Type: Li-polymer Battery

Time of Use: 3 months*

Easy Operation

Voice Guide: Real voice navigation

Installation

Door Thickness: 38-60 mm, 60-90 mm, 90-120 mm, Other range*

Door Opening Direction: Right inward opening, Left outward opening, Right outward opening, Left inward opening

Door Type: Wooden door, Copper door, Security door



* App: Philips Alpha-VP-5HWS-H works with Home Access App.

* 3 meters: the maximum PIR motion detection distance is 3 meters, which can be set to 1 meter, 2 meters and 3 meters via the mobile App.

* 3 months: this is internal test data; actual battery life may vary with usage frequency.

* Other range: the included installation kit is suitable for doors with the mentioned thickness. For doors outside this range, please contact authorized consumer care centers or designated offline dealers.

* The digital keypad shown in the product photos may differ from the actual display. Please refer to the digital keypad's appearance during actual use.