

PHILIPS

Over-ear headphones

Detailed, natural sound

Noise Canceling Pro

Up to 70 hours play time

Replaceable ear-cup cushions

TAH8000BK



Superb hi-res sound

Immerse in rich, detailed sound with the wireless over-ear headphones that were built for years of comfortable listening. Music sounds thrilling, call quality is crystal-clear, and adaptive noise cancellation lets you focus on what matters.

Over-ear wireless headphones. Hi-res sound.

- Thrilling sound. Hi-res streaming and wired listening
- Powerful 40 mm silk-coated drivers
- Immerse freely with Adaptive Noise Canceling
- 5-mic technology. Clearer calls, even in noisy locations
- Up to 70 hours play time (50 with noise canceling on)

Auracast™ connectivity. Replaceable components.

- Bluetooth® multipoint connectivity and Auracast™
- Designed for years of comfortable use
- Shockproof, dustproof hard-cover travel case included

Your companion for years to come

- A quick 10-minute charge provides 8 hours of playback
- Philips Headphones app. Personalize settings and controls
- Warm, detailed, natural. Philips sound signature
- RCS-certified recycled plastic. Responsible packaging

Highlights

Thrilling sound

Silk-coated 40 mm drivers give you detailed sound—and Dynamic Bass brings you full, rich bass even at low volumes. The LDAC and LC3 codecs are supported so you can get the most from hi-res streaming, and you can listen wired via USB-C. Plus, you can turn on Spatial Audio in our app for a more immersive listening experience.

Noise Canceling Pro

Adaptive noise cancellation quickly reacts to your surroundings to suppress external noise, including wind, in real time. If you want to hear what's going on around you, Awareness Mode lets outside sounds back in. Quick Awareness enhances voices, so you can have a conversation without removing your headphones.

5-mic technology

If you're on a call, dedicated mics and a noise-reduction algorithm combine to clearly pick up your voice and reduce background noise. Even if you're on a busy urban street on a very windy day—your voice will come through clearly, and the person you're speaking to won't be distracted by what's going on around you.

Up to 70 hours (with ANC off)

With noise canceling off, you get 70 hours play time from a full charge (with noise canceling on, you get 50 hours). For a quick boost, 10 minutes charging via USB-C gives you an extra 8 hours. Pairing is simple via our companion app, plus Android users can use Google Fast Pair and Windows users can use Microsoft Swift Pair.

Bluetooth® 5.4 and Auracast™

Bluetooth® 5.4 brings you a steadier connection for seamless, high-quality streaming, and multipoint connectivity lets you connect to two Bluetooth® devices at once. Support for Auracast™ means you can listen to public broadcasts: tune in to announcements at the airport or catch the commentary while you're in a sports bar.

Your daily companion

The wide, soft headband can be adjusted via a hidden slider for the perfect fit—and the soft memory-foam ear-cup cushions can be replaced when they reach the end of their life. The ear cups fold flat and inward for easy portability, or safe storage in a drawer.

Philips Headphones app

Our handy companion app lets you manage connected devices or turn adaptive noise cancellation off and adjust the levels yourself. You can also use the app to scan for Auracast™ broadcasts, control sound features like Dynamic Bass and Spatial Audio, create custom sound presets, get the latest firmware—and more!

Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, detailed sound with rich bass. Whatever you're listening to, you'll love what you hear.

Recycled materials

We use post-consumer recycled plastics in this product, and our packaging is plastic-free. Inserts are printed on recycled paper with soy-based ink, and the packaging itself is made from FSC-certified recycled cardboard.

Specifications

Sound

Acoustic system: Closed
Frequency range: 20 - 40,000 Hz
Impedance: 16 Ohm
Sensitivity: 112 dB (1K Hz, 126mV)
Speaker diameter: 40 mm
Maximum power input: 20 mW
Driver type: Silk coated
Hi-Res Audio

Connectivity

Bluetooth version: 5.4
Bluetooth profiles: A2DP, AVRCP, HFP
Maximum range: Up to 10 m
Multipoint connection
Supported codec: SBC, LDAC, LC3, AAC
Headphone socket: 3.5 mm

Outer Carton

Length: 28.80 cm
Number of consumer packagings: 3
Width: 22.70 cm
Gross weight: 1.9 kg
Height: 25.00 cm
GTIN: 1 08 40063 20734 6
Nett weight: 0.81 kg
Tare weight: 1.09 kg

Convenience

Philips Headphones app support
Google fast pair
Firmware updates possible
Type of controls: Button

Power

Number of batteries: 1 pcs
Charging time: 2 hour(s)
Music play time (ANC on): 50 hour(s)
Music play time (ANC off): 70 hour(s)
Fast charging time: 10 mins for 8 hrs
Battery weight (Total): 22 g
Battery capacity(Headphones): 1000 mAh
Battery type(Headphones): Lithium Polymer

Packaging dimensions

Height: 23 cm
Packaging type: Carton
Type of shelf placement: Hanging
Width: 21.2 cm
Depth: 9.1 cm
Number of products included: 1
Gross weight: 0.390 kg
Nett weight: 0.270 kg
Tare weight: 0.120 kg

Product dimensions

Height: 21.50 cm
Width: 19.00 cm
Depth: 9.00 cm
Weight: 0.260 kg

Accessories

Audio cable: 3.5-3.5mm stereo cable, L=1m
Quick Start Guide
Charging cable: USB-C cable, 200 mm

Design

Color: Black
Wearing style: Headband
Foldable design: Flat/In-ward
Ear coupling material: Memory foam
Ear fitting: Over-ear
Earcup type: Closed-back

Telecommunication

Microphone for call: 3 mics
Wind noise reduction

UPC

UPC: 8 40063 20734 9

ANC features

ANC technology: Hybrid, ANC Pro+
Awareness mode
Adaptive ANC
Microphone for ANC: 4 mic
ANC (Active Noise Canceling)

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant
Voice assistant activation: Press Voice Assistant button
Voice assistant support

