

# PHILIPS




Philips Unite LED  
6000 Panels

Signage Solutions

27"

Direct View LED



27HDL6400IR

## Philips Unite LED 6000 Series panels

Premium performance. Seamless integration.

The Philips Unite 6000 Series redefines professional LED performance. Purposefully engineered and expertly specified to bring ease of installation together with advanced features and stunning visual quality. Ideal for true business impact.

### **Precision calibration – colour accuracy**

- Multi-layer calibration for consistency across modules.
- Advanced colours, gradients, and greyscale.
- Outstanding picture quality with real depth.

### **Flexible configurations**

- Modular design adapts to any space or resolution need.

### **Ultra smooth picture motion**

- High refresh rates deliver flicker-free, fluid motion

### **Vivid brightness – up to 1000 nits**

- Enabling bolder visuals – even in lighter environments.

### **Brilliant COB LED + critical redundancy**

- 0.9 fine pixel pitch for ultra sharp visuals.
- Dual power and data for fail-safe performance.
- Ideal for control rooms and high visual dependency needs.

# Highlights

### **Brilliant Flip Chip COB LED for advanced quality**

Delivering advanced quality visuals with an ultra fine 0.7mm pixel pitch. Vibrant colours, deep blacks, and uniform brightness create an immersive visual experience, ideal for high impact professional settings. Cool common cathodes bring stability, reliability, and higher definition together with lower energy consumption for reduced cost of ownership.

### **Mission critical redundancy**

The 27HDL6500IR with 7HDL6578IM/00, and the 27HDL6400IR with 7HDL6493IM/00 Philips Unite LED 6000 Series options include built in power and data redundancy. Providing continuous operation even during component failure, these solutions are ideal for high stakes environments such as control rooms and broadcast studios, where uptime is non-negotiable.

### **Ultra smooth picture motion**

With refresh rates up to 7680 Hz, Philips Unite LED 6000 Series panels deliver flicker-free, seamless visuals. Ideal for playing fast-moving content, live feeds, and for mission critical applications where every frame counts.

### **Vivid brightness – up to 1000 nits**

Up to 1000 nits of brightness ensures vibrant, high contrast imagery even in areas with high ambient light. Ideal for well-lit spaces such as lobbies, shopping malls and retail spaces, or broadcast environments that demand visual impact.

### **Precision calibration – colour accuracy**

Factory and multi-layer calibration guarantee uniform brightness and colour accuracy across all modules. The result? Consistent image quality that maintains brand integrity and professional standards at any scale. Ideal for bringing revenue generating advertising on board. Multilayer greyscale calibration ensures flawless dark tone uniformity, vibrant colour accuracy, and ultra

smooth detail. Meanwhile, automatic recalibration keeps visuals perfect – ideal for premium LED installations.

### **Colour depth that stands out**

Higher colour depth enhances gradients, eliminates banding, and brings content to life with more detail and realism. Advanced greyscale brings greater texture quality to imagery while also supporting faster processing times. Ensuring premium performance for branding perfection, unrivalled presentations, and immersive displays.

### **Optimised for every environment**

Designed for flexibility, the advanced brightness control, calibration layers, and performance tuning features within the Philips Unite LED 6000 Series simplify integration and operation, adapting to lighting and content needs and delivering content without compromise. Front access makes servicing and maintenance easier, with each of the modules in a cabinet able to be removed easily, and direct access to power supply, hub board, and wiring.

# Specifications

## Picture/Display

Brightness (nits): 1000 nit  
 Brightness uniformity:  $\geq 95\%$   
 Calibration(brightness/color): Brightness  
 Color temperature adjust range: 4000~9500 (by software)  
 Color temperature default: 6500K $\pm$ 500 K  
 Contrast ratio: 5000:1  
 Bit-depth(bit):  $\geq 15$   
 Frame frequency (Hz): 50-60  
 Refresh rate(Hz): 7680 Hz  
 Colour uniformity:  $\pm 0.012C_x, C_y$   
 Colour coordinates: 0.313, 0.325 ( $\pm 0.012C_x, C_y$ )  
 Viewing angle (°) H/V: >160/160  
 Scan rate: 40

## Power

Input voltage: AC100~240V (50 & 60Hz)  
 BTU/M2: 301  
 Cabinet Max Power consumption (W): 90  
 Cabinet Typical Power consumption (W): 30  
 Power consumption/M2 (W): 444  
 Power supply unit: HWT-403V8-2S-SS

## Operating conditions

Temperature range (operation): -20 - 45 °C  
 Temperature range (storage): -20 - 50 °C  
 Humidity range (operation)[RH]: 10%-80%RH  
 Humidity range (storage) [RH]: 10%-85%RH  
 Working environment (indoor/outdoor): Indoor

## Cabinet

Cabinet area (m2): 0.2025  
 Cabinet resolution (W x H): 640 x 360 pixels  
 Data connector: RJ45  
 Power connector: C13/C14  
 Receiving card quantity: 2  
 Receiving card brand: Novastar  
 Weight (KG): 4Kg ( $\pm$ )  
 Cabinet construction: Die-Casting Aluminum  
 Cabinet Size (WxHxD in mm): 600x337.5x33.15  
 Cabinet size (inch): 27.1"  
 Receiving card type: A8s-Pro

## Module

LED type: COB  
 Pixel constitution: 1R1G1B\_Flip Chip  
 Pixel pitch (mm): 0.9375

Module size (WxH in mm): 150x168.75x2.0 mm  
 (tolerance: +0/-0.1)

LED Pole type: Common Cathode  
 LED Lifetime (Hrs, half brightness): 100,000  
 Conformal coating (UV-resistant): No  
 Flatness of LED module with back shell:  $\leq 0.25$ mm

Module Resolution (WxH in pixels): 160 x 180

Included: Black screen power saving, Flash memory, Dynamic power saving

## Miscellaneous

Warranty: 2 years  
 Regulatory approvals: FCC SDOC, Part 15, Class A, EN55032, EN55035, EN61000-3-2, EN61000-3-3, IEC/UL60950, IEC/UL62368, CE, RoHS

