

PHILIPS

True wireless headphones

Noise Canceling Pro

Small buds. Great value

Natural sound. Dynamic bass

Pocket-sized charging case

TAT2569DB



The essential everyday earphones

Upgrade your everyday essentials with the small true wireless earphones that fit like a dream and sound great too. You get up to 31 hours play time with the pocket-sized charging case and your calls will be clearer than ever.

True wireless earbuds. Great sound and clear call

- Great sound even at low volume with Dynamic Bass
- Always hear your music. Noise Canceling
- 10 mm driver and dynamic bass-boost function
- Up to 31 hours play time. Pocket-sized charging case

Comfortable and convenient

- Stable Bluetooth® connection and easy pairing
- Quick charge for 10 minutes and get an extra hour

Ready for you

- Comfy fit and customizable on-ear touch controls
- Warm, natural sound. Philips sound signature

Highlights

Noise Canceling

Noise canceling quiets external noise, including wind, so you can focus on your tunes or calls. Want to hear more of what's going on around you? Tap an earbud to activate Awareness Mode.

Great sound. Dynamic Bass

These true wireless earbuds might be small, but you won't need to turn up the volume to get the best sound out of their 10 mm drivers. Activate Dynamic Bass via the earbud controls, or the Philips Headphones app, and you can enjoy the full power of your favorite basslines even if listening quietly.

31 hrs play time (7 + 24.5)

You get 7 hours play time from a full charge, and an extra 24.5 hours from the case. Pop the earbuds back in the charging case and they'll recharge fully in 1.5 hours. If you need a quick boost, just 10 minutes gives you an extra hour,

and Mono mode lets you use either earbud while the other one charges. The case can be charged via USB-C.

Bluetooth® 5.4 multipoint

Bluetooth® 5.4 brings you a steadier connection for seamless streaming without annoying dips in the sound.

Comfy fit and touch controls

The ear tips rest gently but securely in your ear canal and interchangeable silicone ear-tip covers let you find your perfect fit. Touch controls on the earbuds keep things simple.

Philips sound signature

Music to podcasts, you'll love what you hear! These true wireless earbuds feature large drivers tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.

Specifications

Sound

Frequency range: 20 - 20,000 Hz

Speaker diameter: 10 mm

Impedance: 32 Ohm

Maximum power input: 5 mW

Sensitivity: 106 dB (1k Hz)

Driver type: Dynamic

Connectivity

Bluetooth version: 5.4

Bluetooth profiles: A2DP, AVRCP, HFP

Maximum range: Up to 10 m

Supported codec: SBC

Outer Carton

Number of consumer packagings: 24

GTIN: 1 08 40063 20772 8

Convenience

Mono mode for TWS

Type of controls: Touch

Power

Number of batteries: 3 pcs

Music play time: 7 + 24.5 hour(s)

Charging time: 1.5 hour(s)

Fast charging time: 10 mins for an hour

Battery type(Charging case): Lithium Polymer (built-in)

Battery type(Earbud): Lithium Polymer (built-in)

Packaging dimensions

Packaging type: Carton

Type of shelf placement: Hanging

Number of products included: 1

Accessories

Quick Start Guide

Eartips: 3 sizes (S/M/L)

Charging case

Charging cable: USB-C cable, 200 mm

Design

Color: Dark blue

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear tip

Telecommunication

Microphone for call: 1 AI mic

UPC

UPC: 8 40063 20772 1

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant

Voice assistant activation: Multi-Function touch
Voice assistant support

