

# PHILIPS

## True wireless headphones

Small buds. Great value

Natural sound. Dynamic bass

Pocket-sized charging case

2-mic technology

TAT2020WT



## Hear your sounds perfectly

Hear your sounds perfectly. These True Wireless headphones use 13 mm drivers for lush sound and dynamic bass and an AI mic for clear calls. With a pocket-sized charging case, it gives 20 hours play time.

### **True wireless earbuds. Great sound and clear call**

- Great sound even at low volume with Dynamic Bass
- 13 mm driver and dynamic bass-boost function
- 2-mic technology. Clearer calls, even in crowded places

### **Ready for you**

- Comfy fit and customizable on-ear touch controls
- Warm, natural sound. Philips sound signature

### **Comfortable and convenient**

- Stable Bluetooth® connection and easy pairing
- Up to 20 hours play time. Pocket-sized charging case

# Highlights

## Great sound. Dynamic Bass

These true wireless earbuds might be small, but you won't need to turn up the volume to get the best sound out of their 13 mm drivers. Activate Dynamic Bass via the earbud controls, or the Philips Headphones app, and you can enjoy the full power of your favorite basslines even if listening quietly.

## 2-mic technology

If you're on a call, our two-mic set up and a noise-reduction algorithm will combine to pick up the sound of your voice and quieten background noise. Even if you're in a busy café, your voice will come through clearly and the person you're speaking to won't need to listen to all the other conversations going on around you as well!

## Bluetooth® 5.4 multipoint

Bluetooth® 5.4 brings you a steadier connection for seamless streaming without annoying dips in the sound.

## 20 hrs play time (5 + 15)

You get 5 hours play time from a full charge, and an extra 15 hours from the case. Pop the earbuds back in the charging case and they'll recharge fully in 1.5 hours. Mono mode lets you use either earbud while the other one charges. The case can be charged via USB-C.

## Comfy fit and touch controls

The ear tips rest gently but securely in your ear canal and interchangeable silicone ear-tip covers let you find your perfect fit. Touch controls on the earbuds keep things simple.

## Philips sound signature

Music to podcasts, you'll love what you hear! These true wireless earbuds feature large drivers tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.

# Specifications

## Sound

**Frequency range:** 20 - 20,000 Hz  
**Speaker diameter:** 13 mm  
**Impedance:** 32 Ohm  
**Maximum power input:** 5 mW  
**Sensitivity:** 109 dB (1k Hz)  
**Driver type:** Dynamic

## Connectivity

**Bluetooth version:** 5.4  
**Bluetooth profiles:** A2DP, AVRCP, HFP  
**Maximum range:** Up to 10 m  
**Supported codec:** SBC

## Outer Carton

**Number of consumer packagings:** 24  
**GTIN:** 1 08 40063 20775 9

## Convenience

**Mono mode for TWS**  
**Type of controls:** Touch

## Inner Carton

**Number of consumer packagings:** 3  
**GTIN:** 2 08 40063 20775 6

## Power

**Number of batteries:** 3 pcs  
**Music play time:** 5 + 15 hour(s)  
**Charging time:** 1.5 hour(s)  
**Battery type(Charging case):** Lithium Polymer (built-in)  
**Battery type(Earbud):** Lithium Polymer (built-in)

## Packaging dimensions

**Packaging type:** Carton  
**Type of shelf placement:** Hanging  
**Number of products included:** 1

## Accessories

**Quick Start Guide**  
**Eartips:** 3 sizes (S/M/L)  
**Charging case**  
**Charging cable:** USB-C cable, 200 mm

## Design

**Color:** White  
**Ear coupling material:** Silicone  
**Ear fitting:** In-ear  
**In-ear fitting type:** Silicone ear tip

## Telecommunication

**Microphone for call:** 1 mic

## UPC

**UPC:** 8 40063 20775 2

## Voice assistant

**Voice assistant compatible:** Apple Siri, Google Assistant  
**Voice assistant activation:** Multi-Function touch  
**Voice assistant support**

