

PHILIPS

Home Projector

NeoPix 950 Smart

150" in True FULL HD 1080p

Innovative 2LCD technology

2 x 12 watts stereo speakers

Google TV streaming device inc

NPX950



New display technology, enhanced experience

Stunning 150" 1080p Native Full HD picture! 2LCD technology and 2 x 12 Watts stereo speakers. Enjoy your favourite shows, films and more with the included Google TV streaming device

Advanced Image Technology

- True Full HD 1080p
- 2LCD display technology

Connected preferences

- Google TV streaming device included
- Wi-Fi screen mirroring

Audio and adjustments

- Massive audio experience
- Build your perfect image

Highlights

Google TV streaming device included

Google TV brings together all your favourite streaming apps and personalised recommendations in one intuitive platform. With a user-friendly interface, Google TV curates shows, movies and videos based on your viewing habits, suggesting options from services like Netflix, Hulu, Disney+ and more, so you can discover new favourites without endless scrolling.

Wi-Fi screen mirroring

Connect your mobile devices wirelessly to mirror and share your local content on tablets, smartphones or even computers. Videos on your phones? No worries, just send it through Wi-Fi!

Massive audio experience

The 12 Watts stereo audio system with clear bass enhances the cinematic experience with powerful sound and the possibility to connect to larger sound systems via Bluetooth or its 3.5 mm output jack.

Build your perfect image

Its advanced features like auto keystone correction, 4 corner adjustment, digital zoom, auto focus and smart obstacle avoidance ensure perfectly proportioned images

True Full HD 1080p

Watch films and more in Native Full HD 1080p high-definition sharpness, full of the fine details that can be lost at lower resolutions. The picture remains lifelike and text is crystal-clear when displayed on a wall, ceiling... and more!

2LCD display technology

By stacking two LCDs, the NeoPix 950 Smart delivers significantly higher brightness and more vivid colours compared to traditional single-LCD displays.

Specifications

Technology

Display technology: 2 LCD

Light source: LED

Brightness: up to 1400 lumens*

Contrast ratio: 1100:1

Resolution: 1920 x 1080 pixels

Throw ratio: 1.2:1

Aspect ratio: 16:9

Focus adjustment: Auto

Integrated media player

Keystone correction: Auto

LED lifetime: Up to 30,000 h

Projection image size: up to 380 cm (150")

Connection

Wi-Fi: Dualband 2.4 GHz and 5 GHz

WLAN IEEE 802.11 b/g/n: screen mirroring function

Bluetooth: 5.2

HDMI: x 2

USB: x 2

Audio out: 3.5 mm jack

Sound

Stereo Speaker: 2 x 12 W

Bluetooth speaker connection

Dimensions

Weight: 4.3 kg

unpacked (W x D x H): 280.5 x 181.5 x 264 mm



* Google TV is the name of this device's software experience and a trademark of Google LLC.

* Colour brightness (colour light output) and white brightness (white light output) will vary depending on projector settings. Colour light output is measured in accordance with IDMS 15.4; white light output is measured in accordance with ISO 21118.

* The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.