

PHILIPS

Car headlights bulb

Ultinon Pro6000 Boost

Type of lamp: H1

Road-legal LED bulb

Enhanced fleet compatibility

Superior brightness

11258U60B2X2



Ultimate road-legal LED bulb

Ultra-compact design with high performance

Discover the Philips Ultinon Pro6000 Boost series, the new benchmark in automotive road-legal LED bulbs. Explore the next generation of retrofit LED lighting and enter a new era where performance and light quality reach new heights.

Certified LED range

- Approved by automotive experts in Europe

Extended fleet integration

- Fits an unprecedented range of vehicles
- Compact design that fits where others can't

Next-generation performance

- Brighter illumination on the road
- Safe driving technologies
- Long-term durability and warranty

Reliable Philips quality

- Meeting rigorous automotive standards

Philips Accessories for You

- Vehicle-specific solutions

Ultinon Pro6000 Boost

Car headlights bulb

LUM11258U60B2X2/10

Highlights

Certified LED range

The Philips Ultinon Pro6000 Boost range has been approved for road use in several European Union countries¹, ensuring full compliance with road-traffic regulations. As a result, these LED bulbs can safely replace traditional bulbs in a broad range of vehicles, from cars and two-wheelers to camper vans, vans and light commercial vehicles. Drive in confidence with our new Philips Ultinon Pro6000 Boost LED bulbs, road-legal and approved for public roads.

Enhanced compatibility

The next-generation Philips Ultinon Pro6000 Boost H1-LED bulb fits more vehicles than ever before, bringing premium lighting to a wider range of drivers. With support for additional headlight types and over 60 extra vehicle models, this H1-LED bulb delivers exceptional illumination across an unprecedented variety of vehicles. Experience the difference of superior LED technology with brighter, clearer light that enhances your visibility and driving confidence. Check out our complete compatibility list at [Philips.com/roadlegalLED](https://philips.com/roadlegalLED) to find the perfect LED replacement for your halogen bulbs!

Simpler installation

The next-generation Philips Ultinon Pro6000 Boost H1-LED bulb features a compact footprint allowing fitting in even the narrowest headlight housings. Its sleek, minimalist body makes bulb replacement straightforward for both high- and low-beam functions¹, offering drivers greater

versatility and functionality. Forget about complex LED retrofitting challenges – this bulb's innovative design ensures a hassle-free upgrade experience without special tools or modifications.

Improved brightness

Enjoy maximum visibility with lower power consumption. The next-generation Philips Ultinon Pro6000 Boost H1-LED delivers an impressive 1550 lumens of effective light output in a compact design for outstanding on-road performance. Its optimised beam pattern helps you spot hazards earlier and drive with exceptional clarity and confidence, even on the darkest roads.

Safe driving technologies

The Philips Ultinon Pro6000 Boost series delivers an optimal light spectrum and a 5800 K colour temperature, improving contrast for road signs and hazards, even at high speeds. Its advanced SafeBeam technology produces a precisely defined cut-off line and controlled beam pattern that maximises visibility without dazzling oncoming traffic. This combination ensures maximum illumination with safe, comfortable lighting for every drive.

Long-term durability

Drive longer with peace of mind. Built to last up to 3000 hours, the Philips Ultinon Pro6000 Boost H1-LED gen2 lasts six times longer than standard

halogen bulbs on the market. Active cooling technology ensures stable brightness and prevents overheating for long-lasting reliability. For complete peace of mind, every bulb comes with a 5 year warranty (2 years standard + 3 years extended protection²).

Expert engineering

With our extensive expertise in building premium automotive lighting products that prioritise safety and reliability, we excel in maintaining high-quality standards. Our range of Philips LED bulbs meets the strict requirements for electromagnetic compatibility (EMI) with vehicle systems and offers stable, professional-quality lighting. Rely on the world-renowned expertise of an automotive specialist.

Philips accessories for you

Each vehicle model is unique, and while most don't need additional accessories when retrofitting to LED lights, some do. The next-generation Philips Ultinon Pro6000 Boost LED range includes vehicle-specific ring types and our exclusive Philips 3-in-1 CANbus adapter for the best lighting experience. Check our online compatibility list at [Philips.com/roadlegalLED](https://philips.com/roadlegalLED)¹ to determine if your vehicle requires a Philips accessory.

Ultinon Pro6000 Boost

Car headlights bulb

LUM11258U60B2X2/10

Specifications

Marketing specifications

Product highlight: Ultra compact, AirBoost heat management, SafeBeam technology
Expected benefits: Road-legal, Superior brightness, Easy to fit

Product description

Application: High Beam, Low Beam
Base: P14.5s
Colour temperature: 5800 K
Designation: LED H1 11258 U60B2 12 V 15 W X 2
Designation LED Type: H1-LED
Lifespan: 3,000 hours
Operating Temperature: -40 to +105°C
Range: Ultinon Pro6000 Boost
Technology: LED, LED
Type: H1
Ingress protection rating (IP): IP54
ECE R37 certification: No
ECE R10 certification
Polarity free
Homologation: National approval¹

Compliance to ROHS

Compliance to EU ELV

Vibration and shock Resistance (IEC 60810)

Light performance: Up to +140%

Diameter: 11.0

Length – mm: 75.0

Light characteristics

Lumens: 1550 lm

Electrical characteristics

Wattage: 15 W

Voltage: 12 V

Ordering information

Order entry: 11258U60B2X2

Ordering code: 3081894

Logistic data

Quantity in box: 2 pcs

Packaging Data

Packing: Set box

EAN1: 8719018030818

EAN3: 8719018030825

Packed product information

Length: 11,1 cm

Width: 5 cm

Height: 13,5 cm

Net weight per piece [g]: 27 g

Net weight per pack: 34 g

Gross weight: 92 g

Outer pack information

Length: 23.6 cm

Width: 11.6 cm

Height: 15.4 cm

Packing: Carton

Quantity: 8 pcs (4 sets)

Gross weight per outer pack: 0.425 kg



* ¹ The Philips Ultinon Pro6000 LED Boost range is approved for road traffic in the respective countries where approval exists and for the listed range of vehicle models and lighting functions only. For more information about the legal requirements that apply in your country and to consult our latest compatibility list, visit Philips.com/roadlegalLED. You are responsible for complying with legal requirements applicable in your country.

* ² The Philips Ultinon Pro6000 LED Boost range is covered by a 2 year guarantee on purchase + 3 years' free extended warranty upon registration. The Philips warranty covers manufacturing defects and non-commercial use only.