

# PHILIPS



## TV headphones

### 6000 series

Reliable digital connection

Comfy fit and 30 m range

30 hrs of play time

Replaceable battery



SHD6000BK

## Crystal-clear TV sound, just for you

Unwind in comfort with the wireless over-ear headphones that are dedicated to bringing you great TV sound. You get a steady digital connection to your TV and up to 30 hours play time. Perfect for watching without disturbing anyone else.

### **Wireless over-ear TV headphones. Built to watch.**

- Easy to set up. Easy to use
- Base unit connects to the TV via included optical cables
- No missed moments. Stable digital connection to base unit
- Reliable digital 2.4 G connection and 30 m range

### **Tuned for great TV sound. Designed for comfort.**

- Great sound and comfy fit for long viewing sessions
- 30 hours of play time. Replaceable, rechargeable battery
- Large 32 mm drivers tuned for crisp and clear TV sound
- Lightweight and adjustable dual-layer headband

### **Brilliant for films, series, sports and more!**

- Convenient buttons on ear cup for volume control
- A quick 15 minute charge gets you 4 hours of play time
- Warm, natural sound. Philips sound signature
- RCS-certified recycled plastic. Responsible packaging

# Specifications

## Sound

Acoustic system: Closed  
 Frequency range: 10 - 21,000 Hz  
 Speaker diameter: 32 mm  
 Impedance: 24 Ohm  
 Maximum power input: 10 mW  
 Sensitivity: 96 dB (1 kHz, 179 mV)  
 Driver type: Dynamic

## Connectivity

Cable Connection: 3.5 mm stereo plug  
 Finishing of connector: chrome-plated  
 Maximum range: Up to 30 m  
 Headphone socket: 3.5 mm

## Outer Carton

Length: 32.50 cm  
 Number of consumer packages: 3  
 Width: 26.00 cm  
 Gross weight: 2.447 kg  
 Height: 32.50 cm  
 GTIN: 1 48 95229 17523 2  
 Net weight: 0.98 kg  
 Tare weight: 1.467 kg

## Convenience

Automatic power off  
 Volume control: Rotary  
 Type of controls: Button

## Power

Number of batteries: 1 pcs  
 Music play time: 30 hour(s)  
 Charging time: 3 hour(s)  
 Fast charging time: 15 mins for 4 hrs  
 Battery weight (Total): 15.4 g  
 Battery capacity (Headphones): 600 mAh  
 Battery type (Headphones): Lithium Polymer

## Packaging dimensions

Height: 30.5 cm  
 Packaging type: Carton  
 Type of shelf placement: Hanging  
 Width: 24 cm  
 Depth: 9 cm  
 Number of products included: 1  
 EAN: 48 95229 17523 5  
 Gross weight: 0.671 kg  
 Net weight: 0.326 kg  
 Tare weight: 0.345 kg

## Product dimensions

Height: 22.00 cm  
 Width: 19.00 cm  
 Depth: 8.50 cm  
 Weight: 0.153 kg

## Accessories

Others: 1 pc replaceable battery, 3.5 mm optical cable  
 Quick Start Guide  
 Docking station (transmitter)  
 Included adapters: AC/DC adapter

## Design

Colour: Black  
 Wearing style: Headband  
 Ear coupling material: Fabric  
 Ear fitting: Over-ear  
 Earcup type: Closed-back

## Sustainability

Plastic shell: contains 6% RCS certified recycled post-consumer Acrylonitrile Butadiene Styrene TE-0013249

# Highlights

## Easy to set up and use

These wireless TV headphones are so easy to set up, you can be ready to watch before the popcorn's popped! Simply connect the base unit to your TV using the included 3.5 mm cable or optical cable. The headphones come pre-paired with the base unit and you can control the volume via buttons on the ear cup.

## Digital 2.4 G connection

These TV headphones use a digital 2.4 G connection to receive signals from the base unit, so you won't be interrupted by interference if others are using smart devices or radios nearby. You can even go into the kitchen to make a snack—the 30 m range ensures that you'll still hear what's happening.

## Great sound, comfy fit

Large 32 mm drivers deliver crisp sound that lets you hear speech and sound effects clearly, while soundtracks are rich and full. Settling in for a film or binge-watching a series? The dual-layer headband features an inner band that adjusts to fit your head perfectly, and the lightweight ear cups are soft and comfy.

## 30 hrs of play time

Fully charged, these TV headphones will give you up to 30 hours of play time, and a quick 15 minute charge gets you 4 extra hours. Recharging the headphones fully takes 3 hours via USB-C, and the battery is easy to replace when it reaches the end of its life.

## Philips sound signature

The drivers in these TV headphones are tuned to the Philips sound signature, which brings you warm, natural sound with deep bass and clear high frequencies. From films to series, you'll enjoy clear spoken dialogue and detailed sound effects, while the rich bass adds to the excitement of action sequences.

## Recycled materials

RCS-certified post-consumer recycled plastics are used in these headphones and our packaging is plastic-free. Inserts are printed on recycled paper and the packaging itself is made from FSC-certified recycled cardboard.

