

# PHILIPS



## Over-ear headphones

Detailed, natural sound

Noise Canceling Pro

Up to 70 hours play time

Replaceable ear-cup cushions



TAH8000WT

## Superb hi-res sound

Immerse in rich, detailed sound with the wireless over-ear headphones that were built for years of comfortable listening. Music sounds thrilling, call quality is crystal-clear, and adaptive noise cancellation lets you focus on what matters.

### **Over-ear wireless headphones. Hi-res sound.**

- Thrilling sound. Hi-res streaming and wired listening
- Powerful 40 mm silk-coated drivers
- Immerse freely with Adaptive Noise Canceling
- 5-mic technology. Clearer calls, even in noisy locations
- Up to 70 hours play time (50 with noise canceling on)

### **Auracast™ connectivity. Replaceable components.**

- Bluetooth® multipoint connectivity and Auracast™
- Designed for years of comfortable use
- Shockproof, dustproof hard-cover travel case included

### **Your companion for years to come**

- A quick 10-minute charge provides 8 hours of playback
- Philips Headphones app. Personalize settings and controls
- Warm, detailed, natural. Philips sound signature
- RCS-certified recycled plastic. Responsible packaging

# Highlights

## Thrilling sound

Silk-coated 40 mm drivers give you detailed sound—and Dynamic Bass brings you full, rich bass even at low volumes. The LDAC and LC3 codecs are supported so you can get the most from hi-res streaming, and you can listen wired via USB-C. Plus, you can turn on Spatial Audio in our app for a more immersive listening experience.

## Noise Canceling Pro

Adaptive noise cancellation quickly reacts to your surroundings to suppress external noise, including wind, in real time. If you want to hear what's going on around you, Awareness Mode lets outside sounds back in. Quick Awareness enhances voices, so you can have a conversation without removing your headphones.

## 5-mic technology

If you're on a call, dedicated mics and a noise-reduction algorithm combine to clearly pick up your voice and reduce background noise. Even if you're on a busy urban street on a very windy

day—your voice will come through clearly, and the person you're speaking to won't be distracted by what's going on around you.

## Up to 70 hours (with ANC off)

With noise canceling off, you get 70 hours play time from a full charge (with noise canceling on, you get 50 hours). For a quick boost, 10 minutes charging via USB-C gives you an extra 8 hours. Pairing is simple via our companion app, plus Android users can use Google Fast Pair and Windows users can use Microsoft Swift Pair.

## Bluetooth® 5.4 and Auracast™

Bluetooth® 5.4 brings you a steadier connection for seamless, high-quality streaming, and multipoint connectivity lets you connect to two Bluetooth® devices at once. Support for Auracast™ means you can listen to public broadcasts: tune in to announcements at the airport or catch the commentary while you're in a sports bar.

## Philips Headphones app

Our handy companion app lets you manage connected devices or turn adaptive noise cancellation off and adjust the levels yourself.

You can also use the app to scan for Auracast™ broadcasts, control sound features like Dynamic Bass and Spatial Audio, create custom sound presets, get the latest firmware—and more!

## Recycled materials

We use post-consumer recycled plastics in this product, and our packaging is plastic-free. Inserts are printed on recycled paper with soy-based ink, and the packaging itself is made from FSC-certified recycled cardboard.

## Your daily companion

The wide, soft headband can be adjusted via a hidden slider for the perfect fit—and the soft memory-foam ear-cup cushions can be replaced when they reach the end of their life. The ear cups fold flat and inward for easy portability, or safe storage in a drawer.

## Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, detailed sound with rich bass. Whatever you're listening to, you'll love what you hear.

# Specifications

## Sound

Acoustic system: Closed  
Frequency range: 20 - 40,000 Hz  
Impedance: 16 Ohm  
Sensitivity: 112 dB (1K Hz, 126mV)  
Speaker diameter: 40 mm  
Maximum power input: 20 mW  
Driver type: Silk coated  
Hi-Res Audio

## Connectivity

Bluetooth version: 5.4  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC, LDAC, LC3, AAC  
Headphone socket: 3.5 mm

## Outer Carton

Length: 28.80 cm  
Number of consumer packagings: 3  
Width: 22.70 cm  
Gross weight: 1.9 kg  
Height: 25.00 cm  
GTIN: 1 48 95229 16525 7  
Nett weight: 0.81 kg  
Tare weight: 1.09 kg

## Convenience

Philips Headphones app support  
Google fast pair  
Firmware updates possible  
Type of controls: Button

## Power

Number of batteries: 1 pcs  
Charging time: 2 hour(s)  
Music play time (ANC on): 50 hour(s)  
Music play time (ANC off): 70 hour(s)  
Fast charging time: 10 mins for 8 hrs  
Battery weight (Total): 22 g  
Battery capacity(Headphones): 1000 mAh  
Battery type(Headphones): Lithium Polymer

## Packaging dimensions

Height: 23 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 21.2 cm  
Depth: 9.1 cm  
Number of products included: 1  
EAN: 48 95229 16525 0  
Gross weight: 0.390 kg  
Nett weight: 0.270 kg  
Tare weight: 0.120 kg

## Product dimensions

Height: 21.50 cm  
Width: 19.00 cm  
Depth: 9.00 cm  
Weight: 0.260 kg

## Accessories

Audio cable: 3.5-3.5mm stereo cable, L=1m  
Quick Start Guide  
Charging cable: USB-C cable, 200 mm

## Design

Color: White  
Wearing style: Headband  
Foldable design: Flat/In-ward  
Ear coupling material: Memory foam  
Ear fitting: Over-ear  
Earcup type: Closed-back

## Telecommunication

Microphone for call: 3 mics  
Wind noise reduction

## ANC features

ANC technology: Hybrid, ANC Pro+  
Awareness mode  
Adaptive ANC  
Microphone for ANC: 4 mic  
ANC (Active Noise Canceling)

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Press Voice Assistant button  
Voice assistant support

## Sustainability

Plastic shell: contains 13% RCS certified recycled post-consumer Acrylonitrile Butadiene Styrene  
TE-00132492

