

# PHILIPS



True wireless  
headphones

7000 series

45 hours play time

Noise Canceling Pro

6-mic technology

Detailed, natural sound



TAT7000BK

## Great sound in any language

Business or pleasure, travel gets a whole lot easier with the true wireless earbuds that can help you connect. With our app and adaptive noise cancellation, you'll hear more—and say more—wherever you go.

### True wireless earbuds

- Superb hi-res sound wherever you go
- Immerse freely with Adaptive Noise Canceling
- 6-mic technology. Clearer calls, even in crowded places

### The perfect travel companion

- Stable Bluetooth® multipoint connection and Auracast™
- Up to 45 hours play time
- Comfy, sweat-resistant, customizable
- IPX4, earbud controls, three sizes of silicone ear tips

### Seamlessly brilliant

- Quick charge for 15 minutes and get an extra 4 hours
- Philips Headphones app. Custom control
- Warm, detailed, natural. Philips sound signature
- Responsible packaging

# Highlights

## Great sound

The LDAC codec is supported so you can get the most out of hi-res streaming, and Dynamic Bass brings you full, rich bass even at low volumes.

You can also turn on Spatial Audio in our companion app to enjoy a subtle surround-sound effect for music or movies. Plus, the in-app equalizer lets you adjust the bass, treble, and voice to your liking.

## Noise Canceling Pro

Adaptive noise cancellation automatically reacts to your surroundings to suppress external noise, including wind, in real time. To hear what's going on around you, simply tap an earbud to activate Awareness Mode. Or activate Quick Awareness to enhance voices and have a conversation without removing an earbud.

## 6-mic technology

If you're on a call, our six-mic setup and a noise-reduction algorithm will combine to pick up the sound of your voice and quiet background noise. Even if you're in a busy cafe, your voice will come

through clearly, and the person you're speaking to won't need to listen to all the other conversations going on around you as well!

## Bluetooth® 6.0, Auracast™

Bluetooth® 6.0 ensures a fast, steady connection, and support for Auracast™ lets you listen to public broadcasts on your travels. You can connect to two Bluetooth® devices at once and manage connected devices via our app—plus Microsoft Swift Pair makes life easy for Windows users.

## 45 hours play time (9 + 36)

With noise canceling off, you get 9 hours play time from a full charge and an extra 36 hours from the pocket-sized charging case (with noise canceling on, you get 6 hours and an extra 24 from the case). For a quick boost, 15 minutes in the case gives you an extra 4 hours. The case can be charged via the USB-C (not included in the packaging).

## Philips Headphones app

Our handy companion app is packed with features for your earbuds. Use the app to control noise canceling and wind-noise reduction,

manage connected devices, tweak the bass, treble, and voice frequencies, get the latest firmware—and more.

## IPX4 and comfy in-ear fit

An IPX4 rating means these buds can handle the moisture if you sweat, and a little light rain won't bother them either. You get three sizes of silicone ear tips for the perfect fit, and you can customize how the earbud touch controls are set up via the Philips Headphones companion app.

## Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, detailed sound with rich bass. Whatever you're listening to, you'll love what you hear.

## Recycled materials

We use post-consumer recycled plastics in this product, and our packaging is plastic-free. Inserts are printed on recycled paper with soy-based ink, and the packaging itself is made from FSC-certified recycled cardboard.

## 7000 series

True wireless headphones

TAT7000BK/97

# Specifications

### Sound

Frequency range: 20 - 20,000 Hz  
Speaker diameter: 10 mm  
Impedance: 16 Ohm  
Maximum power input: 5 mW  
Sensitivity: 112 dB (1kHz, 1mW)  
Driver type: Dynamic  
Hi-Res Audio

### Connectivity

Bluetooth version: 6.0  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC, AAC, LDAC

### Outer Carton

Length: 26.10 cm  
Number of consumer packagings: 24  
Width: 22.30 cm  
Gross weight: 3.12 kg  
Height: 21.50 cm  
GTIN: 1 48 95229 16025 2  
Nett weight: 1.76 kg  
Tare weight: 1.36 kg

### Convenience

Automatic power off  
Volume control  
Water resistance: IPX4  
Philips Headphones app support  
Mono mode for TWS  
Firmware updates possible  
Type of controls: Touch  
Microsoft Swift Pair

### Inner Carton

Length: 12.10 cm  
Number of consumer packagings: 3  
Width: 10.05 cm  
Height: 9.00 cm  
Nett weight: 0.22 kg  
Gross weight: 0.35 kg  
Tare weight: 0.13 kg  
GTIN: 2 48 95229 16025 9

### Power

Number of batteries: 3 pcs  
Charging time: 2 hour(s)  
Music play time (ANC on): 6 + 24 hour(s)  
Music play time (ANC off): 9 + 36 hour(s)  
Fast charging time: 15 mins for 4 hrs  
Battery type(Charging case): Lithium Polymer (built-in)  
Battery type(Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 17.8 g  
Battery capacity(Case): 740 mAh  
Battery capacity(Earbud): 55 mAh

### Packaging dimensions

Height: 10 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 9.7 cm  
Depth: 3.8 cm  
Number of products included: 1  
EAN: 48 95229 16025 5  
Gross weight: 0.101 kg  
Nett weight: 0.073 kg  
Tare weight: 0.028 kg

### Accessories

Quick Start Guide  
Eartips: 4 pairs (S/M/L/XL)  
Charging case

### Design

Color: Black  
Ear coupling material: Silicone  
Ear fitting: In-ear  
In-ear fitting type: Silicone ear tip

### Telecommunication

Microphone for call: 6 mics

### Dimensions

Charging case dimension(WxDxH): 6.49 x 3.01 x 4.07 cm  
Earbud dimension(WxDxH): 2.15 x 2.42 x 2.77 cm  
Total weight: 0.051 kg

### ANC features

ANC technology: Hybrid, ANC Pro  
Awareness mode  
Microphone for ANC: 2 mic  
ANC (Active Noise Canceling)

### Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Multi-Function touch  
Voice assistant support

