

# PHILIPS

Smart lever lock

2000 series

Built-in Wi-Fi

Fingerprint access

Passage mode

Integrated lever

DDL220XI5KNW



## Integrated smart lever lock

### Effortless access with fingerprint unlock

Seamless style meets smart security—the integrated lever handle combines everyday comfort with a passage mode for high-traffic moments, plus multiple unlock methods and instant alerts to keep you informed.

#### Seamless ease of use

- Passage mode keeps entry open for busy moments
- Ergonomic lever handle offers smooth, comfortable use
- Easy installation and effortless setup

#### Technical solutions

- Works with voice assistants for easy smart home integration
- Remote control your lock through app on your smartphone

#### Enhanced security and safety

- Anti-peep PIN code to keep it private

# Highlights

## Works with voice assistants

Seamlessly integrate the lock into your smart home system with Amazon Alexa or Google Assistant. Use voice commands to lock /unlock the door and check door status, offering convenient hands-free control.

## Anti-peep PIN code

The Anti-Peep PIN Code feature lets you enter your real PIN code along with random digits before and after, creating a total of up to 20 characters. This ensures that even if someone is nearby, they cannot observe your real PIN, keeping your entry private and secure.

## Passage Mode

Schedule passage mode in the Philips Home Access app for regular times or short durations. Keep the door open for guests, family, or busy moments—then return to secure mode automatically.

## Remote control through app

With the Philips Home Access app, you can lock and unlock your door remotely, share PIN codes, monitor real-time notifications, and check your lock's activity history—all from your smartphone, ensuring complete control over your home's security no matter where you are.

## Ergonomic Lever Handle

Designed for daily comfort, the integrated lever handle provides easy grip and effortless turning, making entry simple for children, seniors, and guests.

## Easy installation

No extra wiring or complex tools required—just a screwdriver and follow the step-by-step guide for a quick installation. With an intuitive app interface, configuring PIN codes and settings is seamless, making it easy for anyone to get started.

# Specifications

## Design

**Material:** Aluminum alloy

## Access solutions

**Unlocking from outside:** PIN code, Mechanical key, Home Access app, Fingerprint  
**Unlocking from inside:** Lever, Home Access app, Voice assistant

## Max Credentials Capacity

**Master PIN code:** 1  
**User PIN code:** 100  
**One-time PIN code:** Unlimited

## Design

**Color:** Nickel

## Installation

**Bolt type:** Latch bolt  
**Keyway:** SC1  
**Door thickness:** 1-3/8 to 2 inch (35-50mm)  
**Opening direction:** Left inside / Left outside, Right inside / Right outside  
**Cross bore hole:** 2-1/8 inch (54mm)  
**Backset:** 2-3/8 or 2-3/4 inch (60mm/70mm)

## Max Credentials Capacity

**Fingerprint:** 50

## Modes

**Operation mode:** Manual mode, Passage mode, Auto mode  
**Security mode:** Privacy mode

## Connectivity

Bluetooth  
 Wi-Fi

## Power

**Power supply:** 8 AA batteries  
**Emergency powering:** Not supported

## Voice guide

**Language:** English / French / Spanish

## Operating Environment

**Temperature:** From -35°C to 66°C  
**Humidity:** 0-95%

## Key Features

**Safety:** AES128, Local storage  
**Alarm:** Low battery alarm, Wrong entry limit alarm, Jam alarm  
**Remote control:** App unlock, Generate temporary PIN codes, Create schedule PIN codes, Simple sharing

