

PHILIPS

Smart lever lock

2000 series

Built-in Wi-Fi

Fingerprint access

Passage mode

Integrated lever

DDL220XI5KMW



Integrated smart lever lock

Effortless access with fingerprint unlock

Seamless style meets smart security—the integrated lever handle combines everyday comfort with a passage mode for high-traffic moments, plus multiple unlock methods and instant alerts to keep you informed.

Seamless ease of use

- Multiple unlock methods fit your lifestyle
- Passage mode keeps entry open for busy moments
- Ergonomic lever handle offers smooth, comfortable use

Technical solutions

- Remote control your lock through app on your smartphone
- Works with voice assistants

Enhanced security and safety

- Anti-peep PIN code to keep it private

Highlights

Anti-peep PIN code

The Anti-Peep PIN Code feature lets you enter your real PIN code along with random digits before and after, creating a total of up to 20 characters. This ensures that even if someone is nearby, they cannot observe your real PIN, keeping your entry private and secure.

Remote control through app

With the Philips Home Access app, you can lock and unlock your door remotely, share PIN codes, monitor real-time notifications, and check your lock's activity history—all from your smartphone, ensuring complete control over your home's security no matter where you are.

Multiple unlock methods

Choose the way to unlock your Philips smart lock with integrated lever handle: fingerprint, PIN code, key, or the Philips Home Access app. Flexible options for every family member and situation.

Works with voice assistants

Seamlessly integrate the lock into your smart home system with Amazon Alexa or Google Assistant. Use voice commands to lock/unlock the door and check door status, offering convenient hands-free control.

Passage Mode

Schedule passage mode in the Philips Home Access app for regular times or short durations. Keep the door open for guests, family, or busy moments—then return to secure mode automatically.

Ergonomic Lever Handle

Designed for daily comfort, the integrated lever handle provides easy grip and effortless turning, making entry simple for children, seniors, and guests.

Specifications

Design

Material: Aluminum alloy

Access solutions

Unlocking from outside: Mechanical key, Home Access app, Fingerprint, PIN code

Unlocking from inside: Home Access app, Voice assistant, Lever

Max Credentials Capacity

Master PIN code: 1

User PIN code: 100

One-time PIN code: Unlimited

Design

Color: Matte black

Installation

Bolt type: Latch bolt

Keyway: SC1

Door thickness: 1-3/8 to 2 inch (35-50mm)

Opening direction: Left inside / Left outside, Right inside / Right outside

Cross bore hole: 2-1/8 inch (54mm)

Backset: 2-3/8 or 2-3/4 inch (60mm/70mm)

Max Credentials Capacity

Fingerprint: 50

Connectivity

Bluetooth

Wi-Fi

Z-Wave: No

Modes

Operation mode: Manual mode, Auto mode

Security mode: Privacy mode

Power

Power supply: 8 AA batteries

Emergency powering: Not supported

Voice guide

Language: English / French / Spanish

Accessory

Wi-Fi bridge: Not included

Operating Environment

Temperature: From -35°C to 66°C

Humidity: 0-95%

Key Features

Safety: AES128, Local storage

Alarm: Low battery alarm, Wrong entry limit alarm, Jam alarm

Remote control: App unlock, Manage user account, Create schedule PIN codes, Simple sharing

