

PHILIPS

Electric storage
water heater

AquaShield

10L, Storage

150W

Single heating element

Mechanical control

AWH1630/70



Continuous temperature control system

High-Performance Magnesium Anode Rod

FlowGuide technology ensures higher heating efficiency, high-Quality Components for durable life. Meanwhile, SafeShield system ensures all-around protection for you.

User friendly design

- Long-lasting heat preservation

Heat-Express technology

- Flowguide technology

With all-around protection system

- Six-level safety protection system ensures safe operation
- ELCB

High-Quality Components

- Enameled Stainless Steel Heating Element
- Single weld line design

Highlights

Heat-Express technology

Supported by our FlowGuide, the utilization of hot water is greatly enhanced, allowing up to 20% more hot water availability for your extended enjoyment.

Long-lasting heat preservation

The thick polyurethane insulation layer slows down the heat loss in the tank, and as such reduces the energy consumption caused by unnecessary repetitive heating.

High-Quality Components for durable life

With an enamel-coated heating tube that provides superior resistance against corrosion and scaling, significantly extending the product's service life.

Six-level safety protection

Six-level safety protection including high-temperature protection, dry burning protection and IPX4 waterproof provides a safer use.

Durable inner tank

Enamel tank with single weld line design, reduces over 67% water leakage risk than 3 weld lines.

ELCB

ELCB detects small stray voltages on the metal enclosures of electrical equipment, and interrupts the circuit if a dangerous voltage is detected.

Specifications

General specifications

Net weight: 7.5 kg

Gross weight: 8.8 kg

Packaging dimension (L*W*H):

385*350*365 mm

Product dimension (L*W*H): 324*324*315 mm

Waterproof: IPX4

Main parameters

Rated Power: 150 W

Capacity: 10 L

Color: White

Control type: Mechanical control

Voltage and frequency: 220V/50Hz

Installation way: Floor mount

Heating type: Single heating element

Temperature regulating range: 75°C

Country of origin

Made in: China

Service

Warranty: 2 years

