

PHILIPS

Split Air Conditioner
Non-Inverter 1.5HP

Air Series

Smart Core Self-wash

Auto Restart with Memory

One Touch Turbo

FAC12AB1FMYB



Split Air Conditioner Non-Inverter 1.5HP Ab1 Serie

Delivers quiet, efficient, and hygienic performance with 3-Star Energy Efficiency.

Ab1 Malaysia

- Smart Core Self-wash
- Auto Restart with Memory
- One Touch Turbo
- Sleep Mode
- DN Multi-Dimensional Noise Reduction System
- Automatic Vertical Louver Swing
- LED Backlight Display
- Filter Dirty Alarm

Air Series

Split Air Conditioner Non-Inverter 1.5HP

Highlights

Smart Core Self-wash

Automatically captures moisture from the air to deeply clean the evaporator. This not only delivers cleaner airflow but also ensures long-lasting, powerful operation of the core.

Auto Restart with Memory

Automatically restores previous settings (mode, temperature, fan speed, and swing) after a power outage—no need to reset manually.

One Touch Turbo

Delivers powerful cooling in as fast as 30 seconds, quickly creating a comfortable environment.

Sleep Mode

Automatically adjusts cooling based on ambient temperature and body temperature for a quieter, more restful night's sleep.

DN Multi-Dimensional Noise Reduction System

Optimized air duct design, advanced refrigerant flow, and structural engineering minimize noise for whisper-quiet operation.

Automatic Vertical Louver Swing

One-touch "Comfort Wind" function with automatic left-right sweep delivers personalized airflow to suit different preferences and age groups.

LED Backlight Display

Easy-to-read LED display for clear visibility, even at night.

Filter Dirty Alarm

Smart reminder after 1,000 hours of operation alerts you to clean the filter, ensuring optimal performance and healthier airflow.

FAC12AB1FMYB/68

Specifications

Classification

Air conditioning: Split air conditioning

Sustainable

Refrigerant: R32

Charged Volume(g): 520

Technical Specification

Voltage: 220-240 V

Frequency: 50Hz

Phase: 1

Energy Efficiency

Energy Rating: ★★★

Cooling T1

Capacity(W): 3517

Capacity(Btu): 12000

Power Input(W): 1078

Running Current(A): 4.7

EER(W/W): 3.26

EER(Btu/h/W): 11.13

CSPF(W/W): 3.46

CSPF(Btu/h/W): 11.81

Indoor Unit

Sound Levels(S/H/M/L/SL)(dB(A)):

48/40/38/35/30

Air Circulation(S/H/M/L/SL)(m³/h):

690/540/490/440/350

Net Dimension(WxHxD)(mm): 790x275x198

Package Dimension(WxHxD)(mm):

856X342X292

Net/Gross Weight(kg): 9/11.5

Outdoor Unit

Sound Levels(H)(dB(A)): 51

Net Dimension(WxHxD)(mm): 805X517X318

Package Dimension(WxHxD)(mm):

842X348X570

Net/Gross Weight(kg): 27/29.5

Piping Connection

Liquid(mm(inch)): ϕ 6.35(1/4)

Gas(mm(inch)): ϕ 12.7(1/2)

Chargeless Pipe Length

Chargeless Pipe Length(m): 5

Maximum Pipe Length

Maximum Pipe Length(m): 10

Maximum elevation Length

Maximum elevation Length(m): 5

