

PHILIPS



True wireless
headphones

1000 series

Small buds. Great value

Natural sound. Dynamic Bass

Pocket-sized charging case

Up to 20 hours of play time



TAT1510BK

Get your music on

The best things in life are simple. Grab your headphones, take your tunes and head out! With great sound, dynamic bass and a pocket-sized charging case, these comfy true wireless earbuds are ready for your day—and night.

Great sound and clear call

- Always hear your music. Noise Cancelling
- Great sound even at low volume with Dynamic Bass
- Clear calls. They'll hear what you're saying

Packed with essential features

- No worries. Up to 20 hours of play time with the case
- Quick charge for 15 minutes and get an extra hour
- Multipoint connection and touch controls
- IPX4 splash and sweat resistant

Ready for you

- Always ready. Pocket-sized charging case and mono mode
- Philips Headphones app. Personalise your earbuds
- Warm, natural sound. Philips sound signature
- RCS-certified recycled plastic. Responsible packaging

1000 series

True wireless headphones

TAT1510BK/00

Specifications

Sound

Frequency range: 20–20,000 Hz

Speaker diameter: 10 mm

Impedance: 32 Ohm

Maximum power input: 8 mW

Sensitivity: 107 dB (1 kHz)

Driver type: Dynamic

Connectivity

Bluetooth version: 5.4

Bluetooth profiles: A2DP, AVRCP, HFP

Maximum range: Up to 10 m

Multipoint connection

Supported codec: SBC

Outer Carton

Length: 30.00 cm

Number of consumer packages: 24

Width: 16.00 cm

Gross weight: 2.328 kg

Height: 20.00 cm

GTIN: 1 48 95229 17650 5

Net weight: 1.45 kg

Tare weight: 0.878 kg

Convenience

Water resistance: IPX4

Philips Headphones app support

Mono mode for TWS

Firmware updates possible

Type of controls: Touch

Power

Number of batteries: 3 pcs

Music play time: 6 + 14 hour(s)

Charging time: 2 hour(s)

Fast charging time: 15 mins for 1 hr

Battery type (Charging case): Lithium Polymer (Built-in)

Battery type (Earbud): Lithium Polymer (Built-in)

Battery weight (Total): 8.7 g

Battery capacity (Case): 350 mAh

Battery capacity (Earbud): 40 mAh

Packaging dimensions

Height: 11 cm

Packaging type: Carton

Type of shelf placement: Hanging

Width: 9.5 cm

Depth: 3.6 cm

Number of products included: 1

EAN: 48 95229 17650 8

Gross weight: 0.086 kg

Net weight: 0.061 kg

Tare weight: 0.025 kg

Accessories

Quick Start Guide

Eartips: 3 sizes (S/M/L)

Charging case

Charging cable: USB-C cable, 200 mm

Design

Colour: Black

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear-tip

Telecommunication

Microphone for call: 1x AI mic

Dimensions

Charging case dimension (W x D x H): 6.39 x 2.79 x 5.05 cm

Earbud dimension (W x D x H): 3.20 x 2.08 x 2.30 cm

Total weight: 0.04 kg

UPC

UPC: 8 40063 20767 7

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant

Voice assistant activation: Multi-Function touch

Voice assistant support

Sustainability

Plastic shell: contains 45% RCS certified recycled post-consumer Polycarbonate TE-00132492

Highlights

Noise Cancelling

Noise cancelling quietyens external noise, including wind, so you can focus on your tunes or calls. Want to hear more of what's going on around you? Tap an earbud to activate Awareness Mode.

Great sound. Dynamic Bass

These true wireless earbuds sound great, and you won't need to turn up the volume to get the best out of their 10 mm drivers. Activate Dynamic Bass via the left earbud and you can enjoy the full power of your favourite basslines even if listening quietly.

Clear calls

Your voice will come through clearly when you're on a call. One AI mic picks up the sound of your voice while a noise-reduction algorithm quietyens some of the background noise from the world around you.

20 hours of play time with the case

You get 6 hours of play time from a full charge, and an extra 14 hours from the case with noise cancelling off. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

Multipoint and touch controls

Touch controls on the earbud stalks keep things simple, and multipoint lets you connect to two Bluetooth devices (iOS or Android) at the same time.

Pocket-sized charging case

Head out with the small charging case in your pocket and your earbuds will always be ready for you. They'll stay protected and keep charging when you're not using them, and mono mode means that you can use either earbud while the other one charges.

Philips sound signature

The custom drivers in these headphones are tuned to the Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled carboard with inserts printed on recycled paper.

