

PHILIPS



EcoDesign

Signage Solutions

65"

Direct LED Backlight

Ultra HD



65BDL3650QE

Display better

EcoDesign 18/7 display

Engage your audience with this environmentally conscious 4K Ultra HD digital display. Delivering uncompromised 4K UHD performance while running on half the power compared to other market models, with the very latest PPDS EcoDesign.

Cost-effective system solution

- Android SoC processor. Native and web apps

Effortless setup. Total control.

- FailOver. Ensure that content is always running
- Optional Interact for wireless screen share
- Philips Wave ready for remote management

Smart and powerful

- Connect and control your content via the cloud
- Wi-Fi and Bluetooth 5.2 via optional module

Sustainable quality. EcoDesign

- 100% recycled and recyclable packaging
- EPEAT Gold Climate+ certified
- Consumes >50% less energy compared to equivalent models

Highlights

PPDS EcoDesign

Designed with manufacturing processes, physical features, materials, packaging and built-in software that are kinder to the environment and deliver better energy efficiency, the Philips Signage 3650 EcoDesign display is designed to operate using less than half the power of its counterparts, while still delivering the same unrivalled performance.

Powered by Android 10

Powered by our Android 10 SoC platform, these hard-working displays are optimised for native Android apps, and you can install web apps directly onto the display too. Flexible and secure, ensuring that display specs stay up to the moment for longer.

SmartBrowser

Connect and control your content via the cloud with the integrated HTML5 browser. Using the Chromium-based browser, design your content online and connect a single display or your complete network. Show content in both landscape and portrait mode, with full HD

resolution. Simply connect the display to the Internet using the optional CRD22 Wi-Fi module or via LAN, and enjoy your own created playlists.

EPEAT Gold Climate+ certified

Recognised by and registered with EPEAT with a Gold Climate+ Ecolabel, the Philips Signage 3650 EcoDesign meets the robust set of criteria laid out by the world's premier ecolabel for electronics.

FailOver

Critical for demanding commercial applications, FailOver is a revolutionary technology that automatically plays back-up content onscreen in the unlikely event of an input source or application failure. Simply select a primary input connection and a FailOver connection and you are ready for instant content protection.

Interact (optional)

Wirelessly screen-share using your existing Wi-Fi network to instantly and securely connect devices, or use our optional HDMI Interact dongle to cast directly onto the screen without connecting to the secured network.

Philips Wave

Unlock the power, versatility and intelligence inside your Philips Signage 3650 EcoDesign displays remotely with Wave. This evolutionary cloud platform puts you fully in control, with simplified installation and setup, monitoring and controlling displays, upgrading firmware, managing playlists and setting power schedules — saving you time, energy and environmental impact.

Integrated media player

Easily schedule content to play from a USB or from internal memory. Your Philips Professional Display will wake from standby to play the content you want, and then return to standby once playback is done.

Specifications

Picture/Display

Diagonal screen size (metric): 163.9 cm
Diagonal screen size (inch): 64.5 inch
Aspect ratio: 16:9
Panel resolution: 3840 x 2160
Pixel pitch: 0.372 x 0.372 mm
Optimum resolution: 3840 x 2160 @ 60 Hz
Brightness: 350 cd/m²
Display colours: 1.06 Billion
Contrast ratio (typical): 1200:1
Dynamic contrast ratio: 500,000:1
Response time (typical): 8 ms
Viewing angle (horizontal): 178 degree
Viewing angle (vertical): 178 degree
Picture enhancement: 3/2 - 2/2 motion pull down, Motion compens. deinterlacing, Progressive scan, Dynamic contrast enhancement
Panel technology: IPS
Operating system: Android 10
Haze: 25%

Connectivity

Audio output: 3.5 mm jack
Video input: DVI-I (x 1), HDMI 2.0 (x 2), USB 2.0 (x 2), USB 3.0 (x 2)
Audio input: 3.5 mm jack
Other connections: micro SD
External control: RS232C (in/out) 2.5 mm jack, IR (in/out) 3.5 mm jack, RJ45
Optional WiFi functionality: CRD22 Wi-Fi dongle

Convenience

Placement: Landscape (18/7), Portrait (18/7)
Tiled Matrix: Up to 15 x 15
Keyboard control: Hidden, Lockable
Remote control signal: Lockable
Signal loop through: RS232, IR Loop through
Ease of installation: Smart Insert
Energy-saving functions: Smart Power
Network controllable: RS232, RJ45

Sound

Built-in speakers: 2 x 10 W RMS

Power

Mains power: 100–240 V~, 50/60 Hz
Consumption (Typical): 86 W
Consumption (Max): 133 W
Standby power consumption: <0.5 W
Power Saving Features: Smart Power
Energy Label Class: C

Supported Display Resolution

Computer formats: 1920 x 1080, 60 Hz, 1680 x 1050, 60 Hz, 1600 x 1200, 60 Hz, 1440 x 900, 60 Hz, 1280 x 1024, 60 Hz, 1280 x 800, 60 Hz, 1280 x 720, 60 Hz, 1152 x 870, 75 Hz, 1024 x 768, 60, 70, 75 Hz, 800 x 600, 56, 60, 72, 75 Hz, 720 x 400, 70 Hz, 640 x 480, 60, 67, 72, 75 Hz, 1152 x 864, 75 Hz, 832 x 624, 75 Hz, 3840 x 2160, 24, 25, 30, 60 Hz
Video formats: 480p, 60 Hz, 480i, 60 Hz, 1080p, 50, 60 Hz, 1080i, 50, 60 Hz, 720p, 50, 60 Hz, 3840 x 2160p, 24, 25, 30, 60 Hz

Dimensions

Set Width: 1462.3 mm
Product weight: 28.5 kg
Set Height: 837.3 mm
Set Depth: 68.9 mm (D@wall mount)/89.9 mm (D@handle) mm
Set Width (inch): 57.57 inch
Set Height (inch): 32.96 inch
Wall Mount: 400 x 400 mm, M8
Set Depth (inch): 2.71(@ wall mount) / 3.54(@ handle) inch
Bezel width: 14.9 mm (Even bezel)
Product weight (lb): 62.83 lb

Operating conditions

Altitude: 0 ~ 3000 m
Temperature range (operation): 0 ~ 40 °C
MTBF: 30,000 hour(s)
Temperature range (storage): -20 ~ 60 °C
Humidity range (operation)[RH]: 20~80% RH (No condensation)
Humidity range (storage) [RH]: 5~95% RH (No condensation)

Multimedia Applications

USB Playback Video: H.264, H.263, H.265, MPEG1/2, MPEG4, VP8, VP9
USB Playback Picture: BMP, JPEG, PNG
USB Playback Audio: AAC, HEAAC, MPEG

Internal Player

CPU: Quad-Core Cortex A55
GPU: G52 MC1
Memory: 16 GB, 3 GB DDR

Accessories

Included Accessories: IR sensor cable (1.8 m) (x 1), RS232 daisy-chain cable, Philips logo (x 1), USB Cover (x 1), AC Power Cord, AC Switch Cover, Cable clip (x2), Quick start guide, RS232 cable

Miscellaneous

On-Screen Display Languages: Simplified Chinese, Traditional Chinese, English, French, German, Italian, Polish, Russian, Spanish, Turkish, Japanese, Arabic
Warranty: 3 year warranty
Regulatory approvals: CE, CB, BSMI, FCC, Class A, VCCI, J-Moss, ETL, RoHS

