

PHILIPS

On-ear headphones

Natural sound. Dynamic Bass

Comfort on-ear fit

Noise Cancelling

Up to 70 hours of play time

TAH4500LB



Slip into great sound

If you want super-comfy noise-cancelling headphones for daily use, these are it. You get rich sound with deep bass even at low volumes. The replaceable ear-cup cushions and battery maximise comfort and performance in the years to come.

On-ear wireless headphones. Focus and flow.

- Great sound even at low volume with Dynamic Bass
- Custom-tuned 32 mm drivers
- Comfort fit with replaceable components for years of use

Comfort fit, noise cancelling, long battery life

- Always hear your music with Active Noise Cancelling
- Stable Bluetooth® multipoint connectivity and easy pairing
- Bluetooth® 6.0, Android Fast Pair, Microsoft Swift Pair
- Up to 70 hours of play time (50 with noise cancelling on)
- Quick charge for 5 minutes to get an extra 4 hours

Clear calls and intuitive in-app equalizer

- Clear calls. They'll hear what you're saying
- Philips Headphones app. Customise your experience
- Warm, natural sound. Philips sound signature
- GRS-certified recycled plastic. Responsible packaging

Highlights

Great sound. Dynamic Bass

Custom-tuned 32 mm drivers and Dynamic Bass combine to bring you great sound with full, rich bass even at low volumes. If you're watching a film or gaming, you can turn on a low-latency mode in our companion app.

Long-lasting comfort

Soft PU leather ear cups and a soft adjustable headband give you a super-comfy fit. For the best acoustic seal and comfort, you can replace the memory-foam ear cushions if they wear down over time. You can also swap out the headphone's rechargeable lithium-ion battery when it reaches the end of its life.

Active Noise Cancelling

Active noise cancellation reduces external noise so you can focus on your tunes, podcasts and calls. You can leave it on auto or use the Philips Headphones app to adjust the levels yourself.

Bluetooth® 6.0

Compatibility with the latest Bluetooth® 6.0 devices lets you stream without annoying dips in the sound, and you can connect to two devices at once. Android Fast Pair and Microsoft Swift Pair are supported too.

Up to 70 hours (with ANC off)

With noise cancelling off, you can get up to 70 hours of play time from a full charge, and with noise cancelling on, you get up to 50 hours. For a quick boost, charge for just 5 minutes to get an extra 4 hours.

Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm reduces some of the background noise from the world around you.

Philips Headphones app

Feel like your music's missing something? Our companion app features EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to adjust noise cancellation, activate Dynamic Bass, manage connected devices, update firmware and more.

Philips sound signature

The custom drivers in these headphones are tuned to the Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

Specifications

Sound

Acoustic system: Closed
Frequency range: 20 - 20,000 Hz
Impedance: 32 Ohm
Maximum power input: 10 mW
Sensitivity: 113 dB (1 kHz, 1 mW)
Speaker diameter: 32 mm
Driver type: Dynamic

Connectivity

Bluetooth version: 6.0
Bluetooth profiles: A2DP, AVRCP, HFP
Maximum range: Up to 10 m
Multipoint connection
Supported codec: SBC

Outer Carton

Length: 21.70 cm
Number of consumer packages: 3
Width: 18.50 cm
Gross weight: 1.32 kg
Height: 25.50 cm
GTIN: 1 48 95229 17758 8
Net weight: 0.50 kg
Tare weight: 0.82 kg

Convenience

Volume control
Philips Headphones app support
Google Fast Pair

Firmware updates possible

Type of controls: Button
Microsoft Swift Pair

Power

Number of batteries: 1 pcs
Charging time: 2 hour(s)
Music play time (ANC on): 50 hour(s)
Music play time (ANC off): 70 hour(s)
Fast charging time: 5 mins for 4 hrs
Battery weight (Total): 9.52 g
Battery capacity (Headphones): 500 mAh
Battery type (Headphones): Lithium Polymer (built-in)

Packaging dimensions

Height: 24.5 cm
Packaging type: Carton
Type of shelf placement: Hanging
Width: 19.85 cm
Depth: 5.5 cm
Number of products included: 1
EAN: 48 95229 17758 1
Gross weight: 0.332 kg
Net weight: 0.168 kg
Tare weight: 0.164 kg

Product dimensions

Height: 17.84 cm
Width: 15.84 cm
Depth: 7.37 cm
Weight: 0.156 kg

Accessories

Quick Start Guide

Design

Colour: Light Blue
Wearing style: Headband
Foldable design: Flat/Inwards
Ear coupling material: Synthetic leather
Ear fitting: On-ear
Earcup type: Closed-back

Telecommunication

Microphone for call: 1 mic

UPC

UPC: 8 40063 20803 2

ANC features

ANC technology: FB
Microphone for ANC: 3 mic
ANC (Active Noise Cancelling)

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant
Voice assistant activation: Press Multi-Function button
Voice assistant support

Sustainability

Plastic shell: contains 71% GRS certified recycled post-consumer Polycarbonate TE-00132492

