

PHILIPS

True wireless headphones

Small buds. Comfort fit.

Adaptive Noise Canceling

6-mic technology

Detailed, natural sound

TAT3000BK



Set the vibe, love the fit

Listen freely with true wireless earbuds that feel lighter, fit better, and sound rich, warm, and detailed. Adaptive Noise Canceling responds to your surroundings, while Cafe and Lounge modes let your music hang back and set the vibe.

True wireless earbuds. Adaptive noise canceling

- Detailed sound, comfort fit, and Spatial Audio modes
- Comfy SecureFit ear tips and large 10 mm drivers
- Immerse freely with Adaptive Noise Canceling
- Stable Bluetooth® multipoint connection and Auracast™
- 6-mic technology. Clearer calls, even in crowded places

Your daily go-to

- IPX4 splash and sweat resistant
- Up to 48 hours play time. Pocket-sized charging case
- Quick charge for 10 minutes and get an extra 2 hours

Ready for you

- Philips Headphones app. Customize your experience
- GRS-certified recycled plastic. Responsible packaging
- Warm, natural sound. Philips sound signature

Highlights

Small earbuds, detailed sound

SecureFit textured ear tips bring you a fit that feels lighter and more comfortable, while creating a good seal for even better sound.

Philips Spatial Audio features include Cafe and Lounge modes, which make your music sound like part of the background ambience: great for focusing on a task while listening.

Adaptive Noise Canceling

Adaptive noise cancellation quickly reacts to your surroundings to suppress external noise, including wind, in real time. If you want to hear what's going on around you, Awareness Mode lets outside sounds back in. Quick Awareness enhances voices, so you can have a conversation without removing your headphones.

Bluetooth® 6.0, Auracast™

Bluetooth® 6.0 ensures a fast, steady connection, and support for Auracast™ lets you listen to public broadcasts on your travels. You can connect to two Bluetooth® devices at once and

manage connected devices via our app—plus Microsoft Swift Pair makes life easy for Windows users.

6-mic technology

These headphones boast a six-mic setup, and three of those mics plus an AI noise-reduction algorithm combine to bring you super-clear calls. Even if you're in a busy cafe, your voice will come through clearly and the person you're speaking to won't be distracted by what's going on around you.

IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

48 hours play time (12 + 36)

With noise canceling off, you get 12 hours play time from a full charge and an extra 36 hours from the pocket-sized charging case (with noise canceling on you get 8 hours and an extra 24

from the case). For a quick boost, 10 minutes gives you an extra 2 hours. The case can be charged via USB-C.

Philips Headphones app

Feel like your music's missing something? Our companion app features EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to activate Dynamic Bass, manage connected devices, update firmware, and more.

Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

Specifications

Sound

Frequency range: 20 - 20,000 Hz
Speaker diameter: 10 mm
Impedance: 32 Ohm
Maximum power input: 5 mW
Sensitivity: 106 dB (1K Hz, 179 mv)
Driver type: Dynamic

Connectivity

Bluetooth version: 6.0
Bluetooth profiles: HFP, A2DP, AVRCP
Maximum range: Up to 10 m
Multipoint connection
Supported codec: SBC, LC3

Outer Carton

Length: 26.50 cm
Number of consumer packagings: 24
Width: 23.00 cm
Gross weight: 3.05 kg
Height: 22.50 cm
GTIN: 1 48 95229 17941 4
Nett weight: 1.57 kg
Tare weight: 1.48 kg

Convenience

Volume control
Water resistance: IPX4
Philips Headphones app support
Mono mode for TWS
Firmware updates possible
Type of controls: Touch
Google Fast Pair
Microsoft Swift Pair

Inner Carton

Length: 12.30 cm
Number of consumer packagings: 3
Width: 10.05 cm
Height: 10.00 cm
Nett weight: 0.20 kg
Gross weight: 0.336 kg
Tare weight: 0.136 kg
GTIN: 2 48 95229 17941 1

Power

Number of batteries: 3 pcs
Charging time: 2 hour(s)
Music play time (ANC on): 8 + 24 hour(s)
Music play time (ANC off): 12 + 36 hour(s)

Fast charging time: 10 mins for 2 hrs
Battery type(Charging case): Lithium Polymer (built-in)
Battery type(Earbud): Lithium Polymer (built-in)
Battery weight (Total): 13.27 g
Battery capacity(Case): 600 mAh
Battery capacity(Earbud): 60 mAh

Packaging dimensions

Height: 10.9 cm
Packaging type: Carton
Type of shelf placement: Hanging
Width: 9.6 cm
Depth: 3.55 cm
Number of products included: 1
EAN: 48 95229 17941 7
Gross weight: 0.093 kg
Nett weight: 0.066 kg
Tare weight: 0.027 kg

Accessories

Quick Start Guide
Eartips: 3 pairs (S/M/L)
Charging case

Design

Color: Black
Wearing style: In-ear
Ear coupling material: Silicone
Ear fitting: In-ear
In-ear fitting type: Silicone ear tip

Telecommunication

Microphone for call: 3 mics for each side

Dimensions

Charging case dimension(WxDxH): 6.21 x 2.80 x 4.89 cm
Earbud dimension(WxDxH): 3.21 x 2.38 x 2.07 cm
Total weight: 0.052 kg

ANC features

ANC technology: Hybrid
Awareness mode
Adaptive ANC
Microphone for ANC: 2 mic
ANC (Active Noise Canceling)

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant
Voice assistant activation: Multi-Function touch
Voice assistant support

Sustainability

Plastic shell: contains 57% recycled post-consumer Polycarbonate TE-00132492

