

# PHILIPS



## True wireless headphones

Smart charging case

Noise Canceling

4-mic technology

Detailed, natural sound



TAT6000BK

## Great sound, multitasking smart case

You'll flow through your day with these great-sounding true wireless earbuds and their smart charging case. Noise canceling lets you listen free from distractions, while the case lets you take control without reaching for your phone.

### **True wireless earbuds. Natural sound, smart case.**

- Smart charging case. Touch controls for music and more
- Noise canceling for your sounds, your focus, your world
- 4-mic technology. Clearer calls, even in crowded places
- Great sound even at low volume with Dynamic Bass

### **Simply all you need**

- Up to 28 hours play time
- Stable Bluetooth® connection and multipoint connectivity
- Comfy, water-resistant, customizable
- IPX5 rating and three sizes of silicone ear tips

### **Seamlessly brilliant**

- Quick charge for 15 minutes and get an extra 3 hours
- Philips Headphones app. Custom control
- Warm, detailed, natural. Philips sound signature
- Responsible design and packaging

# Highlights

## Smart charging case

You can use this case to take calls, control playback and noise canceling, tweak bass and treble, or find a missing earbud. The 1.47" touchscreen also features a clock and a timer, plus a flashlight function that emits bright white light. A true multitasker, the case can even take photos by remotely triggering the camera on your connected device.

## Noise Canceling

Music, calls, podcasts, movies. When you want to focus, you can activate and control noise canceling via the earbud's touch controls, the smart case, or our companion app. Handy features include Awareness Mode to let outside sounds back in. Quick Awareness enhances voices so you can have a conversation without removing an earbud.

## 4-mic technology

If you're on a call, our four-mic setup and a noise-reduction algorithm will combine to pick up the sound of your voice and quieten background noise. Even if you're in a busy cafe, your voice will come through clearly and the person you're speaking to won't need to listen to all the other conversations going on around you as well!

## Great sound. Dynamic Bass

You won't need to turn up the volume to get the best sound out of the 10 mm drivers in these true wireless earbuds. Activate Dynamic Bass via the customizable earbud controls, or the Philips Headphones app, and you can enjoy the full power of your favorite basslines even if listening quietly.

## 28 hrs play time (7 + 21)

With noise canceling off, you get 7 hours play time from a full charge and an extra 21 hours from the smart charging case (with noise canceling on, you get 5 hours and an extra 16 from the case). For a quick boost, 15 minutes gives you an extra 3 hours. The case can be charged via USB-C.

## Bluetooth® 5.4, multipoint

Bluetooth® 5.4 brings you a steadier connection for seamless streaming without annoying dips in the sound, even in built-up areas. Multipoint connectivity lets you connect to two Bluetooth® devices at the same time, and you can easily manage connected devices via the Philips Headphones app.

## Philips Headphones app

Our handy companion app makes it easy to adjust settings for the smart charging case, including how long the screen stays on and

whether it displays a 12- or 24-hour clock. You can also use the app to personalize noise canceling, activate a low-lag setting for gaming, get the latest firmware, and more.

## Responsible design

We're continually working to make our supply chain more sustainable and transparent. These earbuds are made with RCS-certified post-consumer recycled plastics, and our plastic-free packaging uses FSC-certified recycled cardboard and soy-based ink.

## IPX5 and comfy in-ear fit

An IPX5 rating means these buds can handle the moisture if you sweat, and a little light rain won't bother them either. You get three sizes of silicone ear tips for the perfect fit, and you can customize how the earbud touch controls are set up via the Philips Headphones companion app.

## Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, detailed sound with rich bass. Whatever you're listening to, you'll love what you hear.

# Specifications

## Sound

Acoustic system: Closed  
Frequency range: 20 - 20,000 Hz  
Speaker diameter: 10 mm  
Impedance: 16 Ohm  
Maximum power input: 5 mW  
Sensitivity: 105 dB (1kHz)  
Driver type: Dynamic

## Connectivity

Bluetooth version: 5.4  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC

## Outer Carton

Length: 23.00 cm  
Number of consumer packagings: 24  
Width: 22.00 cm  
Gross weight: 4.35 kg  
Height: 30.60 cm  
GTIN: 1 48 95229 16543 1  
Nett weight: 1.92 kg  
Tare weight: 2.43 kg

## Convenience

Automatic power off  
Volume control  
Water resistance: IPX5  
Philips Headphones app support  
Mono mode for TWS  
Firmware updates possible  
Type of controls: Touch

## Inner Carton

Length: 10.80 cm  
Number of consumer packagings: 3  
Width: 9.80 cm  
Height: 13.50 cm  
Nett weight: 0.24 kg  
Gross weight: 0.50 kg  
Tare weight: 0.26 kg  
GTIN: 2 48 95229 16543 8

## Power

Number of batteries: 3 pcs  
Music play time (ANC on): 5 + 16 hour(s)  
Music play time (ANC off): 7 + 21 hour(s)  
Fast charging time: 15 mins for 3 hrs

Battery type(Charging case): Lithium Polymer (built-in)  
Battery type(Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 10.1 g  
Battery capacity(Case): 410 mAh  
Battery capacity(Earbud): 50 mAh

## Packaging dimensions

Height: 11 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 9.5 cm  
Depth: 3.9 cm  
Number of products included: 1  
EAN: 48 95229 16543 4  
Gross weight: 0.106 kg  
Nett weight: 0.080 kg  
Tare weight: 0.026 kg

## Accessories

Quick Start Guide  
Eartips: 3 pairs (S/M/L)  
Charging case  
Charging cable: USB-C cable, 200 mm

## Design

Color: Black  
Ear coupling material: Silicone  
Ear fitting: In-ear  
In-ear fitting type: Silicone ear tip

## Telecommunication

Microphone for call: 4 mics

## Dimensions

Charging case dimension(WxDxH): 3.00 x 6.60 x 4.20 cm  
Earbud dimension(WxDxH): 2.90 x 2.10 x 2.30 cm  
Total weight: 0.056 kg

## UPC

UPC: 8 40063 20663 2

## ANC features

ANC technology: Hybrid  
Awareness mode  
Adaptive ANC  
Microphone for ANC: 4 mic  
ANC (Active Noise Canceling)

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Multi-Function touch  
Voice assistant support

## Sustainability

Plastic shell: contains 76% RCS certified recycled post-consumer Polycarbonate TE-00132492

